


骨传导耳机



使用指南及保修说明

Operating instructions and Warranty description

示意图及配件



- ① 麦克风
- ② 电源键/多功能复合键
- ③ 指示灯(内侧)
- ④ 充电口
- ⑤ 音量“—”键
- ⑥ 音量“+”键

配件清单

1. 耳机
2. Type-C充电线
3. 说明书(含保修卡)

使用说明

开机

长按电源键约3秒，当指示灯红蓝交替闪烁，表示耳机已经开机。

无线连接

首次使用，耳机正常开机后，会进入无线配对状态，此时手机无线设置里可搜索到“K08”，点击连接，成功后指示灯熄灭，播放音乐时，指示灯蓝灯5秒闪烁一次。

更换配对设备及回连

断开当前配对设备连接，耳机指示灯红蓝交替闪烁，其他设备即可搜索到“K08”点击连接。

耳机支持自动回连配对设备，正常开机后即会自动回连最后一次连接的设备，请确保前端(如手机无线)正常开启。

关机

长按电源键约3秒即会关机，指示灯熄灭。

充电

正常连接，手机会显示耳机电量，如电量显示红色，即表示需要充电，插入充电线充电即可。

备注:5V充电设备，如手机充电器都可进行充电。

操作说明

电源键/多功能复合键

长按电源键3秒—————耳机开/关机

长按1秒电源键出提示音后松手—————唤醒语音助手

播放状态

单击电源键—————暂停播放

长按“+”键2秒—————下一曲

长按“-”键2秒—————上一曲

单击“+”键—————音量加

单击“-”键—————音量减

来电状态

单击电源键—————接听

单击电源键—————挂断

长按电源键1秒—————拒接

长按电源键2秒—————手机与耳机音源切换

指示灯说明

红蓝交替：配对状态

红灯常亮：正在充电

蓝灯常亮：充满电量

产品参数

型号: K08

版本: 5.4

重量: 25g

电池: 160mAh

充电: ≈2小时

播放: ≥6小时&60%音量

通话: -38±3dB

距离: ≈10米

输入: 5V/130mA

协议: HFP, A2DP, AVRCP

故障及排除

无法开机

确定耳机是否充满电量，按键是否误操作，同时充电激活。

无法连接手机

耳机指示灯是否处于红蓝交替闪阶段，如耳机处于蓝灯呼吸状态，表示耳机与其他设备已经连接，需要断开当前连接设备。

无法回连

确定前端（如手机无线）是否正常开启。

耳机音量较小

手机是否需加大音量，需要手机增加或减小音量。确认佩戴方式是否正确。

合格證
Q.C.Passed

产品保修卡

该卡为产品保修凭证，请妥善保管

产品名称:	产品型号:
购买日期:	客户名称:
联系方式:	

产品维修记录

日期	不良现象	方案


Bone Conduction Headphones



User's Guide and warranty

Operating instructions and Warranty description

Schematic diagram and accessories



- ① Microphone
- ② Power/Multi function composite key
- ③ Indicator tight (inside)
- ④ Charging port
- ⑤ Volume“—”
- ⑥ Volume“+”

Parts list

1. headset
2. Type-C charging cable
3. Instruction manual (including warranty card)

Instructions

Power on

Press the power button for about 3 seconds. When the red and blue light alternately flashes, it means the headset has been turned on.

Wireless connection

For the first time use, after the headset are turned on normally, they will enter Wireless pairing mode. At this time, "K08" can be searched in the phone's Wireless settings. Click to connect, and after successful connection, the indicator light will turn off, and the blue light will flash once every 5 seconds when playing music.

Replacement of matching equipment and reconnection

Disconnect the Wireless of the currently paired device, and the headphone indicator light will flash alternately in red and blue. Other devices can search for "K08" and click to connect. The headset support automatic reconnection to paired devices. After normal startup, they will automatically reconnect to the last connected device. Please ensure that the front-end (such as Wireless on your phone) is turned on normally.

Power off

Press and hold the power button for about 3 seconds to turn off the device and the indicator light will turn off.

Charging

If connected normally, the phone will display the headset battery level. If the battery level displays in red, it means that it needs to be charged. Simply plug in the charging cable to charge.

Note: 5V charging devices, such as mobile phone chargers, can be charged.

Operating instructions

Power/Multi function Composite Key

Press for 3 seconds—————Power on/off the headset

Press for 1second to release your hand—————Wake up voice assistant

Play music

Click the power button—————Pause playback

Press“+”for 2 seconds—————Next song

Press“-”for 2 seconds—————Previous song

Click“+”—————Volume up

Click“-”—————Volume decrease

Call status

Click the power button—————Answer

Click the power button—————Hang up

Press the power button for 1 second—————Reject

Press the power button for 2 seconds—————Switching between phone and headset audio sources

Indicator light description

Alternate red and blue: Pairing state

The red light is always on: Charging

Blue light always on: Full charge

Product parameters

Model : K08

Version : 5.4

Weight : 25g

Battery : 160mAh

Charging : ≈2 hours

Play : ≥6H&60% volume

Voice : -38±3dB

Distance : ≈10 meters

Input : 5V/130mA

Protocol : HFP, A2DP, AVRCP

Troubleshooting

Unable to boot

Determine whether the headset is fully charged, whether the button is misoperated, and then charge and activate.

Unable to connect to Wireless

Whether the headphone indicator is in the alternately flashing stage of red and blue, such as the headphone is in the breathing state of blue light, Indicates that the headset has been connected to other devices and needs to disconnect the current connected device.

Can't back to even

Make sure the front end (e.g., Wireless) is open properly.

Headset volume is low

Whether the phone increases the volume, the phone needs to increase or decrease the volume. Wearing a way Whether it is right.

Certificate of conformity
Q.C.Passed

Product warranty card

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Purchase date:	Clients name:
Contact:	

Product maintenance records

Date	Bad phenomenon	Solution

70mm

95mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.