

User manuals

I : APP Download

The public version of the APP is now available on major app shops worldwide.

Search for "Tuya Smart" or "Smart Life" in the app shops or scan the QR code below to download.



II : Guidelines for fast equipment distribution network

1. Download the APP and register your personal account, and open the Bluetooth of your mobile phone and connect to the WIFI network after successfully login.
- 2.Press and hold the ON/OFF button of the controller for more than 5 seconds, when you see the light body light up in red and flashing rapidly, release the button, the device will enter the network state.
3. Click Figure 1 [Add Device] or the [+] plus sign in the upper right corner, then select Figure 2 [Auto Scan] and click [Next] to enter the Figure 3 page and click [Next].

Figure 1







Figure 2



Figure 3




4. Enter the password of the currently connected WIFI, click [Next] to light up the white light after successful connection, then click [Next], finally click [Done] in the upper right corner to enter the main control interface of the APP to complete the network (if the above operation is not successful, then return to the first step to re-operation)



III: Equipment unbinding.

After completing the wiring test action, if you need to unbind the device, you can unbind it directly on the top of the APP interface, after clicking unbind, the device

1. APP unbinding: Click on the top right corner of the device control interface. Click the button at the top right corner of the device control interface to enter the device details page, and then click [Remove Device] at the bottom of the device details interface.
- After the APP unbundling is completed, the online device will also be unbundled automatically and will enter the fast networking function with the red light flashing.



IV : Controller function




Button	Function
ON/OFF	Short press to turn on/off, long press for 5 seconds and the red light will flash, entering network status
CCT	Color Switch
MODEL	Scene Modes/Music Modes (Press for 1 second, and the white light will flash, press it again ,the two modes switch between each other)

V : Installation diagram



- Way 1: Mount it vertically
2: Attach the light bars to the back



1. Peel off the 3M self-adhesive centrifugal paper and stick it to the base surface
2. Wipe the adhered surface, then peel off the other side of the centrifugal paper and adhere it



VI:Function



VII: Wide Applications: Home, bars, game halls, etc.



VIII: Troubleshooting

1. When the device cannot be linked to the Smart Life app

Make sure the device is powered on and the phone is connected to WIFI and Bluetooth is turned on

When connecting for the first time, make sure your smartphone is close to the device and the router.

Make sure the device is in the pending connection state and the red light flash

If it is still not successful,please exit the Smart Life app and then go back in to the Smart Life app to connect (make sure the device is in the pending connection state and the red light is flashing)

2. Sluggish response and loss of connection

Make sure the WIFI network is stable and the device is powered up properly

Re-exit the Smart Life program and re-enter the Smart Life program to connect

3. Device music sensitivity is not enough

Make sure the controller is close to the music source, this will make the microphone sound better

You can adjust the sensitivity inside the "Smart Life" program

- 4.If the adhesive provided is not sticky enough to wipe the wall,please make sure it is dry and clean.

After installing the bracket, press hard for a few times to make sure it sticks completely.

IX: Third party controls supported

Alexa and Google Assistant

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.