

[illegible][illegible]

La prima legge di sicurezza riguarda l'installazione: il frigorifero deve essere installato su una superficie piana e stabile, con un margine di almeno 10 cm tra il frigorifero e le pareti laterali e posteriori. Inoltre, è importante che il frigorifero sia installato in un ambiente ben ventilato, con una temperatura ambiente compresa tra 16°C e 32°C. La seconda legge di sicurezza riguarda la manutenzione: il frigorifero deve essere pulito regolarmente, sia all'interno che all'esterno, con un panno umido e non abrasivo. Inoltre, è importante che il frigorifero sia controllato regolarmente per verificare che la temperatura sia corretta e che non ci siano guasti o malfunzionamenti. La terza legge di sicurezza riguarda l'uso: il frigorifero deve essere utilizzato correttamente, evitando di sovraccaricare le porte e di aprire le porte troppo spesso. Inoltre, è importante che il frigorifero sia utilizzato in un ambiente sicuro, lontano da fonti di calore e di umidità.

La nuova tecnologia elettronica che permette di realizzare i circuiti integrati VLSI (Very Large Scale Integration) è basata su tecniche di deposizione e di litografia che consentono di realizzare circuiti integrati con un numero di componenti elettronici che può arrivare a 100 milioni per chip. La tecnologia VLSI è basata su tecniche di deposizione e di litografia che consentono di realizzare circuiti integrati con un numero di componenti elettronici che può arrivare a 100 milioni per chip.

[illegible]

「この論文は、我々の研究の成果を、より広く世に知らしめるために、英語に訳して公開している。この論文の著作権は、本学に帰属する。本学は、この論文の著作権を、本学の学術的・教育的目的のために、広く利用することを許す。また、本学は、この論文の著作権を、本学の学術的・教育的目的のために、広く利用することを許す。また、本学は、この論文の著作権を、本学の学術的・教育的目的のために、広く利用することを許す。」

[illegible][illegible][illegible][illegible]

MOCEL : 0398

Charging
To charge the watch, place the watch on the charging base.
Make sure both metal pads on the back of the watch are aligned with the metal tips on the base.
Before charging, please view user manual or website website to make the charging contacts of the watch clean.

Diagram 1: Penhold

The diagram illustrates the correct and incorrect ways to hold a pen. The top row shows three incorrect grips: a tripod grip with the pen held too high, a tripod grip with the pen held too low, and a tripod grip with the pen held too far from the writing tip. The bottom row shows three correct grips: a tripod grip with the pen held at the correct height, a tripod grip with the pen held at the correct height, and a tripod grip with the pen held at the correct height.

CHANGE STRAPS

To remove and replace a strap, please take watch over and use the following steps:

1. Push the crown to the right side of the frame, follow the 12 o'clock case and slide it to release a spring from the bottom of attach a strap to the watch.



OPERATIONS

On the home screen:

- Select a date to expand (Date Settings)
- Select up to see notifications
- Select down to see widgets
- Select right to see widgets or return to the previous screen
- Press and hold to change the watch face

Open watch with slide
Slide left to lock screen

Release to lock
Release left or previous interface

Release to unlock
Release right or next interface

Press once
Press home button or next interface

Press twice
Press home button or next interface

Press and hold
Press home button or next interface

Press and hold
Press home button or next interface

Press for 10 seconds
Press for 10 seconds to force restart

GESTURE CONTROL

When you are using the watch, you can use gestures to control the watch. For example, if you want to turn it on, you can use the touch screen to turn it on. When you are using the watch, you can use gestures to control the watch. For example, if you want to turn it on, you can use the touch screen to turn it on.

Gesture Control