

英文

English Version




I.Instruction for Use

Warm Reminder: This product needs to download the APP, connect to Bluetooth through the APP, and cannot connect to Bluetooth alone. Please notice.


1. Smart watches can measure heart rate and blood oxygen, but cannot be used for any medical functions.
2. Charging: Please charge your smartwatch before use and make sure it is fully charged. Please make sure that the eject pins of the 2 magnetic charging cables are aligned with the 2 charging contacts of the main unit, or plug the charging cables into the USB adapter (adapter 5V 1A). Make sure that the metal contacts are free of dust, oxidation, and impurities. While charging, a charging icon will appear on the smartwatch's screen. If you don't use your smartwatch for a long time, please charge it once a month.
3. Do not use a power adapter with an output current of more than 2A for charging; otherwise, the smartwatch will be damaged.
4. Do not shower with hot water or place the smartwatch under high temperature; otherwise, the water resistance of the smartwatch will be damaged.
5. Do not charge when wet or with water.

II.Appearance

1.Product instruction



01



- 2.Package List
- A.Package Box*1
 - C.User Manual*1
 - B.Smart Watch*1
 - D.Magnetic USB Charger Cable*1

III.Application installation and Bluetooth connection

Please search "Flickudpro" in My app and Google Play on Android devices or APP Store on iPhone; or scan the QR code below to download and install the application.

Note: Android supports 5.0 and above; IOS supports 10.0 and above; Bluetooth hardware 5.0 and above;

Connect the smartwatch. Click on the selection of bind device and then find the device you want to connect to. If there are multiple devices in the vicinity, select the MAC address of the smartwatch you want to bind. If the smartwatch is successfully tied to the phone, the bluetooth icon will display at the top of the smartwatch.



02

Bluetooth 3.0 connection (Bluetooth call connection)

After the watch is connected to the APP, the mobile phone will pop up a Bluetooth pairing request dialog box, connect the NX3 HT audio Bluetooth, click pairing, and the audio connection can be successful. After the watch is successfully connected to the mobile phone, you can use the watch to dial up to control the phone to make calls, answer calls from the mobile phone on the watch, and view the call log information of the watch. When using the Bluetooth calling function, you need to ensure that the connection between the watch and the mobile phone is stable. If the connection is found to be disconnected, please pull down the main interface and click the headset icon to turn blue and the connection is successful.

IV.Product Parameters

Main control chip: RTL8762DK+H4233	Compatibility: IOS 10.0 or above; Android 5.0 or above; It fits most mobile devices on the market.
Screen size: 1.83 inches, TFT color screen	
Battery capacity: 410 mAh	
Battery type: Polymer battery	
Use time: About 10 days	
Waterproof level: IP67	
Charging method: magnetic USB cable	
Operating temperature: 0-40 °C	

V.Instruction for Use

03

- Press the side button or lift your hand to wake up the screen. Slide up to enter the information bar; slide down to enter the control center; slide left to enter the sports data; slide right to enter the split-screen mode.
- ### VI.Function Description
- 1.Replace the Watch Dial
Long press the main page for 3 seconds to enter the watch dial replacement page. Or download the replacement dial on the app.
 - 2.Control Center
Slide down to enter the control center. There are: 1.Do not disturb mode 2.Brightness Adjustment 3.Settings 4.Find my phone 5.Volume 6.Voice assistant
 - 3.Do Not Disturb Mode
Slide down to the control center and click the Do not disturb icon to confirm that do not disturb mode is on.
 - 4.Brightness Adjustment
Slide down to the control center and click the brightness adjustment icon to adjust the brightness of your device.
 - 5.Settings
Slide down to the control center and click the settings icon to enter the function setting.
 - 6.Find My Phone
Slide down to the control center, click Find My Phone icon, and your phone will vibrate to alert you.
 - 7.Volume
Slide down to the control center, click audio icon, open audio mode.

04

- 8.Voice Assistant
Slide down to the control center, click the voice assistant, click the button to enter voice, or long press the function/back button for 3 seconds.
- 9.Sport Data
Slide once to the left to the sports data page, view the sports data, and record steps, calories, and kilometers separately.
- 10.Message
Slide up to the message bar to view message.
- 11.Heart Rate
Slide twice to the left to the heart rate page, start measure and show the data.
- 12.Call Function
This function needs to be connected to audio Bluetooth. When entering the dial, you can enter the phone number and call as needed; long press on the keypad 7 and 9 to enter "and #"
- 13.Sport Mode
Press the function/back button, enter the function page find the sports. Click into the sports mode and choose the sport you like.
- 14.Weather
Press the function/back button, enter the function page find weather, click to check weather.
- 15.Music Control
Press the function/back button, enter the function page find music control, click it and enter to adjust Up and down songs, start/stop, add or subtract volume.

05

- 16.Blood Pressure
Press the function/back button, enter the function page find blood pressure, click and measure.
- 17.Blood Oxygen
Press the function/back button, enter the function page find blood oxygen, click and measure.
- 18.Other Functions
1.Sleep 2.Stopwatch 3.Timer 4.Alarm Clock 5.Sedentary Reminder 6.Drink Water Reminder 7.Remote Camera (Launch from App) 8.Female Menstrual Cycle (Launch from App)
- 19.Cautions
1. Why should I wear my smartwatch tightly when measuring my heart rate?
Using the principle of light reflection, the smartwatch penetrates the skin with a light source and collects the signal reflected on the sensor to calculate the heart rate. If not worn tightly, ambient light will enter the sensor and affect the measurement accuracy.
2. Not recommended to wear in a hot bath: the first factor: a hot bath will produce steam due to the high temperature of the bath water, it is easy to produce a lot of steam. Steam is a gas with a small molecule radius, so it can easily penetrate the gap on the intelligent smartwatch casing. When the temperature drops, the water will gradually condense into water droplets, which will cause damage to the circuit board and further damage the smartwatch.

06

3. When connecting Bluetooth. Make sure the Bluetooth of your phone and the smartwatch are turned on. When doing a Bluetooth search, please make sure the smartwatch is not connected to another account number; when doing a Bluetooth search, please keep the smartwatch and the phone as close as possible.
4. If the user's phone has installed other software, such as Mobile Manager, in order to ensure the normal operation of the background APP, please turn on the phone's message push and allow background operation, otherwise it can not push messages.
5. To ensure the accuracy of the test data, after entering the blood oxygen test mode, stay relaxed and still during the test and make sure the smartwatch and your heart are at the same height. Please do not talk during the test. (This function provides data reference for blood oxygen changes before and after human exercise and cannot be used for medical purposes).

07

Battery Information

Battery Material	Lithium polymer battery
Battery Model	702126
Battery Power Parameter	1.517wh
Nominal Voltage	3.7V
Rated Capacity	410mAh

Warning

This product is not a medical device. This smartwatch and its applications are not available for diagnosis, treatment or preventive therapy of diseases. Consult a medical professional before changing your exercise habits and sleep habits to avoid serious injury. The manufacturer reserves the right to modify and improve the functional descriptions of the user guide, as well as to update the content on an ongoing basis without notice. This user guide is for reference only, for smartwatch sold here, please refer to the final product.

08

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.