

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
–Reorient or relocate the receiving antenna.
–Increase the separation between the equipment and receiver.
–Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
–Consult the dealer or an experienced radio/TV technician for help.
To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user’s authority to operate this equipment. (Example– use only shielded interface cables when connecting to computer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.



INSTRUCTIONS FOR USE

Power on/ off

1. Power on: Charge or long press the button for 3 seconds to turn it on;
2. Power off: Switch to the shutdown interface or long press the button for 3 seconds to confirm shutdown.

Operating Methods

1. When the watch is on, wrist raise or pressing the button to wake up the watch and swipe to switch the interface;
2. If no use, the screen will be off in 5 seconds by default. You can modify the off time in APP or watch setting;
3. 24–hour heart rate monitoring is on by default, you can choose to turn it on or off in the General Settings of the APP.

INSTALL APP


Before using EIGIS Smart Watch KE6, please download and install the APP "GloryFitPRO".
Method 1 – Scan QR Code:
Scan the QR Code on your watch or on the User Manual here with your phone and select the correct App "GloryFitPRO" to install.

Method 2 – Download in App Store:
For Apple Users: Search "GloryFitPRO" in the App Store to install it.
For Android Users: Search "GloryFitPRO" in the Android Market, like: Google Play.
Note: Device requirements: Iphone 11.0+ and above; Android 5.0+ and above, support Wireless.




DEVICE CONNECTION

Go to APP "GloryFitPRO", click "Device" – "Add Device" – "Select Device", choose the corresponding model, and follow the prompts to connect. (Refer to the following picture for operation)




Wireless Pairing:

1. New users need to register according to the requirements within the APP, after registration is complete, enter account number and password to log in.
2. Turn on the Wireless of the phone, then open the APP to pair the watch.
After successfully pairing, APP will automatically save the Wireless address of the watch;
APP will automatically search and connect the watch when it is opened or running in the background of your phone.
Data Synchronization: Scroll down on the APP homepage to synchronize the data
(The smart watch can store offline data for 7 days, the more data you have, the longer it takes to synchronize, up to about 2 minutes.)
Synchronize Contacts: Go to the Wireless setting of your phone and open Synchronize Contacts. (Refer to the following picture for operation)



OVERVIEW OF SMART WATCH KE6

Touch Screen: Scroll down to enter status bar, scroll up to view notifications, swipe left to enter main function, swipe right to enter frequently used function menu.
Upper button: Long press to turn on/off / Startup screen / Return to home interface / Rotate slide.
Lower button: Startup screen / Customized shortcuts.



MAIN FUNCTION INTERFACE

Home Interface

Main interface: Smart watch KE6 has 5 default dials, in the

home interface, long press for two seconds, after the vibration, you can swipe to switch the dial. After pairing with the APP, the watch will synchronize the time, date and day of the week information of the phone.
Plenty of dials/ Custom dials: Open the APP, click "Device" – "Dial Settings" to enter the dial center to select or customize dials.

Call

After smart watch KE6 is successfully connected to the phone, you can make or receive calls directly from the watch, the watch will instantly synchronize the dialing number.

AI Voice

After smart watch KE6 is successfully connected to the phone, it can directly conduct intelligent voice dialog.

Notification

Scroll up the home interface, you can view the message notification. Tap to view detail message, you can choose to delete at the bottom of the message, the watch can save 8 recently pushed messages, scroll up to flip, scroll down to the end to return to the home interface.

Sports

Click to enter the exercise interface, add common sports modes (110+ sports modes). Select a specific sports mode, click to start monitoring, press the upper right button or swipe right to pause, click "■" to end.

Daily Activity Status

Switch to the Daily Activity Status screen to view the current status of steps, distance and calories. The distance and calories are calculated based on the current number of steps, height and weight set within the APP.

Heart Rate

Switch to the heart rate interface, click "Start", switch the menu to re–measure.

Blood Oxygen

Switch to the blood oxygen interface, click "Start", switch the menu to re–measure.

Pressure

Switch to the pressure interface, click "Start", switch the menu to re–measure.

Sleep

Switch to the sleep interface to view sleep information.

Weather

Switch to the weather interface to view the weather and temperature.

Music

After smart watch KE6 is successfully connected to the phone, turn on the music control and press the play button to play the music, support pause and switch songs.

Alarm Clock

Enter the alarm clock interface, you can add or delete alarm clocks, and you can set up to 5 groups of alarm clocks.

Breathing Training

Enter the breathing training interface, set the time of breathing training (default training 1 minute). Click "Start", follow the animation and vibration for breathing rhythm training.

Physiological Cycle

This function will be enabled only when female users are logged in. Click "Physiological Cycle" in the APP – turn on the reminder, set up your personal physiological cycle status, and then you can view it on the watch.

Find Your Phone

Switch to the find your phone interface, under the connection status, tap "find your phone", the phone will ring to remind you.

Remote Camera

Open the APP, select "More Settings" – "Remote Photo" – shake the watch to take photos.

Stopwatch

Switch to the stopwatch interface, click to start the timer, and when the timer is stopped, swipe right to exit back to the previous interface.

Timer

Switch to the timer interface, you can select the time that has been set or add a custom time.

Calculator

Click to enter the calculator function and swipe right to exit.

Flashlight

Click into the flashlight interface to open the flashlight. Click the screen to close the flashlight. Swipe right to exit.

One-touch Monitoring

Switch to one–touch monitoring mode and click "Start" to monitor heart rate/ oxygen/ pressure at the same time.

Exercise Log

Switch to the exercise log interface to view the recent exercise log.

Setting

1. Screen Settings.2. Sound and Vibration.3. Do Not Disturb Mode.4. Theater Mode.5. Lower Button Setting.6. Power Saving Mode.7. Time and Date.8. Password.9. Motion Recognition.10. System Menu.11. QR Code.12. About

PRECAUTIONS

- Do not disassemble, repair or modify the watch by yourself.
- Do not expose to chemicals such as gasoline, cleaning solvents, alcohol or insect repellents.
- Do not use in high–pressure, high–magnetic environments.
- Do not wear the watch in a hot bath, saunas, etc.
- Do not turn on more pushes without special needs.
- It is strictly prohibited to use over–voltage load power supply for charging. (Smart watch KE6 supports 5V 500MA charging.)
- It is prohibited to throw it into the fire to avoid an explosion.
- Please avoid severe impact, extreme heat and sun exposure to the watch.
- Please dry it with a soft cloth before charging when the watch gets wet, otherwise the charging PIN will corrode and lead to charging failure.
- It may be uncomfortable if you have sensitive skin or wear the watch too tightly.
- Please dry the sweat on your wrist in time, the watch band may cause skin allergy and itching if it contacts with soap, sweat, allergens or polluting ingredients for a long time.
- Weekly cleaning of the watch is recommended. Wipe with damp cloth and use mild soap to clean up of oil or dirt.

FAQ

- What should I do if Wireless connection fails ? (Failed to connect/reconnect or very slow to connect/reconnect)
Note: Confirm that your device is iOS 11.0+ or Android 5.0+ or above and supports Wireless.
1. Due to the problem of signal interference in wireless connection, it may take too long to connect each time. If you can not connect for a long time, please make sure that the operation is carried out in an environment without magnetic fields or interference from multiple Wireless devices.
2. Turn Wireless off and turn it on again.
3. Close the APP or restart your phone.
4. Your phone should not be connected to other Wireless

devices or features at the same time.

5. Make sure the app is running properly in the background, if not the connection may fail.

Can't search for the watch ?

1. Please make sure the watch is in a charged and activated state and not connected to another phone; then put the watch close to your phone.
- If it still doesn't work, turn off the Wireless on your phone, and then restart the Wireless after 20 seconds.
2. Make sure your phone has GPS turned on.

Why should I wear my watch tightly when measuring my heart rate ?
Smart watch KE6 uses the principle of light reflection to calculate your heart rate by capturing the signal reflected back to the sensor after the light source penetrates your skin. If you don't wear it tightly, ambient light will enter the sensor and affect the measurement accuracy.
Why don't I get message notifications when I have notifications turned on ?
For Android phones:
First, make sure your phone and watch are connected, then turn on the corresponding permissions in the phone settings, allow "GloryFitPRO" to access incoming calls, SMS, contacts, and keep "GloryFitPRO" running in the background.
If your phone is installed with security software, please add "GloryFitPRO" as trusted.

For iPhone: If there is no reminder after connecting, it is recommended to restart the phone to reconnect.
When connecting the watch again, you must wait for the phone to pop up the [Wireless Pairing Request] – [Pairing].
Is the smart watch waterproof ?
Support IP68 waterproof and dust–proof rating
) Can be worn while washing hands, in the rain, or washing the car.)
Does the Wireless connection need to be on all the time ? Is there still data when disconnected ?
Data is retained on the watch before it is synchronized (7 days of data can be retained).
When the Wireless connection between the phone and the watch is successful, the data of the watch will be uploaded to the phone automatically, please synchronize the data to the phone in time.
Note: If you turn on the call and notification function, you must keep the Wireless in the connection state, and the alarm clock reminder supports offline.