

Electronic Badge F1

Product Introduction:

APP download and connection:

1. Scan the QR code to download and install the "HryFine" APP



2. APP connection method:

- (1) After the watch is turned on, open Settings -- General -- About This Machine, and check the wireless address.
- (2) Turn on the wireless of the mobile phone, enter the APP and click to add a device, scan the corresponding device and click it directly to connect.

3. Audio connection mode:

Open Settings--General-- wireless (turn on switch), enter the wireless system of the mobile phone, and search for the wireless name corresponding to the bracelet for binding (after successful connection, the wireless icon is colored).

Note: When the watch is connected to the APP, the watch data will be synchronized with the mobile phone through wireless, such as: information, contacts, step counting, etc. Once disconnected or unbound, data will not be synced.

Watch Operating Instructions:

Function introduction

Dialing: Connect to the mobile phone wireless to dial out, you can make calls on the watch;

Contact: After the watch is successfully connected to the APP, you can add contacts in the APP, after the contacts are successfully added, the watch phone book will be displayed synchronously, and the watch can make a call by clicking on the contact in the phone book;

Call log: The call record can be displayed on the watch, and the phone number can be dialed by clicking on it;

Message: Display the mobile phone information push content, support SMS of information;

wireless photography: open the camera in the APP, and take photos with the watch operation;

wireless music: You can control the music in the mobile phone, "+" "-" to adjust the volume;

Settings: wireless switch, notification setting, raise hand to turn on the screen, vibrate, button setting, backlight display, time setting, sound and haptic, APP view, language setting, cover hand off screen, Do Not Disturb mode, screen off clock, power off, restart, factory reset, About this unit;

Find the mobile phone: the mobile phone is not silent, the operating device, the mobile phone will ring;

Weather: Connect to the APP to display the current weather temperature;

Drink water reminder: the device and APP set the water drink reminder, the device vibrates the reminder;

Stopwatch: Support stopwatch timing and segmentation;

Calculator: easy to calculate;

Calendar: You can view the calendar on the device;

Alarm: You can set up the alarm clock, and press and hold to delete the alarm;

Style: Switch between multiple UI styles

Screen-off clock: When turned on, the time hand will be displayed when the screen is off;

Breathe: Breathe in slowly as the animation unfolds and exhale as the animation closes

Short video control: You can control the playback and likes of Douyin videos on your phone, and adjust the volume with "+" and "-".

Disassembly:

Take off the watch, pinch one end of the strap and push it out along the wristband card slot of the main unit, so that the strap and the main unit can be successfully removed.

Notes:

*In daily use, you should avoid wearing the watch for hot showers, saunas and diving, and when the water meter is wet, please wipe the surface water stains with a soft cloth before operating.

*The measurement results of this product are for reference only, and the data provided by the product is not used for any medical purposes and basis.

*If the power adapter is used for charging, the power adapter that meets the requirements of the corresponding safety standards should be used to avoid bursting or fire caused by the fake and shoddy power adapter.

Basic parameters:

Support system: Android 5.0 or for Android and above

Supported languages: English, Chinese Simplified, Italian, Portuguese, Polish, Spanish, French, Russian, Turkish, Hungarian, Dutch, German, Thai, Indonesian, Malay, Filipino, Persian, Hebrew, Finnish, Swedish

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.