



















英语

M806TU/乐巢SEENDA/MOU-301/说明书

SEENDA User Manual 2.4G+Bluetooth+Bluetooth Wireless Ergonomic Trackball Mouse MOU-301	CONTENTS Product Features ----- 2 2.4G USB Connection ----- 3 Bluetooth Connection ----- 4 Charging Function Guide ----- 11 How to Switch Connection Mode ----- 12 Data Parameters ----- 13 What's in Package ----- 13	Product Features  A Left Button B Forward Button C DPI Button D TYPE-C Charging Port E Bluetooth 1 Indicator F Switch Device Button G USB Receiver H Right Button I Backward Button J Scroll Wheel K Charging / DPI Indicator L Bluetooth 2 Indicator M 2.4G Indicator N Power Switch	2.4G USB Connection 	Bluetooth Connection 	Windows 10 System 	7 "BT+2.4G MS" is connected and can be used normally.  Mac OS System Please complete the Bluetooth mode installation step 123 before pairing. 	5 Click "Bluetooth" in "System Preferences".  6 Your computer will automatically find "BT+2.4G MS", then click "pair", and you can use it after installation.  iOS System Only the system above iOS 13 supports the mouse function. Please complete the Bluetooth mode installation step 123 before pairing.	4 Click Settings on your device, then turn on Accessibility.  5 Click Touch.  6 Turn on Assistive Touch. 	7 Click Settings on the device, then turn on Bluetooth.  8 Your computer will automatically find "BT+2.4G MS", then click "Pair", complete pairing.  9 "BT+2.4G MS" is connected and can be used normally. 	Android system Please complete the Bluetooth mode installation step 123 before pairing. 4 Click Settings on the device, then turn on Bluetooth.  5 Your computer will automatically find "BT+2.4G MS", then click "pair", complete pairing.  6 "BT+2.4G MS" is connected and can be used normally. 	Charging Function Guide When the power is insufficient, the charging indicator and the corresponding channel indicator flash until it is turned off. Please connect the power supply for charging in time, and use the USB cable to connect the TYPE-C charging Port. 	How to switch connection mode After BT1, BT2, and 2.4G USB mode is connected, press the mode switch button on the bottom of the mouse to switch between multiple devices. 	Data parameters Basic parameter: Movement Detection Technology: Optical Lithium Battery Capacity: 300mA DPI: 200-400-800-1200-1600 Click Life: 3 million+ Dimension: 134.4x98.2x47.2mm Weight: 136g Bluetooth transmission parameters: Transmission distance: 10m Working Voltage: 3.7V Working current: 8mA Reaction rate: 125Hz System requirement: Bluetooth-enabled device Windows 8, Windows 10 or higher version Mac OS x 10.4 or higher version Android 4.3 or higher version 2.4G transmission parameters: Transmission distance: 20m Working Voltage: 3.7V Working current: 10mA Reaction rate: 250Hz System requirement: An available USB port Windows XP, Windows 7, Windows 8, Windows 10 or higher version Mac OS x 10.4 or higher version What's in Package ▶ 1 x Wireless Mouse ▶ 1 x USB Receiver ▶ 1 x Type C Charging Cable ▶ 1 x User Manual	Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.
--	--	---	---	--	---	---	---	--	--	--	--	--	--	--