

尺寸：140\*50mm

智能眼镜

使用指南

智能AI扫码下载APP

|                                                                                                                           |                                                                                                                        |                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| <div><div></div><div>开关机</div></div> <div><br/>右触控</div> <div>开机：长按3秒开机<br/>关机：长按5秒关机</div>                               | <div><div></div><div>连接</div></div> <div><br/>右触控</div> <div>打开手机蓝牙，搜索设备名称Glasses-D12，并链接。<br/>注：开机后3秒自动回连配对过的手机</div> | <div><div></div><div>音乐</div></div> <div><br/>右触控</div> <div>音乐暂停/播放：触摸点击右侧1下<br/>音乐切换：触摸点击右侧3下，切换下一曲</div> |
| <div><div></div><div>电话</div></div> <div><br/>右触控</div> <div>来电接听/挂断：触摸点击右侧1下<br/>拒接电话：长按右侧2秒<br/>(注：通话音量大小可在手机上调节)</div> | <div><div></div><div>拍照</div></div> <div><br/>右触控</div> <div>拍照：在手机打开相机状态下，单击右侧拍照</div>                                | <div><div></div><div>唤醒语音助手</div></div> <div><br/>右触控</div> <div>唤醒语音助手：长按右侧2秒唤醒<br/>(注：单击取消语音助手)</div>     |
| <div><div></div><div>中英文语音切换</div></div> <div><br/>右触控</div> <div>中英文语音切换：触摸点击右侧4下</div>                                  | <div><div></div><div>音量</div></div> <div><br/>右触控</div> <div>音量增加：触摸点击右侧2下<br/>(注：音乐音量大小也可以在手机上调节)</div>               | <div><div></div><div>充电</div></div> <div><br/>右触控</div> <div>Type-C：充电时显示红灯，充满时显示蓝灯长亮</div>                 |

SMART GLASSES

User Manual

Smart AI Scan QR Code to Download App

|                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                               |                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div><div></div><div>Switch Machine</div></div> <div><br/>Right touch</div> <div>Switch on: Long press 3 seconds to switch on<br/>Switch off: Long press 5 seconds to switch off</div>                                                                    | <div><div></div><div>Pairing</div></div> <div><br/>Right touch</div> <div>turn on the Bluetooth of the mobile phone, and search for Device name Glasses-D12 and link to it.<br/>Note: The device is automatically reconnected to paired phones 3 seconds after booting.</div> | <div><div></div><div>Music</div></div> <div><br/>Right touch</div> <div>Music pause/play : Touch right side 1 time<br/>Music Switching : Switch to the next song: Touch on the Right side 3 times</div>                |
| <div><div></div><div>Phone</div></div> <div><br/>Right touch</div> <div>Phone Answer/Hangup: Touch right side 1 time<br/>Rejection of calls: long press on right side for 2 seconds<br/>(Note: The volume of the call can be adjusted on the phone)</div> | <div><div></div><div>Take a photo</div></div> <div><br/>Right touch</div> <div>Take a photo: Tap right side to take a photo when the camera is turned on in the mobile phone.</div>                                                                                           | <div><div></div><div>Voice assistance</div></div> <div><br/>Right touch</div> <div>Wake up Voice assistant : long press right side for 2 seconds to wake up<br/>(Note: Touch once to cancel the voice assistant)</div> |
| <div><div></div><div>Chinese and English switching</div></div> <div><br/>Right touch</div> <div>English and Chinese voice switching: Touch right side 4 times.</div>                                                                                      | <div><div></div><div>Volume</div></div> <div><br/>Right touch</div> <div>sound increases: Touch on the Right touch 2 times<br/>(Note: Music volume can also be adjusted on mobile phones)</div>                                                                               | <div><div></div><div>Charge</div></div> <div><br/>Right touch</div> <div>Type-C: Red light during charging<br/>blue light stays on when full.</div>                                                                    |

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.