

尺寸：140\*50mm

# 智能AI眼镜

## 使用指南



Android 8.0及以上手机

iOS13.0及以上手机

支持蓝牙BT 5.0

智能AI眼镜扫码下载APP


安卓:通过软件应用商店搜索“小智眼镜”下载安装应用

苹果:通过App store搜索“小智眼镜”下载安装应用





### 开关机



触控

前键


后键

开机: 长按前键2秒开机

关机: 长按前键2秒关机



### 连接



触控

前键


后键

进入配对状态:

开启眼镜, 即可进入配对状态



### 拍照录像录音



触控

前键

后键


拍照: 单击前键

开始/停止 录像: 长按后键/录像中单击后键

开启/结束 录音: 三击前键/录音中单击前键



### AI对话/语音交互



触控

前键

后键


打开/关闭AI对话: 单击后键

打断AI回复: 单击触摸区域

唤醒语音助手: 长按触摸区域5秒



### 播放音乐



触控

前键

后键


暂停/播放: 单击触摸区域

上一首: 三击触摸区域

下一首: 双击触摸区域



### 来电电话



触控

前键


后键

接听/接听后挂断: 单击触摸区域

拒接: 双击触摸区域



### 手电筒



触控


前键

后键

打开/关闭手电筒: 三击后键



### 音量



触控

前键

后键


音量增加: 双击前键

音量减少: 双击后键

(注: 音乐音量大小也可以在手机上调节)



### 充电



Type-C: 充电时显示红灯, 充满时显示蓝灯长亮

# Smart AI Glasses

## User Manual



Android 8.0 and above mobile phones

iOS 13.0 and above mobile phones

Supports Bluetooth 5.0

Scan the QR code with your smart AI glasses to download the app


Android: Search for "XIAOZHI Glass" through the software application store to download and install the application.

Apple: Search for "XIAOZHI Glass" through the App store to download and install the app.





### Power button



Touch Area

Front Button


Back Button

Power On: Long press the front button for 2 seconds to turn on the device.

Power Off: Long press the front button for 2 seconds to turn off the device.



### Pairing



Touch Area

Front Button


Back Button

Enter Pairing Mode:

Turn on the glasses to enter pairing mode.



### Photo, Video & Audio Recording



Touch Area

Front Button

Back Button


Take a photo: Click the front button once

Start/stop video recording: Long press the back button / Click the back button once while recording

Start/stop audio recording: Triple-click the front button / Click the front button once while recording



### AI Conversation/Voice Interaction



Touch Area

Front Button

Back Button


Turn AI conversation on/off: Click the back button once

Interrupt the AI's response: Tap the touch area

Activate the voice assistant: Long press the touch area for 5 seconds



### Play Music



Touch Area

Front Button

Back Button


Pause/Play: Tap the touch area once

Previous Track: Triple-tap the touch area

Next Track: Double-tap the touch area



### Incoming Calls



Touch Area

Front Button


Back Button

Answer/Hang up after answering: Tap the touch area once

Reject: Double-tap the touch area



### Flashlight



Touch Area


Front Button

Back Button

Turn the flashlight on/off: Triple-click the back button



### Volume



Touch Area

Front Button

Back Button


To increase volume: Double-click the front button

To decrease volume: Double-click the back button

(Note: You can also adjust the music volume on your phone.)



### Charging



Type-C: A red light indicates charging; a steady blue light indicates a full charge.

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.