

BACK

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. In addition, for a Class B digital device or peripheral or cordless phone, the user manual shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

3. The below statement is applicable for when the device is so small or for such use that it is impracticable to label it with the statement specified under paragraph (a) of the 15.19 in a font that is four-point or larger, then the information required by this paragraph shall be placed in the user manual. In addition, if the 15.105 statement is in manual, this will suffice for the above (15.19(a) statement in manual) and for 2.1077 compliance statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warnings and Disclaimers:

- To recharge the device, please only use the USB cable that we have provided in the packaging;
- This product is intended for use when supplied with power from the designated battery or power supply unit. Other usage may be dangerous and will invalidate any approval given to this product;
- Please recharge the device for 3 hours before initial usage;
- Do not short the terminals. Connection to improper grounded equipment can result in short-circuit.
- Use of non-original manufacturer-approved accessories will damage the product and cause explosion;
- Recharge the product at room temperature (21°C or 69.8°F);
- Store in a cool and dry place;
- If terminals are soiled, clean with a soft cloth;
- Unplug from the socket when the device is not being recharged;
- Keep the device away from fire;
- Keep the device out of reach of infants or children;
- Do not expose the device to any mechanical shock.

Safety Precautions:

- Device will get warm after prolonged use**
- The product will get warm after being used for a period of time;
- It is highly recommended to turn the product off and let it cool down before using it again;
- The product should be placed away from heat sources such as radiators, registers, stoves, or other products (including amplifiers) that produce heat.

Main Compositions: Silicone, ABS Plastic, Polyester, Metal

Caution: This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of skin lacerations. Prolonged and frequent use are not advised or recommended as this product is sold as novelty purpose only. This product should be used with discretion. No medical claims are warranted or implied by the use of this product. Do not use when bathing or in the shower. The device cannot be used while it is being charged.



Raccolta differenziata dei rifiuti.
Controlla le linee guida del tuo comune.



IQ00308E-000

FRONT

How to Operate the Vibrating Dildo:





- Press and hold to turn ON the device.
- Press again to cycle through the 10 different rhythms.
- Press and hold to turn OFF the device.

Technical Data:


Operating temperature : 10°C - 35°C
Charging voltage : 5V
Battery : Li-Ion 3.7V, 1.85Wh
Battery capacity : 500mAh
Fully charged : Approx. 2 hours
Charging cycles : Approx. 300 times
Usage period : Approx. 45 minutes
Interface : USB port (5V, >1A)

Charging Instructions:


*Ensure that both charging points connect to each other perpendicularly.
*Plugging the USB cable incorrectly will cause damage to the device.



WARNING:



How to Operate the Controller:





- * Turn ON the vibrating dildo before operating the controller.
- Press and hold to turn ON the device.
- Press again to cycle through the 10 different rhythms.
- Press and hold to turn OFF the device.

Technical Data:


Operating temperature : 10°C - 35°C
Charging voltage : 5V
Battery : Li-Ion 3.7V, 0.22Wh
Battery capacity : 60mAh
Fully charged : Approx. 30 minutes
Charging cycles : Approx. 300 times
Usage period : Approx. 10 hours
Interface : USB port (5V, >1A)

Charging Instructions:

*Ensure that both charging points connect to each other perpendicularly.
*Plugging the USB cable incorrectly will cause damage to the device.



WARNING:



INNER

Size: 150mm(W) x 100mm(H)