

User manual

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Warning: This product includes lithium polymer battery.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Please remove the Smart watch in case of any leakage or excessive heat from the product to avoid burns or rash.
7. Only charge with the supplied USB cable.

8. Using other accessories than the ones delivered with the product can cause abnormal functionality.
9. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
10. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.

Download App

Scan the following QR code, download and install the App.



Scan QR Code and Download

Pairing

Open the app and set up your profile.

Go to [Device], click [Add a new device]. Choose your device on the scanning list.

You can see the model name “JX943” on the app after pairing.

Activate & Charge Device

Make sure power is working normally before initial use. In case the device battery is low, connect the device to the charger. The device will automatically boot up (please connect the magnet USB in normal DC port (5V/500mA) for charging as below.

Smart Watch Features

Main dials

There are 5 main dials for your option. Long press the touch

panel to choose.



Always on Mode



Screen Clock



Analog Clock



Digital Clock

Click on AOD in the settings menu, select the time display mode you want, and the watch will display the time continuously after entering standby mode.

Physical Exercise



Exercise

Press and hold the physical exercise page to start a new training measure recording. 20 sports modes are available. The last training data is displayed on the training page.

Heart Rate Monitor



Heart Rate

Touch the heart rate page to start measuring your heart rate.

Blood Pressure Monitor



Touch the blood pressure page to start measuring your blood pressure.

SpO2/Blood Oxygen Monitor



Touch the SpO2 page to start measuring your SpO2/blood oxygen.

Activity



The smart watch automatically measures steps, calories and distance. The measured data is synchronized to the app.

Note: The sports data stored on the watch is cleared at midnight every day.

Sleep Monitor



Please note that after you connect the **JX943** with the app, by wearing the smart band during sleep, it will measure your sleep time and quality. The measured data is synchronized to the app and you can check it on the app.

Stopwatch



Touch the stopwatch page to start timing, and press it again to stop timing.

Weather Forecast



The weather page displays the weather information of the current and next day. The latest weather information from the App can be synchronized to the watch if the watch is connected to the App.

Message Reminder



The watch can synchronize incoming notifications from Twitter, Facebook, Whats App, Instagram etc.

The latest **8** messages can be stored on the watch.

Note: You can switch on or off the incoming notification in the app.

Set



Set up page includes Display, Vibrate & Ring, DND, Low power mode, AOD, Phone call, System, the device and About.

More Information about Smart watch use in Wet Conditions

The smart watch is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout.

Note: Do not swim with the smart watch. It is not recommended to shower with the Smart watch, though it does not hurt the band. Remove the watch periodically to allow your skin to dry and breathe. Whenever you get your

bracelet wet, dry it thoroughly before putting it back on.

Using the function button and the touch screen

Press and hold the function button for 3 seconds to turn on the device, press the function button to wake up the device.

Quick View

When the screen is turned off, just turn your wrist towards you and the screen will automatically light up. The watch screen automatically turns off after being idle for a few seconds.

Tap the main dial and slide left, you can find state, heart rate, sleep and physical exercise function quickly.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

Warning!

-Lithium battery inside!

-Do not open the product!

-Do not expose to heat, water, moisture or direct

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.