

HYUNDAI HY-C8

真无线蓝牙耳机

使用说明书

使用前请阅读使用说明书

产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或卸载产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

眼镜X1

充电线X1

使用说明书X1

产品示意说明

功能触摸区

DC磁吸充电

蓝牙耳机

产品规格

蓝牙版本:V5.4

传输距离:10M

电池容量:55mAh

使用时长:约9小时

充电时间:约1小时

额定输入:5V—55mA

LED指示灯状态

眼镜指示灯

- 眼镜充电(未充满):红灯长亮
- 充满电灯灭
- 低电量显示:红灯闪烁
- 开机:红灯闪烁
- 关机:红灯长亮1s熄灭
- 配对中:红灯灯闪烁
- 配对成功:灯灭

产品操作说明

1.开机

方式一:分别长按两个镜腿的多功能键3秒开机。

2.关机

方式一:长按任何一个镜腿的多功能键6秒,两个镜腿应同时会关机。

3.配对

步骤一:左右镜腿开机后会自动进行配对。

步骤二:打开智能设备的蓝牙列表,搜索"HY-C8"并连接。

触控按键的操作

眼镜操作

上一曲:短按左或右多功能键1次

下一曲:短按左或右多功能键1次

音量+:长按左耳功能键

音量-:长按右耳功能键

暂停/播放:短按左或右多功能键2次

电话免提

眼镜操作(来电状态下)

接听:短按左或右多功能键2次

拒接:长按左或右多功能键2秒

挂断:短按左或右多功能键2次

语音助手

眼镜操作

待机状态下,三击多功能键进入唤醒语音助手,三击左多功能键关闭语音助手

拍照功能

眼镜操作

打开相机,右键3下拍照

恢复出厂设置

激活机后未与手机配对状态下,连续单击耳机功能键5次清除配对信息后关机。

产品中有有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均GB/T26572规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。
表中标记"×"的部件,皆因全球技术发展水平限制而无法实现有害物质的替代。
印刷电路板组件*:包括印刷电路板及其零部件,电子元器件等,根据产品型号不同,您所购买的产品可能不会含有以上所有部件

10

在中华人民共和国境内销售的电子电气产品必须标识此标志,标志内的数字代表在正常的使用状态下的产品的环保使用期限。

保修卡

尊敬的用户,本保修卡是您将来申请保修的凭证,请您配合销售商填写并妥善保管备用!

用户信息

用户姓名

电子邮箱

联系电话

邮政编码

通讯地址

产品信息

产品名称

产品型号

产品条码/编号/批号

销售商信息

名称

地址

联系电话

邮政编码

销售日期

发票号码

备注

现代综合商事控股株式会社 授权
被授权方:深圳市现代数码电子有限公司
地址:深圳市宝安区西乡街道宝田路50号信田研发大楼601A
制造商:现代创新(深圳)科技发展有限公司
地址:深圳市龙岗区民治街道上芬社区龙建设路交汇处融创智汇大厦A座1509

HYUNDAI合格证

产品编号: 生产时间: 检查日期:

FCC声明

根据FCC规则第15部分,本设备经过测试,符合B类数字设备的限制,这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量。如果未按照规定安装和使用该指示可能会对无线电通信造成有害干扰。然而,有不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或电视接收造成有害干扰,可通过转动来确定设备,关闭和打开时,鼓励用户尝试通过一个或多个以下更多措施

—重新定向或重新定位接收天线。

—增加设备和接收器之间的间距。

—设备连接到与接收器不同的电路上的插座已连接。

—请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分。操作受以下两个条件限制条件
(1)本装置不得引起有害干扰。
(2)本装置必须接受任何接收到的干扰,包括可能导致意外操作的干扰。
未经合规责任方明确批准的变更或修改可能使用户对设备的操作权限失效。

HYUNDAI HY-C8

True wireless Bluetooth glasses

Manual

Please read all instructions carefully and retain for future use

Usage Instruction

(1)Don't attempt to disassemble the unit and change any part,except there is operation method mentioned in the manual.

(2) Don't expose the unit to liquid, moisture or humidity, since it isn't a waterproof product.

(3) Disconnect the unit with your BT device and move it to the safearea if the liquid get inside the unit.

(4)Don't assemble or disassemble the unit to avoid electric shock,if there is water on your hands.

(5)Don't expose the unit to extremely high temperature or disposeof the unit in fire as it will result in an explosion.

(6)Don't place the unit in an electromagnetic interferenceenvironment to avoid malfunction.

Packing list

Glasses X1

Charging line x1

User manualx1

Product schematic description

Functional touch area

DC magnetic charging

Bluetooth glasses

Product specification

Bluetooth version:V5.4

Transmission distance:10M

Battery capacity:55mAh

Usage time: approximately9 hours (headphones)

Charging time: approximately1 hour (forheadphones)

Rated input5V—55mA

LED indicator light status

Glasses indicator light

- Glasses charging (not fully charged): The red light stays on for a long time
- Fully charged: light off
- Low battery display: Red light flashing
- Power on: Red and blue lights flashing
- Shutdown: The red light stays on for 1 second before turning off
- Pairing in progress: Red and blue lights flashing
- Pairing successful: light off

Product operating instructions

1.Power on

Method 1: Long press and hold the multifunction keys on both mirror legs for 3 seconds to turn on the camera.

2. Power off

Method 1: Long press the multifunction button on either leg of the mirror for 6 seconds, and both legs should shut down simultaneously.

3.Pairing to the BT device

Step 1:After turning on the left and right mirror legs, they will automatically pair.

Step 2: Open the Bluetooth list of the smart device, search for "HY-C8" and connect.

Operation of touch buttons

Glasses operation

Previous song: Short press the left or right multifunction key once

Next song: Short press the left or right multifunction key once

Volume+: Long press the left ear function key

Volume-: Long press the right ear function key

Pause/Play: Short press the left or right multifunction key twice

Phone Hands Free

Glasses operation (under incoming call status)

Answer: Short press the left or right multifunction key twice

Reject: Long press the left or right multifunction key for 2 seconds

Hanging up: Short press the left or right multifunction key twice

Voice Assistant

Glasses operation

In standby mode, press the multifunction key three times to activate the voice assistant, and press the left multifunction key three times to deactivate the voice assistant

Camera function

Glasses operation

Open the camera, right-click 3 times to take a photo

Restore factory settings

After turning on the phone without pairing state, click the headsetfunction key 5 times to clear the pairing information and then turnoff the phone.

Name and content of hazardous substances in products

Name and content of hazardous substances in products

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuitboards	○	○	○	○	○	○
Small structureparts (each added)	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "×" on the form are all harmful due to the limitations of global technological development.Substitution of substances.
Printed circuit board components*: including printed circuit boards and their parts, electronic components, etc.,Depending on the product model, the product you purchased may not contain all the above components

10

Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use Environmental protection use period.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name

Email

Contact number

Postal code

Mailing address

Product information

Product name

Product number

Product barcode/Serial number /Batch number

Vendor information

Name

Address

Contact number

Postal code

Sales date

Invoice number

Remark

Authorized by: Modern Integrated Commercial Holdings Co., Ltd
Authorized party: Shenzhen Modern Digital Electronics Co., Ltd
Address: 601A, Chentian R&D Building, No. 50 Baosian Road, Xixiang Street, Bao'an District, Shenzhen
Manufacturer: Modern Innovation (Shenzhen) Technology Development Co., Ltd
Address: 1909, Block A, Rongshuang Zhihui Building, Intersection of Longheng Road and Jinglong Jianshe Road, Shangfeng Community, Minzhi Street, Longhua District, Shenzhen

HYUNDAI

Certificate of Approval

Product No.: 生产时间: 检查日期:

FCCStatement

According to Part 15 of the FCC Rules, this device has been tested to meet the restrictions for Class B digital devices. These restraining decrees In providing reasonable protection against harmful disturbances in residential facilities. The device generates and uses radiofrequency energy,If this instruction is not installed and used in accordance with the regulations, it may cause harmful interference to radio communications. However, there are There is no guarantee that interference will not occur in a particular installation. If this device has built for radio or television reception into harmful interference, the device can be determined by turning it off and on when the user is encouraged to try to pass through one or Several more measures below

—Redirect or reposition the receiving antenna.

—Increase the distance between device and receiver.

—Sockets connected to devices on circuits different from the receiver are connected.

—Please consult a dealer or experienced radio/TV technician for assistance.

This device complies with Part 15 of the FCC Rules. The operation is restricted by the following two conditions
(1) The device shall not cause harmful interference.
(2) The device must accept any received interference, including interference that may cause unexpected operation.
Changes or modifications that are not explicitly approved by the compliance responsible party may invalidate the user's permission to operate the device.
This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

文件名称	现代-HY-C8说明书			材料	70g书写纸		单位	mm	厂商物料编号		变更履历		修改		日期	
文件尺寸	54x80mm (单P尺寸)			工艺	1C印刷 风琴折		公差	± 0.5mm					审核		日期	
设计日期	2024/07/13	文件版本	V02				比例	1:1					批准		日期	