

中文



- 1.用一只手按住耳朵,像戴耳环一样挂在耳朵上。
- 2.首先挂在耳朵上方,上下移动调整到最佳听声音的位置。

注意防止音量过高的情

为了减少听力损失和避免造成听力损伤,长时间使用无线听力设备可能会导致,可能导致听力受损或耳鸣影响,为更好地保护听力,请注意防止音量过高的情况,应根据连接听力设备的时间,适当适时地暂停使用,适时可能会出现耳鸣现象,请随时注意听力设备音量,提高音量可能会导致听力损伤。

如在使用本产品时出现皮肤过痒等状况,请尽快停止使用并向医生、或联系服务中心或购买时的旗舰店进行咨询。

1. 请不要将耳机本体置于后壳内以免产生摩擦,出现变形或其他故障。
2. 请不要在飞机舱内使用耳机,无线设备也会影响其他乘客造成干扰造成故障。
3. 请不要在医疗场所使用耳机,无线设备也会影响其他医疗设备引起故障造成故障。
4. 请不要在驾驶的车辆内等敏感的场所或医疗机构的室内使用耳机。请不要在自动门、火灾报警器等可能引起设备损坏近使用,无线设备会影响其正常操作造成事故。

触摸面板在左右各自的前侧。通过触摸控制面板可以进行基本的操作。

注意不是按键操作，需要轻轻触摸控制面板

配对	耳机开始会自动进行配对, 左右配成一对, 可在安卓/IOS手机蓝牙界面看到名称为7900
电源/蓝牙OFF	完全关闭会禁用耳机功能, 耳机组合会返回默认名称(PowerOn/PowerOff)
音乐/电话/通话/播放/接收/充电/充电	单击任意一侧耳机触摸面板
上一首/上一曲	双击左耳机触摸面板
下一首/下一曲	双击右耳机触摸面板
音量加	三击左耳机触摸面板
音量减	三击右耳机触摸面板
白噪音/白噪音	长按任意耳机触摸面板25毫秒5s
触控方式/充电	四击任意耳机触摸面板

请注意以下事项以确保安全充电：触电、短路、起火等引起火灾或人身伤害。请勿使用非原厂指定型号充电器充电，如充电器发生过热、冒烟、发出异常声响等情况，请不要再继续充电，并马上用湿布覆盖充电处并及时就医处理；如充电器不能牢固地连接到设备表面，为避免可能出现设备灼伤情况，请马上用清水清洗皮肤，如造成其他伤害请及时就医处理及及时度理设备。

请使用原装的USB Type-C配件进行充电，使用电脑、过流等情况可能引发火灾或人身伤害，造成国家财产及损失，切勿自行拆卸或改装，以免发生故障或安全问题。如在进行充电时发生危险，例如烫伤、触电等情况，请及时关闭电源后联系售后或购买方所在地售后服务站。请不要将手机暴露在高温处或发热设备周围，如长时间直射，直射的阳光上，或处于高温下的汽车内或靠近暖气等场所，保持良好通风。

英文



1. Use one hand to hold the ear and hang it on it like wearing an earring.
2. First, hang it above the ear and move it up and down to adjust to the best listening sound. The position of the sound

s and hearing, please p
vices connected to th

Please follow the following precautions to avoid injury and property damage. Long term use of high volume can stimulate the ears and may lead to cognitive effects such as reduced hearing.

- 1. Please do not use the device for extended periods of time to prevent sustaining injuries. The volume is too high. According to the different Bluetooth devices connected to this device, there may be a phenomenon of speaking during calls. Please keep an appropriate volume at all times. Please gradually increase the volume as sudden increases may damage the ears.
- 2. Please do not use the device for extended periods of time to prevent sustaining injuries. As soon as possible, and if necessary, or contact a repair center or the seller at the time of purchase for further consultation.

Please do not place the earphone body in the back pocket to avoid compression, deformation, or other malfunctions when carrying.

- 3. Please do not use this aircraft within its functions, as radio waves and other factors may cause accidental operation and accident.
- 4. Please do not use this device near medical devices, as radio waves and other influences may cause malfunctions in pacemakers.
- 5. Please do not use this device in crowded vehicles or other miscellaneous places, or in the interior of medical institutions.
- 6. Please do not operate near automatic doors, elevators, escalators, etc.

The use of radio waves and other factors may cause accidental operations and accidents.

The touch panels are located on the front sides of each side.
By touching the control panel, it is possible to
Basic operations.
Note that it is not a button operation and requires gentle touch of the control panel.

pair	When the headphones are turned on, they will pair left and right on their own. After the pairing is complete, 19056 can be found on the Bluetooth interface of the Android/iD phone
Power ON/OFF	The headphones automatically turn on when the charging compartment is opened, and the headphones automatically turn off when the compartment is closed (Power On/Power Off)
Music Play/Stop Call answering/hanging up	Click on a left and right touch panel
Previous song	Double click on the left ear touch panel
Next piece of music	Double click on the right ear touch panel
Volume increase	Three click left ear touch panel
Volume reduction	Three click right ear touch panel
Summing/active Assistant	Long press the right ear touch panel for 25
Noise reduction mode switching	Four Click Any Earphone Touch Panel

Please pay attention to the following precautions to avoid death or serious injury caused by fire, electric shock, heat, fire, etc. Do not directly touch the charging battery with your hands to prevent liquid leakage. If the leaked liquid accidentally enters your eyes, immediately wash your eyes with clean water for 15 minutes and seek medical treatment promptly. If the leaked liquid accidentally touches the body or clothing, to avoid possible burns or other injuries, please use immediately Wash with water or other ingredients. If there is inflammation or other damage to the skin, please seek medical treatment promptly. Please use the attached USB type-C accessory for charging. Damage, battery leakage, overheating, and other accidents may occur if you use other accessories. Please do not use this machine on your own to avoid malfunctions or electric shock. If you need to replace the rechargeable battery, inspect or repair it, please contact the seller in a timely manner. Post service center or specialized store at the time of purchase. Please do not expose this machine to rain, snow, or other weather conditions. Do not use this machine in the vicinity of fire, sunlight, or high temperature. Please use, store, and place in high-temperature areas such as the interior of the car.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.