

HYUNDAI HY-C8

真无线蓝牙耳机



产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

	眼镜X1		充电线X1
	使用说明书X1		

产品示意图

功能触控区

DC磁吸充电

产品规格

蓝牙版本:V5.4
传输距离:10M
电池容量:55mAh
使用时长:约9小时
充电时间:约1小时
额定输入:5V—55mA

LED指示灯状态

眼镜指示灯	- 眼镜充电(未充满):红灯长亮 - 充满电/熄灭 - 低电量显示:红灯闪烁 - 开机:红蓝灯闪烁 - 关机:红灯长亮1s熄灭 - 配对中:红蓝灯闪烁 - 配对成功:灯灭
-------	---

产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

	眼镜X1		充电线X1
	使用说明书X1		

产品示意图

功能触控区

DC磁吸充电

产品规格

蓝牙版本:V5.4
传输距离:10M
电池容量:55mAh
使用时长:约9小时
充电时间:约1小时
额定输入:5V—55mA

LED指示灯状态

眼镜指示灯	- 眼镜充电(未充满):红灯长亮 - 充满电/熄灭 - 低电量显示:红灯闪烁 - 开机:红蓝灯闪烁 - 关机:红灯长亮1s熄灭 - 配对中:红蓝灯闪烁 - 配对成功:灯灭
-------	---

触控按键的操作

■ 眼镜操作

1.开机
方式——分别长按两个镜腿的多功能键3秒钟。

2.关机
方式——长按任何一个镜腿的多功能键6秒,两个镜腿应同时会关机。

3.配对
步骤——左右镜腿开机后会自动进行配对。
步骤二:打开智能设备的蓝牙列表,搜索“HY-C8”并连接。



■ 触控按键的操作

上一曲:短按左或右多功能键1次
下一曲:短按左或右多功能键1次
音量+:长按左耳功能键
音量-:长按右耳功能键
暂停/播放:短按左或右多功能键2次

电话免提

■ 眼镜操作(来电状态下)

接听:短按左或右多功能键2次
拒接:长按左或右多功能键2秒
挂断:短按左或右多功能键2次

语音助手

■ 眼镜操作

待机状态下,三击多功能键进入唤醒语音助手,三击左多功能键关闭语音助手

拍照功能

■ 眼镜操作

打开相机,右键3下拍照

恢复出厂设置

撬开机后未与手机配对状态下,连续单击耳功能键5次清除配对信息后关机。

产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

	眼镜X1		充电线X1
	使用说明书X1		

产品示意图

功能触控区

DC磁吸充电

HYUNDAI HY-C8

真无线蓝牙耳机



产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

	眼镜X1		充电线X1
	使用说明书X1		

产品示意图

功能触控区

DC磁吸充电

产品规格

蓝牙版本:V5.4
传输距离:10M
电池容量:55mAh
使用时长:约9小时
充电时间:约1小时
额定输入:5V—55mA

LED指示灯状态

眼镜指示灯	- 眼镜充电(未充满):红灯长亮 - 充满电/熄灭 - 低电量显示:红灯闪烁 - 开机:红蓝灯闪烁 - 关机:红灯长亮1s熄灭 - 配对中:红蓝灯闪烁 - 配对成功:灯灭
-------	---

触控按键的操作

■ 眼镜操作

1.开机
方式——分别长按两个镜腿的多功能键3秒钟。

2.关机
方式——长按任何一个镜腿的多功能键6秒,两个镜腿应同时会关机。

3.配对
步骤——左右镜腿开机后会自动进行配对。
步骤二:打开智能设备的蓝牙列表,搜索“HY-C8”并连接。



■ 触控按键的操作

上一曲:短按左或右多功能键1次
下一曲:短按左或右多功能键1次
音量+:长按左耳功能键
音量-:长按右耳功能键
暂停/播放:短按左或右多功能键2次

电话免提

■ 眼镜操作(来电状态下)

接听:短按左或右多功能键2次
拒接:长按左或右多功能键2秒
挂断:短按左或右多功能键2次

语音助手

■ 眼镜操作

待机状态下,三击多功能键进入唤醒语音助手,三击左多功能键关闭语音助手

拍照功能

■ 眼镜操作

打开相机,右键3下拍照

恢复出厂设置

撬开机后未与手机配对状态下,连续单击耳功能键5次清除配对信息后关机。

HYUNDAI HY-C8

真无线蓝牙耳机



产品使用简介

(1) 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。

(2) 请勿将产品放入水或其他任何液体中,此产品非防水设计。

(3) 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品。

(4) 为避免触电,请在安装或拆卸产品时,确保手上没有沾水。

(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。

(6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

包装清单

	眼镜X1		充电线X1
	使用说明书X1		

产品示意图

功能触控区

DC磁吸充电

产品规格

蓝牙版本:V5.4
传输距离:10M
电池容量:55mAh
使用时长:约9小时
充电时间:约1小时
额定输入:5V—55mA

LED指示灯状态

HYUNDAI HY-C8

True wireless Bluetooth glasses



Usage Instruction

(1) Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.

(2) Don't expose the unit to liquid, moisture or humidity, since it isn't a waterproof product.

(3) Disconnect the unit with your BT device and move it to the safe area if the liquid gets inside the unit.

(4) Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.

(5) Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.

(6) Don't place the unit in an electromagnetic interference environment to avoid malfunction.

Packing list

	Glasses X1		Charging line X1
	User manual X1		

Product schematic description





Bluetooth glasses

Product specification

Bluetooth version: V5.4
Transmission distance: 10M
Battery capacity: 55mAh
Usage time: approximately 9 hours (headphones)
Charging time: approximately 1 hour (for headphones)
Rated input: V=55mA

LED indicator light status

Glasses indicator light	• Glasses charging (not fully charged): The red light stays on for a long time • Fully charged: light off • Low battery display: Red light flashing • Power on: Red and blue lights flashing • Shutdown: The red light stays on for 1 second before turning off • Pairing in progress: Red and blue lights flashing • Pairing successful: light off
--------------------------------	---


Product operating instructions

1. Power on
Method 1: Long press and hold the multifunction keys on both mirror legs for 3 seconds to turn on the camera.

2. Power off
Method 1: Long press the multifunction button on either leg of the mirror for 6 seconds, and both legs should shut down simultaneously.

3. Pairing to the BT device
Step 1: After turning on the left and right mirror legs, they will automatically pair.

Step 2: Open the Bluetooth list of the smart device, search for "HY-C8" and connect.



Operation of touch buttons

■ Glasses operation



Previous song: Short press the left or right multifunction key once

Next song: Short press the left or right multifunction key once

Volume+: Long press the left ear function key

Volume-: Long press the right ear function key

Pause/Play: Short press the left or right multifunction key twice

Phone Hands Free

■ Glasses operation (under incoming call status)



Answer: Short press the left or right multifunction key twice

Reject: Long press the left or right multifunction key for 2 seconds

Hanging up: Short press the left or right multifunction key twice

Voice Assistant

■ Glasses operation



In standby mode, press the multifunction key three times to activate the voice assistant, and press the left multifunction key three times to deactivate the voice assistant

Camera function

■ Glasses operation



Open the camera, right-click 3 times to take a photo

Restore factory settings

After turning on the phone without pairing state, click the headset function key 5 times to clear the pairing information and then turn off the phone.

Name and content of hazardous substances in products

Name and content of hazardous substances in products

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structure parts (such as shell)	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.

○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.

×: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds The limit requirements specified in GB/T 26572.

The parts marked with "×" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components*: including printed circuit boards and their parts, electronic components, etc., depending on the product model, the product you purchased may not contain all the above components



Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use

Environmental protection use period.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info		
User name	Email	
Contact number	Postal code	
Mailing address		
Product information		
Product name	Product number	
Product barcode/Serial number/Batch number		
Vendor information		
Name		
Address		
Contact number	Postal code	
Sales date	Invoice number	
Remark		

Authorized by Modern Integrated Commercial Holdings Co., Ltd
Authorized party: Shenzhen Modern Digital Electronics Co., Ltd
Address: 601A, Chentian R&D Building, No. 50 Baotian Road, Xixiang Street, Bao'an District, Shenzhen
Manufacturer: Modern Innovation (Shenzhen) Technology Development Co., Ltd
Address: 1909, Block A, Rongchuang Zhuhui Building, Intersection of Longsheng Road and Jinglong Jianshe Road, Shangfeng Community, Minzhi Street, Longhua District, Shenzhen



SHENZHEN MODERN DIGITAL ELECTRONICS CO., LTD



Certificate of Approval

Product No.: _____

Production Time: _____

QC: _____



FCC Statement

According to Part 15 of the FCC Rules, this device has been tested to meet the restrictions for Class B digital devices. These restraining decrees In providing reasonable protection against harmful disturbances in residential facilities. The device generates and uses radiofrequency energy, If this instruction is not installed and used in accordance with the regulations, it may cause harmful interference to radio communications. However, there are There is no guarantee that interference will not occur in a particular installation. If this device has built for radio or television reception into harmful interference, the device can be determined by turning it off and on when the user is encouraged to try to pass through one or Several more measures below

— Redirect or reposition the receiving antenna.

— Increase the distance between device and receiver.

— Sockets connected to devices on circuits different from the receiver are connected.

— Please consult a dealer or experienced radio/TV technician for assistance.

This device complies with Part 15 of the FCC Rules. The operation is restricted by the following two conditions

(1) The device shall not cause harmful interference.

(2) The device must accept any received interference, including interference that may cause unexpected operation.

Changes or modifications that are not explicitly approved by the compliance responsible party may invalidate the user's permission to operate the device.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and

文件名称	现代-HY-C8说明书			材料	70g书写纸		单位	mm	厂商物料编号	变更履历	修改		日期	
文件尺寸	54x80mm（单P尺寸）			工艺	1C印刷 风琴折		公差	±0.5mm			审核		日期	
设计日期	2024/07/13	文件版本	V02				比例	1:1			批准		日期	