


Product Manual




You can scan the QR code on your phone to download the app

1. Bluetooth device appearance and function instructions



- Magnetic Charging**
"Magnetic charging function, pay attention to the direction of magnetic attraction when charging."
- Control Key**
"When the device is connected to Bluetooth, press and hold to start recording, release the automatic translation and text conversion." "When the device sleeps, press the Control Key to wake up the device."
- Reset Key**
"Press the Reset Key to restart the device."
- Indicator Light**
"Sleep/Standby: no light"
"Bluetooth not connected: blue light flashes"
"Bluetooth connection successful: the blue light flashes three times"
"During charging, the red light is always on; when fully charged, the light is off."

2. Product Usage Process

- Press the voice control button on the device to wake up the device, and the device will flash green;
- Open (Settings) > "Bluetooth" on your phone, and select "TT-TALK (6-digit code)" in the device list to connect;
- After the "TT-TALK" device is successfully connected, it needs to be used with the "TT-TALK" APP.

Note: The device will enter sleep mode if it is not operated within 10 minutes. You only need to press the voice control button again to wake up the device, and the device will automatically reconnect with your phone.




1. Download the APP

Apple phones: Search for "TT-TALK" in the App Store, or scan the QR code with WeChat to download and install.
Android phones: Scan the QR code with WeChat to download and install directly (official app stores of Xiaomi, Huawei, OPPO, etc. will be launched one after another)





Android phone download guide: WeChat scan code > open with browser > download APK installation package
(Huawei phones need to turn off pure mode to download)




3. Language setting:

Open the "Yiqishuo" app installed on your phone, select and set the recognition language by clicking the "Mandarin" button on the left, and click the "English (US)" button on the right to set the target language for translation.
Currently, there are more than 100 languages to choose from.




4. Turn on automatic paste:

Turn on automatic paste, as shown below:




When this mode is activated, there will be a floating frame of "Picture-in-Picture Translator" on the right, which can be hidden to the side of the screen by swiping right.
Apple mobile phone APP turns on automatic paste: Enter settings - find the social APP that needs to be set (such as WeChat, WhatsApp) - click WeChat - find "Paste from other APPs" - set to allow Android mobile phone APP to turn on automatic paste.
Then, switch to any application (such as WeChat, QQ, WhatsApp, email, memo, etc.), click the text input box, then press and hold the voice control button of the translator, aim at the phone and say what you want to enter, release it after speaking, and the text will appear immediately, as shown below:




5. Voice to text:

Turn off the translation switch, as shown below:



Put the "Yiqishuo" app in the background, switch to a third-party app (such as WeChat, QQ, WhatsApp, email, memo, etc.), click the text input box and then press and hold the voice control button of the translator, aim at the phone and say what you want to enter, release it after you finish speaking, and the text will appear immediately, as shown below:



6. Voice translation:

Turn on the translation switch, as shown below:



Click the text input box, then press and hold the voice control button of the translator, point it at the phone and say what you want to enter, release it after you finish speaking, and the text in the translation box you speak and the text that the other party can understand will appear in the text box at the same time (the translation comes first, and the original text is in brackets).
The effect is as follows:



7. Sleep:

The device will enter sleep mode if no operation is performed within 10 minutes. Press the voice control button once to wake up the device. The device will automatically connect to the previous mobile phone and the "Yiqishuo" application will automatically resume work (if the "Yiqishuo" application cannot resume normal work, you need to restart the APP again).

8. Voice broadcast:

Turn on the broadcast switch, as shown below:



After pressing the voice control button on the Bluetooth device and saying what you want to say, the phone will automatically broadcast the translated content.

9. Display only the translation:

Turn on the switch to display only the translation, as shown below:



Only show text: ☒

When the phone translates what is said, the translation is displayed first, and the original text is in brackets.
Note: You need to turn on translation to turn on the "Show only translation" function

10. Display floating window function:

Turn on the display floating window switch, as shown below:



Only for the first opening, you need to enable the floating window permission, and then return to the "Yiqishuo" app.

12. Automatic voice translation function:

Open the homepage of the "Yiqishuo" application, set the source language to your own language, switch the target language to the other party's language, press and hold the voice control button of the Bluetooth device, then click to play the voice message, and release the voice control button after the playback is completed.
At this time, the translation content of the voice message will be immediately broadcast.




13. Conversation Translation:

When you are talking face to face with foreign friends or customers, open the "TT-TALK" application dialogue translation interface, set your own language and the other party's language, then press and hold the microphone button on the screen, speak to the phone, release it when you are finished, and the translation will appear and be broadcasted immediately.



14. Audio and video calls:

When communicating with foreign friends or customers remotely, open the video call interface of the "TT-TALK" application, set your own language, the other party's language and the call type, and then click to invite friends to call, send the invitation link to friends, let them open the call link and join the call. Return to the app and wait for friends to answer.
After the call is connected, each party speaks their native language, and the app will translate the sound heard in real time, and bilingual subtitles will appear.



Note: The invitation link will become invalid if it is not used for more than five minutes. You need to invite again and send the latest link to your friends.

15. Simultaneous Interpretation

For the simultaneous interpretation function, first set your own language (such as Mandarin) on the left side and the other party's language (such as English) on the right side. After the settings are completed, you can start interpreting.


You can translate while speaking, present it in the form of text, and interpret for a long time. The text record of simultaneous interpretation can be saved in TXT format and then shared or stored.

Suitable scenarios: on-site multinational meetings, recording details for international students abroad, taking foreign language online courses, watching foreign language videos, etc.



16. Photo Translation

Open the "Yiqishuo" APP and select Photo Translation. The left side is the photo recognition language and the right side is the translation language. You can also import mobile photos for translation. Both photos and pictures can be translated. You can crop photos by taking photos.




17. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

18. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

19. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

20. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

21. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

22. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

23. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

24. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:



Find and click Additional settings


Click into Languages & Input

Replace the input method with: Baidu Input Method

Choose input method



Use on-screen keyboard



Take Xiaomi mobile phone as an example: Open Settings → More Settings → Language and Input Method → Keyboard, Mouse → Enable the use of on-screen keyboard (as shown below)

25. Offline translation (new)

Offline translation privileges, high-precision real-time offline translation, worry-free travel around the world, applicable to all offline translation functions in the APP, offline languages: Chinese, English, Japanese, Korean, French, Spanish, German, Russian, Thai.

Troubleshooting

- This Bluetooth device is compatible with mobile phone models of major manufacturers, and functions are realized through Bluetooth connection control. If the built-in input method of the mobile phone conflicts with the function of this product, it is recommended to download and install "Baidu Input Method" for use, which will be smoother.
- If the built-in input method of Android phones from different manufacturers conflicts with the function of this product, you can restore it by turning on the screen keyboard (steps are as follows):
Take Xiaomi mobile phone as an example: open the settings first:

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.