

chillax

www.chillaxcare.com



EN : User Guide (p.1)
FR : Manuel d'utilisation (p.2)
EU DECT Audio Baby Monitor

Chillax Baby 360, Chillax Baby 360-2

1 Important guidelines for installation

- To use your Baby Unit and Parent Unit together, you must be able to establish a radio link between them, and the range will be affected by environmental conditions.
- Any large metal object, like a refrigerator, a mirror, a metallic door or reinforced concretes, between the Baby Unit and Parent Unit may block the radio signal.
- The signal strength may also be reduced by other solid structures, like walls, or by radio or electrical equipment, such as TVs, computers, cordless or mobile phones, fluorescent lights or dimmer switches. If the signal is weak, try moving the Parent and/or the Baby Unit to different positions in the rooms.
- Determine a location for the BABY UNIT that will provide the best sound reception of your baby in his/her crib. Place the BABY UNIT on a flat surface.
- Do not place the parent and baby units too close together, or you may hear a high pitched noise. The device is not faulty. The units are designed to be operated at some distance a part e.g. in separate rooms.

SAFETY WARNINGS :


- Strangulation Hazard: Keep the power cables out of the reach of children (more than 3ft (1m) away).
- Do not place the Baby Unit or cords in the crib or within reach of the baby.
- Adult assembly is required. Keep small parts away from children when assembling.
- This product is not a toy. Do not allow children to play with it.
- This Baby Monitor is not a substitute for responsible adult supervision.
- Do not cover the Baby Monitor with a towel or blanket.
- Do not use the Baby Monitor in damp areas or close to water.
- Do not install the Baby Monitor in extreme cold or heat, direct sunlight, or close to a heat source.

CAUTION :


- This Baby Monitor is compliant with all relevant standards regarding electromagnetic fields and is, when handled as described in the User Guide, safe to use. Therefore, always read the instructions in this User Guide carefully before using the device and keep it for future reference.
- Never use extension cords with AC Adapters. Only use the Adapter provided.
- Do not touch the plug contacts with sharp or metal objects. Always use the rechargeables batteries provided in the box.

2 Getting Started

2.1 Charge the Baby Unit




- The batteries are pre-installed in the battery compartment of the baby unit.
- Remove the tag at the end of the compartment cover.



- Insert the DC plug of the power adapter into the DC socket at the rear bottom of the charger pod.
- Connect the other end of the power adapter to the mains socket.

Note : Only use the supplied power adapter.



- Place the baby unit on the charger pod. The charging indicator comes ON.
- Charge the battery for 16 hours in the baby unit on the charger pod before you use it for the first time.


NOTES :

The standby time is up to 9 hours however, it varies depending on the sensitivity level you set, your actual use and the age of the battery.

2.1.1 Replacement of the battery cells in the Baby Unit

You can replace the battery cells when the battery capacity is degraded after a long period of use.

- Place the baby unit on the table with the battery lid facing upwards.
- Use a small coin to turn the lock counterclockwise.
- Now lift the battery compartment cover with your other hand.




- Replace the battery compartment cover.
- To lock the cover, use the small coin again to turn the lock clockwise.
- Replace the baby unit on the charger pod.
- The power indicator comes ON.

2.2 Charge the Parent Unit

The parent unit comes with two battery cells. Charge the battery for 16 hours in the parent unit before you use it for the first time.

- Slide off the battery compartment cover.
- Insert the two supplied battery cells following the proper battery polarity into the compartment.
- Replace the battery compartment cover.
- Insert the small plug of the power adapter into the socket on the side of the parent unit.
- Connect the other end of the power adapter to the mains socket.
- The Charging Indicator comes ON.



NOTES :

- After the first charge (16h), the parent unit only needs 11h to be fully charged.
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.
- The standby time is up to 13 hours however, it varies depending on the sensitivity level you set, your actual use and the age of the battery.

SMART ECO MODE :

- Smart ECO mode automatically minimizes audio transmission and optimizes autonomy. The closer you are to your baby, the less energy the device consumes to establish a perfect connection. The feature is self-adjusted by the system.

3 Using Your Baby Monitor

3.1 Power on/off the Parent Unit

- Slide ON the power switch **12**. Power LED is now ON.
- The parent unit is now powered on and will search for and link itself to the baby unit.

3.2 Power on/off the Baby Unit

Slide ON the power switch **1**. Then the baby unit will automatically connect to the parent unit.

3.3 Listen to your baby

Now the parent unit will sound, and the sound level indicator will inform you when the baby unit detects noise in the baby's room.

The **VOX mode** implemented in this device guarantees you peace of mind, as it activates the parent unit only above a certain level of sound in the baby room, to avoid being disturbed by background noises. The VOX mode is adjustable (see chapter Sound Level Indicator Setting).

3.4 Adjust Speaker Volume

There are 5 volume levels on the baby unit, and 6 levels on the parent unit including VOLUME OFF.

- Press **▲** or **▼** on the parent unit or on the baby unit to adjust the respective volume level.
 - OFF** will be displayed if the volume of the parent unit is turned off.
- Changing the volume setting on the baby unit will affect the baby unit volume when using the Talk Back & Lullaby features.

3.5 Talk Back

You can use the Talk Back feature to comfort and reassure your baby. Whilst using Talk Back you will not be able to hear your baby until you release the button.

- Press and hold **20** on the Parent unit to speak to your baby. The display on the Parent unit shows **Talk**.
- Release the key to hear your baby again.

3.5.1 Adjust Talk Back volume

The baby unit has 5 volume levels from Level 1 to Level 5. Press **▲** or **▼** on the baby unit to increase or decrease the volume respectively.

NOTE : If a lullaby is playing, it will stop during Talk Back, but will restart from the beginning when the Talk Back ends.

3.6 Lullaby

There are 5 lullabies available to play.

- Press **▶** on the baby unit to start playing a lullaby. Press again to stop playing.
- Press **🎵** on the baby unit to select the lullaby and start playing.
- During playback, press **🎵** to switch between different lullabies.

NOTE : This product has an exclusive non disturbing parent mode implemented.

You can play lullabies on the baby unit without hearing them on the parent unit to keep peace of mind.

3.7 Room Temperature Monitoring

The baby unit constantly measures the temperature in your baby's room and alerts you if it gets too hot (higher than 26°C) or too cold (lower than 14°C) with the unit showing **TEMPERATURE** **🌡️**. The temperature is displayed clearly on the parent unit's standby screen. However, it is for reference only.

4 Setting your Baby Monitor with the Parent Unit

4.1 Setting up the Language

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **LANGUAGE**.
- Press **≡** **OK** and **▲** or **▼** to select your desired language.
- Press **≡** **OK** to confirm the selection.

4.2 Setting up the Nightlight

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **NIGHTLIGHT**.
- Press **≡** **OK** then **▲** or **▼** to select **ON** or **OFF** or **DIM**.
- Press **≡** **OK** to confirm the selection.

NOTE :

- ON – full brightness, DIM – 80% brightness, OFF – light off.
- The Nightlight can also be turned ON, OFF or DIM at the baby unit by pressing the **💡** button on the baby unit.
- The Nightlight icon **💡** displays on the parent unit when the Nightlight turned on.

4.3 Setting up the Lullaby

You can set the lullaby playback ON/OFF and the playback volume (level 1 to 5) at the baby unit.

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **LULLABY**.
- Press **≡** **OK** then **▲** or **▼** to select **ON** or **OFF** or **VOLUME**.
- Press **≡** **OK** to confirm the selection.

NOTE : Press **▲** or **▼** to select the lullaby playback volume from levels 1 to 5 at the baby unit when **VOLUME** setting is selected.

4.4 Setting up the Temperature

You can set the room temperature detection the following: -

FORMAT – to select temperature in Celsius or Fahrenheit.

ALERT – to select Alert **ON** or **OFF** when the room temperature reaches the maximum or minimum limits.

MINIMUM – to set the lowest alert temperature (down to 11°C, default is 14°C)

MAXIMUM – to set the highest alert temperature (up to 35°C, default is 29°C)

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **SET TEMP**.
- Press **≡** **OK** and **▲** or **▼** to select **FORMAT**, **ALERT**, **MINIMUM** or **MAXIMUM**.
- Press **≡** **OK** to confirm the submenu options then follow by **▲** or **▼** to select then **≡** **OK** to confirm.

4.5 Setting up the Sound Detection Level

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **VOX LEVEL**.
- Press **≡** **OK** and **▲** or **▼** to select **LEVEL 1** to **5** or **OFF**.
- Press **≡** **OK** to confirm the selection.

NOTE : When the VOX mode is activated, the sound of the parent unit will turn off if no sound is detected. When the sound is detected by the baby unit, the sound of the parent unit switches on immediately. You can change the sound detection level by pressing **▲** or **▼** to select the sensitivity levels (1 to 5).

For example, if you choose level 1 it's very sensitive and you can hear the slightest noise in the room.

4.6 Reinitialisation settings

You can restore all the adjustable settings back to their original factory settings.

- Press **≡** **OK** to access the main menu.
- Press **▲** or **▼** to select **DEFAULT**.
- Press **≡** **OK** to confirm the selection.

5 Help

Not linked is displayed on the screen

- The parent unit and the baby unit may be out of range with each other. Reduce the distance between the units, but not closer than 1.5 metre.
- The baby unit may be switched off. Turn the baby unit on.

The parent unit beeps

- Out of the baby unit range. Reduce the distance between the parent unit and the baby unit.
- The baby unit may be switched off. Turn the baby unit on.
- Batteries in parent unit are running low. Connect the parent unit to the mains power with the supplied power adaptor for recharging.

Cannot hear sound or baby cry from the parent unit

- The volume level in the parent unit may be set too low, increase the volume level of the parent unit. Refer to section Adjust Speaker Volume for volume level settings.
- The parent unit and the baby unit may be out of range with each other. Reduce the distance between the units, but not closer than 1.5 metre.

The baby monitor system produces a high-pitched noise

- The parent unit and the baby unit are too close to each other. Make sure the parent unit and baby unit are at least 1.5 metre away from each other.
- The speaker volume of the parent unit may be set too high. Decrease the volume of the parent unit.

Battery cells in the parent unit is running low quickly

- The volume level of the parent unit may be set too high, which consumes more power. Decrease the volume level of the parent unit.

Talk back feature is not working

- Check that the volume is loud enough at the baby unit, refer to section Adjust Speaker Volume.

6 Cleaning

Clean the Baby Monitor with a slightly damp cloth or with an anti-static cloth. Never use cleaning agents or abrasive solvents.

IMPORTANT

Always switch off and disconnect the power adapter before cleaning your baby monitor.

7 Standard Warranty

This product is guaranteed in accordance with the laws in force in the country where you purchased it. For detailed information on how to activate and implement the warranty in your country, or for guidance on the procedure to follow in order to benefit from the warranty, please contact us by email at: support@chillaxcare.com

8 Technical Specifications

Radio Frequency	1921.536-1928.448 MHz
Field Range/Indoor Range	Up to 1100ft* / Up to 164ft*
Battery Autonomy (Parent and Baby Units)	Up to 13 hours working**
Electrical Connection (Parent Unit and Charger Pod)	WARNING: Use only with provided power supplies. The network voltage is classified as hazard by the criteria of the EN62368-1 standard.
Rechargeable battery (Parent and Baby units)	Use only the batteries supplied. Use any other type of battery presents a risk of explosion. Used batteries must be disposed of in compliance with current environmental protection regulations.
Operating Temperature	From 5°C to 40°C


* Values may vary according to environment.

** Depending on initial charge
Specifications are subject to change without prior notice.
Chillax, Chillax Baby and the Logos, are trademarks of Chillax Care Limited.
5GenCare and the Logo are trademarks of 5GenCare Limited. All other trademarks are the property of their respective owners.
© 2025 Chillax Care. All rights reserved.

9 Disposal of the Device (environment)

  This symbol means that your inoperative electronic appliance must be collected separately and not mixed with the household waste. Local authority has implemented a specific collection and recycling system for which producers are responsible.
Help us protect the environment in which we live!


Overview of Baby Unit



Inside the Box

- 1 x Parent Unit
- 1 x Baby Unit
- 1 x Charger Pod
- 2 x Power adapters
- 1 x User Guide
- 2 x AAA sized rechargeable Ni-MH battery cells

Overview of Parent Unit



     	ON when parent unit is linked and within range of baby unit. Flashes when no link or out of range.
	ON when lullaby is playing.
	ON when sound alert of temperature is enabled. Flashes when sound alert of temperature is triggered.
	ON when the speaker volume is turned off.
	ON when night light is ON. OFF when night light is OFF.
	Battery level indicator.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For PU

The device has been tested and comply with FCC/ISED SAR limits.

For BU

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.