

OBDII CAR DIAGNOSTIC User Manual

This OBDII adapter is compatible with the following software:

Android: OBD Car Doctor, Torque, E OBD2, DashCommand

IOS: OBD Car Doctor, E OBD2, ODB AUTO DOCTOR, CARISTA, Car Scanner ELM OBD2

Window: ScanMaster-ELM, ScanTool.net, PCMSCAN

Software download



Android



IOS

Download and Get Connected



1.Download APP



2.Install OBDII Sensor

Possible OBDII prot Locations



3.Start your engine and make sure the indicators on the OBDII Scanner light up



4.Find Bluetooth or WIFI Signal in Phone and Connect

At the end of its service life, this product may not be disposed of in the normal household waste, but rather must be disposed of at a collection point for recycling electrical and electronic devices. The materials are recyclable according to their labelling. You make an important contribution to protecting our environment by reusing, recycling, or utilizing old devices in other ways. Please ask your municipal administration where the appropriate disposal facility is located.



Pair the iPhone to the sensor



Select Settings> General> Bluetooth



Make sure Bluetooth is ON. Wait for the scanner to appear



Open the APP and operation



Select Settings> General> Bluetooth



Make sure Bluetooth is ON. Wait for the scanner to appear



Select device and wait for it to display connected, enter 1234 password then exit

Pair the Android device to the sensor

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.
- The device has been evaluated to meet general RF exposure requirement.
- To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).