

尺寸76*142.5mm

英语

TRANSLATOR

TABLE OF CONTENTS

English.....2-8

German.....9-17

Italian.....19-26

French.....27-39

Spanish.....36-44

Japanese.....45-52

01

Turn the screen on or manually

When the screen is on, short press the Right power button to turn off the screen.

When the screen is off, short press the Right power button to turn the screen on. Automatically turn off the screen.

When there is no operation on the device within the sleep time and by the system, the device will automatically turn off the screen display (The time can be set in Settings - Display).

Quick Operation Guide

Print of all there you for using our product!
This device supports Wi-Fi, please select Wi-Fi according to the current actual use environment.

Wireless Network Environment

Turn on the translator and connect to Wi-Fi.

Connect to Wi-Fi through the menu "Settings > Wi-Fi".

After turning on Wi-Fi.

Click the Wi-Fi you want to connect to and enter the correct password.

Battery Power

The main screen of the device is the main function interface of the device. There are 18 buttons in total, including voice translation, instant translation, photo translation, document translation, offline translation, voice translation, document translation, and automatic interpretation. Instant translation, include group chat, message case conversion, and learning, a assistant, global chat, video dictation, vocabulary library, camera, multimedia, like management, favorites, settings, etc.

After charging is completed, a full battery icon is displayed.

Power On And Off

Power on: Press and hold the power button on the Right side of the device or the screen display for 5 seconds, the device initialization takes some time, please wait patiently.

Shutdown: Long press the power button on the Right side of the device is 5 seconds will pop up, select the shutdown button to shut down the device.

03

Turn The Screen On And Off

When the screen is on, short press the Right power button to turn off the screen.

When the screen is off, short press the Right power button to turn the screen on. Automatically turn off the screen.

When there is no operation on the device within the sleep time and by the system, the device will automatically turn off the screen display (The time can be set in Settings - Display).

Home Screen

The main screen of the device is the main function interface of the device. There are 18 buttons in total, including voice translation, instant translation, photo translation, document translation, offline translation, voice translation, document translation, and automatic interpretation. Instant translation, include group chat, message case conversion, and learning, a assistant, global chat, video dictation, vocabulary library, camera, multimedia, like management, favorites, settings, etc.

Status Bar

The top of the device screen displays some status information about the device, such as Wi-Fi network status, power, Bluetooth and other status information.

Main Function Introduction

The translation function has two states: offline translation and online translation, which will automatically switch according to the current status of the translator. Online translation currently supports instant translation between languages in 142 countries (supporting 196 languages and instant documents).

Offline translation currently only supports 18 offline translations: Arabic, German, Russian, Traditional Chinese, French, Korean, Dutch, Simplified Chinese, Portuguese, Japanese, Taiwanese, Thai, Spanish, English (US), English (India), Vietnamese (Vietnam), Indonesian, Hindi (with change with version updates).

04

Click the language button above the translation to enter the language selection list.

Click the button in the upper right corner to select the language selection option.

Click on the desired source/target language option.

Speech Recognition

Long press the voice input button on the device that left voice button corresponds to the language on the left side of the homepage, the right voice button corresponds to the language on the right side of the homepage to enter the voice recognition state.

After clicking on the voice will be automatically recognized and playback, and at the same time it will be automatically translated into the set target language and voice translation will be performed (the voice broadcast method depends on the settings) of the language selection list.

The top displays real records of speech translations. When there are too many translation records, click the page up or down to enter the translation records. When the translation is offline, the translation will automatically switch to offline translation.

Click the language button at the top of the translation homepage to enter the language selection list.

Click on the desired source/target language option.

Recording

Recording recognition

Click "New Recording" in the upper right corner.

During the recording process, the translated language will be automatically translated and displayed on the page.

Click the language setting icon in the upper left and upper left corner to select the language setting (Open translation).

There is no limit to the length of recording time.

Save recording results

During the recording process, click the green check icon in the lower right corner and a new translation confirmation box will pop up.

05

Click the "OK" button to automatically save the recording file.

Click the button in the upper right corner to enter the recording list and view the saved recording files. Record list storage location: Plug into your computer and select the Recording-Translator folder.

Dialogue

Introduction: The translator's dialogue function provides intelligent online voice translation, supporting recognition and translation in 41 major countries (regions around the world) (note: change with version updates). It breaks the regional barrier for users' language skills, breaks the communication bridge, and truly realizes barrier-free voice communication with users (friends), join a group conversation.

Actual usage: Any member can communicate. The device does not join any third.

Click the Chat button on the home page.

Click the translation translation ID of the device you want to invite and click OK.

Click the "Enter" button to automatically create a multiperson interactive chat operation.

Invite friends to join the conversation

Click the button in the upper right corner of the homepage and select the option to add members.

Enter the device's conversation translation ID (invitation and click "OK").

Click the "Enter" button to automatically invite friends to join the chat.

Add member

Click the button in the upper right corner and select the option to add members.

Enter the translation ID of the device to be invited and click "OK".

Click the "Enter" button to successfully invite friends to join the chat.

Member management

Click the button in the upper right corner and select the member management option.

06

Click to set mutual translation to set multi-person mutual translation.

Standby time: After entering you can set the sleep time, then set for options: 1 minute, 5 minutes, 15 minutes, and permanent.

Auto and time: There are two ways to set the time automatically and manually.

Clear data: Reset the device to the original state (delete the user's device version's data, this operation is irreversible).

Connect upgrade: Check system information and update firmware version.

About the device: Check the current device name, version number, copyright and other information.

Photo Translation

language selection

Click the language button at the top of the home page to enter the language selection list.

Click on the desired source/target language option.

Photo translation

Click the language button at the top of the home page to enter the language selection list.

Tap the screen to focus on the text you want to translate.

Click the button at the bottom of the screen.

After recognition, the translation results are displayed.

Offline Translation

Precaution

Ready to use at least.

The usage is the same as online translation.

Installer

Wi-Fi settings: Configure the device's Wi-Fi network.

Bluetooth mode: There are two modes to choose from: automatic broadcast and manual broadcast. If manual broadcast mode, the translation results need to be broadcast manually and click play.

07

Bluetooth: Connect device Bluetooth.

Standby time: After entering you can set the sleep time, then set for options: 1 minute, 5 minutes, 15 minutes, and permanent.

Auto and time: There are two ways to set the time automatically and manually.

Clear data: Reset the device to the original state (delete the user's device version's data, this operation is irreversible).

Connect upgrade: Check system information and update firmware version.

About the device: Check the current device name, version number, copyright and other information.

Online Upgrade

When a new upgradable version becomes available, the device will check when the user updates the language, notice the device or 24 hours after the last check. Both Wi-Fi and mobile networks work with the update.

Configurations

Product model	M80
Screen size	4.02 IPS HD screen
processor	Qualcomm MSM 12500
Screen Resolution	640*1136
networking	2G + 16G
Charging Interface	Type-C
microphone	High precision microphone
chip	Corning Gorilla Glass

08

FCU Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used for portable exposure without restriction.