

Smart Glass

User guide

Specification

Product Material: PC+ABS+Metal

Lens Material: PC

Weight: 34g

Rated voltage: 5V

BT Version: Bluetooth V5.3

Pairing name: YK-***

Charging port: Magnetic Charging Column

Charging time: About 1.5 hours

Battery life: 5-6 hours (at 60% volume)


Standby time: about 20 hours

Capacity: 90mAh*2

Sound channel: Double horn

Connection distance: <10m

Product diagram



Power on/off

Turn on: Press and touch both sides of the mirror legs for 2 seconds to turn on


Power off: Long press left or right mirror leg touch for 3 seconds to power off

(Note: If there is sweat on the glasses will affect the switching effect, please pay attention to clean it)

Pairing

After the smart music eyewear are turned on, turn on the Bluetooth of the mobile phone, search for the device nameYK-*** and connect.

(Note: Smart music eyewear turn off automatically when charging)



Phone

Answer/hang up: Touch and tap the mirror leg (right) once

Reject the call: Touch and double click the mirror leg (right)

Note: The volume is adjusted on the phone during the call

Music

Pause/play music: Touch and tap the mirror leg (right)1 time

Remote camera

Remote camera: Turn on the phone camera when Bluetooth is connected, touch and click the mirror leg (right) twice to take a picture

Voice assistant


Wake up the voice assistant: Touch and tap the mirror leg (left)2 time when music is not playing

Wake up voice assistant

-***

Recharge

Magnetic charging: the red light is always on when chargingThe light is off when fully charged



WARNING

1. Keep this product out of the reach of children.
2. Please use and store the product and accessories within the temperature range of 5°C-35°C. When the ambient temperature is too high or too low, it may cause malfunction.
3. Please reasonably control the volume and time of use of the product to avoid damage to the hearing.
4. Do not use the product while driving, cycling, operating machinery or doing work that requires attention to external sounds.
5. Please do not disassemble, hit, squeeze or put the product into fire to avoid explosion. If the battery is bulging or leaking, please do not continue to use it.
6. Do not use the device during thunderstorms, which can cause the device to work abnormally and increase the risk of electric shock.
7. Keep a distance of at least 15cm from implanted medical devices (e.g. pacemakers, etc.) when using the device.
8. Due to the characteristics of Bluetooth technology, the strength of the signal is related to the specific use of the environment, if there are more wireless signals overlap in the vicinity, or there is a strong electromagnetic interference, the product receives a weaker signal, or even disconnected.
9. If you do not use it for a long time, please charge the product once every three months to avoid battery over-discharge damage.
10. Stop using the device before cleaning and maintenance, please use a clean, dry soft cloth to wipe the device.
11. Recommended to use brand manufacturers, through the CCC certification, the output voltage of 5V charger to charge the product. Please avoid using fast chargers with an output voltage of more than 5V, so as not to damage the product by charging at too high a voltage!

Fault resolution

- 1.Smart Music eyewear can't be paired with mobile phone?
Answer:Please check whether the Smart Music eyewear are in pairing or back-connect mode, as well as check whether the Bluetooth search function of your mobile phone is turned on; and check the Bluetooth menu on your device and delete/cancel the Smart Music eyewear, and reconnect the Smart Music eyewear according to the instructions.
2. Smart Music eyewear can't start?
Answer:Please check the battery level of Smart Music eyewear.
- 3.Can I replace the battery of Smart Music eyewear?
A:No, this product uses non-removable lithium polymer battery.
4. Smart Music eyewear disconnect from mobile phones within 10 metres?
Answer:As Bluetooth is a wireless technology, so for smart music eyewear with has been linked.
- 5.I can't hear the sound after connecting the smart music eyewear to computer or mobile phone?
Answer:Please check whether the output channel of the computer has been set as a Bluetooth audio device and whether the Bluetooth of the computer supports A2DP protocol, and check the volume of the computer/mobile phone.
6. Can I use Smart Music eyewear to control the apps on my mobile phone after it is connected to my mobile phone?
Answer:The software settings of device apps may vary, and the functions of individual apps are not supported by Smart Music eyewear.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement :
The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device can be used in portable exposure condition without restriction.

Chemical Hazardous Ingredient List						
Names and contents of hazardous substances in products						
Accessory name	Harmful substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Printed circuit assemblies	○	○	○	○	○	○
Small structural parts such as housings	○	○	○	○	○	○
This form has been prepared in accordance with the provisions of SJ/T11364. ○: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements stipulated in GB/T26572. X: It means that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirement specified in GB/T26572. The parts marked with "X" in the table cannot be substituted for hazardous substances due to the limitation of global technological development.						
Printed Circuit Board Components*: Includes printed circuit boards and their parts, electronic components, etc. Depending on the product model, the product you purchase may not contain all of the above components.						
 Electrical and electronic products sold in the People's Republic of China must be marked with this symbol, and the number inside the symbol represents the environmental protection use period of the product under normal use.						

All accessories

Product x1, manual x1, magnetic charging cable x1, glasses cloth x1