

KC256说明书

高：100mm
宽：100mm
总宽：700mm



#F29008



#060000

宽：100mm



Gianna Bloom Go
User Manual



If you have any trouble using the product,
feel free to email us at service@giannashop.com.

Thank you for choosing the Gianna portable sleep soother!
Please read the user manual carefully
and keep it in a safeplace for future reference.

How to Use

- 1 Please fully charge the device before first use.
- 2 Use the included hook ring or lanyard to secure the device to a crib or stroller.



Scan the code for more ways to use Gianna Bloom Go

How to Connect to the App

Preparation



- 1 Download and open the "My K-Life" app.
- 2 Scan the QR code provided to download the "My K-Life" application.


Entering Pairing Mode

- 1 Ensure your "Gianna Bloom Go" is powered on.
- 2 Press and hold the [Light / Wi-Fi] button for about 5 seconds.
- 3 The Wi-Fi indicator will start blinking blue, indicating the device has entered pairing mode. Once connected successfully, the device will respond accordingly. Follow the on-screen instructions in the app to complete the connection.

Troubleshooting

- 1 If pairing fails, the indicator will stop blinking after 5 minutes. Simply repeat the steps above. Ensure the device is within range of your Wi-Fi router. Please note: only 2.4GHz Wi-Fi is supported. 5GHz is not compatible. Double-check your Wi-Fi password is entered correctly.

Button Functions



1. [Play / Power] Button

- 1 Short press: Play your saved favorite sound and activate the indicator light
- 2 Long press (2 seconds): Power ON / OFF the device

2. [Light / Wi-Fi] Button

- 1 Short press: Turn the night light ON / OFF (8 color options)
- 2 Long press (5 seconds): Enter Wi-Fi pairing mode

3. [Volume +] Button

- 1 Increase sound volume

4. [Volume -] Button

- 1 Decrease sound volume

5. Child Lock Indicator

- 1 Prevents accidental touches. When enabled, only the Power button (long press) remains functional. All other buttons are disabled.

6. Wi-Fi Indicator

- 1 Blinking blue light: Device is in pairing mode (lasts up to 5 minutes)
- 2 Solid blue light: Successfully paired (stays on for 5 minutes, then turns off)
- 3 If not connected within 5 minutes, the light stops blinking and pairing mode ends automatically.

7. Type-C Charging Port

- 1 Supports 5V / 2A input for quick and stable charging

8. Battery Indicator Light

- 1 When battery ≤ 20%: Red light is displayed
- 2 When battery > 20%: Indicator turns off
- 3 While charging: Red light is displayed
- 4 Fully charged: Green light is displayed

Gianna Bloom Go User Interface



Note

- 1 Color and brightness can only be adjusted via the app.
- 2 When the battery level drops below 3%, the device will shut down automatically and all settings will be saved.
- 3 Restore to factory settings: Press and hold both the [Volume +] and [Volume -] buttons for 2 seconds. After a factory reset, all settings will return to default except for recordings saved on your phone.
- 4 Only 2.4GHz Wi-Fi networks are supported.

Certifications

- 1 Device certified: FCC, CE, RoHS, UL, UKCA

Support

- 1 This portable sleep soother supports app control and includes a one-year warranty. If you have any questions about this device, please contact us at service@giannashop.com. We will respond to your request within 24 hours.

总宽:700mm

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.