


1314 Remote Control 44 Keys 2.4G/Infrared



- 1 -

Remote control M+/- and controller key mode list

- | | | |
|----------------------------|--------------------------------------|--|
| 1. Synchronized breathing | 16. Fill gradient | 31. Color by color asynchronous flashing |
| 2. Asynchronous breathing | 17. Fill transition | 32. Accumulation |
| 3. Synchronous transition | 18. Fill breath | 33. Shuttle |
| 4. Asynchronous transition | 19. Colorful and always bright | 34. Tunneling |
| 5. Synchronous gradient | 20. Colorful flashes | |
| 6. Asynchronous gradient | 21. Colorful breath | |
| 7. Synchronous strobe | 22. Collision | |
| 8. Asynchronous strobe | 23. Interval | |
| 9. Stars twinkling | 24. Gorgeous | |
| 10. Blossom | 25. Segmented asynchronous breathing | |
| 11. Horse racing | 26. Segmented asynchronous jump | |
| 12. meteor | 27. Segmented asynchronous strobe | |
| 13. Running water | 28. Colorful horse racing | |
| 14. Cover | 29. Blinking transition | |
| 15. Building Blocks | 30. Squirm | |
- The list of key modes additionally includes the following modes

- 2 -

Remote Rotation Function Introduction to use

1. Rotation (AUTO) Pattern list can play up to 12 patterns, each pattern plays for 10s
 2. Factory default has put 9 modes

M1	M1	M2	M2	M3	M3
M4	M5	M6	null	null	null
 3. When rotating, it can be
 - Switch to the **next** mode of the current mode
 - Switch to the **previous** mode of the current mode
 4. When rotating, if you don't like the current mode, you can long press the

M1	null	M2	M2	M3	M3
M4	M5	M6	null	null	null
 5. through the app/remote control of other functions, debugging of any **new mode**, can be long-pressed

M1	new mode	M2	M2	M3	M3
M4	M5	M6	null	null	null
- Example: After deleting M18, the AUTO list becomes
- Example: New meteor mode, AUTO list becomes

The above is the description of the remote control, and the following is the description of the "Surplife" app.

- 3 -

I. Download Surplife APP

Download "Surplife" APP from Apple Store and Google Play Store, or scan the QR code.




Surplife APP



II. How to connect the controller to Wi-Fi network?


1) Register/Login your Surplife account.




2) Open your phone Bluetooth, turn on the device.

- 4 -

3) Enter "Surplife" app, tap "Add Device" or click "+" to add the device. Click Add to complete



4) Rename the device and select a room for it.




- 5 -

III. APP features in detail:


1). Colorful function

In the color interface, you can adjust the color and brightness of the light strip. Click "+" to enter the static effect interface, in the static effect interface, you can add or delete the color of the light strip, and long press a static effect to delete or edit the static effect




2). Lighting effect

1) Built-in lighting effect selection of various categories of scene modes, and can be long pressed to save or edit to add custom effects. In the Custom effect screen, click Create Custom Effect to add a custom effect




- 6 -

2) In the Custom Effects screen, click Create Custom Effect to add a custom effect.



3). Rotation function


You can select lighting effects for different categories of modes on the rotating screen and set the duration of the lighting effects. Different lighting effects can be combined and played back in sequence.




- 7 -

4). Spreading function

1) Single-frame smear interface: click Create Smear, select dynamic effect, color and color ratio, and click Save after setting.




2) Multi-frame paint interface: click to create a paint, slide the slider can be set to adjust the speed, click "+" to add a frame of the canvas to select the color of each frame, click save after the settings are complete.



- 8 -


5). Rhythmic function

1) Music Mode: Lighting jumps and changes with the rhythm of music. Click "Add Sound" to import a sound file or import from the built-in sound library.



2) Microphones


Cell phone cycloid or device cycloid function that converts light effects to different rhythms according to the signal received by the cycloid



— 9 —


6). Timing function

The lights controlled by this unit can be switched on and off according to the set time. When the lights are turned on, you can select colorful or moody lighting effects by yourself.



7). Group control function


Classify multiple controllers into the same group, you can simultaneously control the equipment in the group with one key dimming and color dimming, switching and other functions.



— 10 —

8). Scene Functions

In the scene interface, find the corresponding controller to create different scene lighting colors or dynamic effects according to your personal needs.




Attentions

- 1) Please use the product in a dry environment.
- 2) For input voltage, please use the DC voltage within the specified range as instructed in the manual, must not connect into 220VAC directly.
- 3) The product is requested common anode connection. The wrong connection will cause a malfunction.

— 11 —

- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) The battery type is a lithium-metal, non-rechargeable Cr2025.
- e) The nominal battery voltage is 3V DC.
- f) Non-rechargeable batteries are not to be recharged.
- g) Do not force discharge, recharge, disassemble, heat above 65°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- h) Ensure the batteries are installed correctly according to polarity (+ and -).
- i) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- j) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- k) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

— 13 —



Printed in China

— 14 —

! WARNING

INGESTION HAZARD: This product contains a button cell or coin battery.

DEATH or serious injury can occur if ingested.

A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.

KEEP new and used batteries **OUT OF REACH of CHILDREN**

Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



— 12 —

— 15 —

— 16 —

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.