



If you have any questions or concerns, please contact us at  
[support@mydribbl.com](mailto:support@mydribbl.com).

[www.mydribbl.com](http://www.mydribbl.com)

# Dribbl

**USER  
MANUAL**

**Dribbl**

## **HOME SPA BUBBLE BATH MASSAGER**

Model NO.: DRIBHOSPABB




## INTRODUCTION

THANK YOU FOR CHOOSING THE DRIBBL HOME SPA BUBBLE BATH MASSAGER.

PLEASE READ THIS MANUAL CAREFULLY BEFORE ASSEMBLING AND USING YOUR DRIBBL HOME SPA BUBBLE BATH MASSAGER.

Familiarize yourself with the features of the Home SPA Bubble Bath Massager first if you are inexperienced in handling this product. For your full enjoyment, it's important to follow proper safety procedures. Always check the electrical circuitry before using the bubble bath. Keep electric plugs away from water to avoid the risk of electrocution.

If you have any questions or concerns, please contact us at [support@mydribbl.com](mailto:support@mydribbl.com)




Dribbl

01

## PACKING LIST

- Host Machine x 1
- PVC Mat x 1
- Connecting Hose x 1
- Remote Control x 1
- PVC Self-adhesive Film x 16



## PRODUCT PARAMETERS

| ■ SPA BUBBLE BATH MACHINE |         |                    |            |
|---------------------------|---------|--------------------|------------|
| Machine Model No.         | BBM-001 | Remote Control No. | BBM-001-RC |
| Voltage                   | 120V    | Bubble Power       | 370W       |
| Heating Power             | 180W    | Total Power        | 550W       |

| ■ SPA BUBBLE BATH MAT |                                                                                           |
|-----------------------|-------------------------------------------------------------------------------------------|
| Main Material         | PVC soft glue                                                                             |
| Dimension             | 47.2" x 15.75" (with more than 100 bubbles)                                               |
| Suction Cup           | With 16 suction cups                                                                      |
| Suitable Bathtub      | Suitable for 1.7m flat bottom bathtub                                                     |
| Function              | Produces bubbles and oxygen to massage the back of the body to increase blood circulation |

Dribbl

02

## SAFETY PRECAUTIONS

In order to use this product safely and avoid causing personal injury or property damage to you or others, please abide by the following precautions:



### Notes on Machine

- The environment where this machine is used must be equipped a leakage protection device, and a qualified power socket should be used with a voltage of 120V.
- For the elderly and children under 13 years old, this product should be used under the careful supervision of their parents. However, the following people or those with the following conditions are not suitable for using this product (within 30 minutes after a meal, in a state of extreme hunger, with a severely weakened body, severe dehydration, high fever, heavy blood loss, with high blood pressure, heart disease, with a purulent ulcer, with an unhealed new wound, drunk, unconscious, during the menstrual period or pregnancy).
- When using it, please ensure that the host machine is placed on a flat surface, and the machine keeps a certain distance from the water source. It is strictly prohibited to use it in a place with high humidity.
- After using, the power plug should be unplugged immediately and the connection with the bath mat should be removed to avoid the danger of the water in the bathtub flowing back into the machine.
- When the power cord of the machine is damaged or there is a malfunction in other parts of the machine, the power should be cut off in time and contact the dealer, return it to the professional personnel of the manufacturer for repair. Don't repair or modify the machine by yourself.

Dribbl

03

### Notes on Mat

- For the first use, please wash the product with warm water, and do not use corrosive cleaning agents.
- The temperature of water for bathing is generally between 38-40°C, and it is better to have a bathing time of 15-20 minutes at a time.
- After using, remove the bathtub mat from the bathtub in time, use the bubble machine to blow out the accumulated water in the bath mat, and dry and store it.



### WARNING

- When children and the elderly use this product for bathing, they must be accompanied by an adult throughout the whole process.
- The indoor environment cannot be overly humid, and the power supply must be equipped with a leakage protection device.
- It is strictly prohibited to use the host machine in the bathtub.
- It is strictly prohibited to pour water on the hoset machine.
- It is strictly prohibited to place it in a place where it can easily be trampled by water.
- It is strictly prohibited to place it outdoors where it will be exposed to rain.
- Unplug the unit from the power supply after use.
- To reduce the risk of electric shock, do not remove, modify or immerse this plug.
- Do not use with any extension cords as this will disable the circuit protector.
- Unauthorized dismantling of the machine is prohibited.
- The cushion should not come into contact with sharp objects.
- Severely illpatients are prohibited from using or following doctor's advice.

Dribbl

04

## OPERATIONS



- Increase Bubble Button:** Increase the power of bubble. Each press increases the power and the amount of bubbles. There are 6 levels of adjustment. And rise one level with each press.
- Decrease Bubble Button:** Reduce the power of bubble. Each press reduces the power and the amount of bubbles.
- Heater ON/OFF Button:** Press it in bubble state can blow away the warm wind and enter the heating mode. Press again to turn off the heater.
- Bubble ON/OFF Button:** Press it, the Bubble Indicator will turn green, and enter the bubble mode. Press again can turn off.
- Bubble Indicator:** The red light indicates that the bubble is in standby mode, and when it turns green, it indicates that it is in bubble working mode.
- Heating Indicator:** When the light is on, the machine is in heating mode. When the light is off, the heater is turned off.

Dribbl

05

## INSTALLATION

### Machine Installation

- Take machine, remote control, hose and mat out of the box.
- Lay the mat in the tub and press each suction cup to suck firmly.
- Connect one end of the hose to the machine.
- Connect the other end of the hose with a air inlet.
- Cover the other air inlet with a cap.
- Fill in the water, connect the power to enjoy the bubble bath.



**Remark:** There are two air inlets on the Mat. When one is connected to the machine, the other has to be screwed with the cap. Both air inlets can be connected. Attach to the side that is convenient for you to control and place.

Dribbl


06

### Suction Cup Intrallation And Disassembly

There are two kinds of suction cups on the mat. Those on the outside are Suction Cup A, and in the middle are Suction Cup B.



**How to hold the suction cup A firmly?**  
Press it and turn to CLOSE according the direction to secure it immediately.



**How to hold the suction cup B firmly?**  
It can be absorbed immediately after being pressed down.

Dribbl


07

## SOLUTION FOR UNSECURED SUCTION CUPS

When the contact area of suction cups is not smooth (the bottom of the bathtub is not smooth), the suction cups can't be firmly attached. You can try to solve this problem by using PVC self-adhesive Film which included in the packing list.

Self-adhesive Film installation instructions: Firstly, put the Mat on the pre-determined position in the bathtub, and then glue the PVC self-adhesive Film directly under the suction cup.

If there are multiple locations need to be pasted, please glue the each suction cup to the PVC self-adhesive Film, then move to the next position until all positions are aligned and pasted.



Dribbl

08

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction