



- 250sq ft delivers a 5-star experience within 5 minutes*
- 350sq ft delivers a 5-star experience within 15 minutes*

*Results achieved by misting at high intensity

Note: Fragrance spread performance may vary depending on the space layout.


Scentiment



Scentiment, LLC. Houston, TX 77032

The Plug-In

The Plug-In



- 1- Diffusion Head
- 2- Nozzle
- 3- Oil Pipe

- 4- Empty 20ml Fragrance oil Bottle
- 5- Power Button / Intensity
- 6- Front Light Bar

Items in the box:

- The Plug In
- x1 Syringe (for Nozzle flushing only)
- Metal Hook

- x2 Nozzle
- x2 Oil Pipe
- x1 Empty 20ml Fragrance oil Bottle




Scan to
learn more



Video
Instructions

Scentiment App: Pairing Mode



3 Download the Scentiment app, and follow the prompts.





Video Instructions




Scan the code to watch a quick video on pairing your diffuser with the Scentiment App.


How to Add Oil



Power
Tap to turn on / Press and hold the power button to turn off



Scent Intensity



	Low	Med	High
Seconds ON	30s	30s	30s
Seconds OFF	300s 5 min	180s 3 min	120s 2 min

Diffuser is not misting: Flushing the diffusion head

Top view



- Take the syringe from the Spare Parts Box and fill it with Diffuser Cleaner or 90% alcohol.
- Insert the syringe into the top misting hole and flush the diffusion head.

Bottom view



- Remove the oil pipe, leaving the small black plastic nozzle attached to the diffusion head.
- Use the syringe to flush the nozzle as well.
- This process helps remove oil buildup that may block the diffusion head.

For aroma diffuser cleaning only. Non-medical use. Not for human use. Non-sterile.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.