

GS300使用说明书

1.外观说明

指示灯

麦克风

镜腿触控区

说明：左右镜腿对称分布触控区、麦克风、充电触点、扬声器及指示灯。

充电触点

扬声器

2.按键位置与功能

如何开机/关机？

打开双腿，眼镜开机

关闭双腿，眼镜关机

如何进入配对状态？

开启眼镜，即可进入配对状态

如何进行语音交互？

长按中间（左侧）

唤醒语音助手

镜腿触控区

说明：左右侧镜腿均分布触控区

如何播放音乐？

单击右侧

播放/暂停

前后滑动（左侧）

声音增加/减少

前后滑动（右侧）

下一首/上一首

来电电话如何操作？

前后滑动（右侧）

接听/拒接

向后滑动（右侧）

通话中挂断

如何控制手机拍摄？

进入手机拍摄界面后，向前滑动（右侧）
（仅部分安卓手机支持）

3.充电说明

当眼镜连接充电线后，将充电线的 USB 端接入标准充电器，仅需 60 分钟即可充满。

4.无线配对

打开手机无线搜索眼镜名“XXX”，在手机端点击配对即可。

5.安装连接APP

1.手机扫描二维码下载并安装APP。
支持系统：iPhone10.0、Android9.0 及以上版本
2.在APP中登录帐号，选择连接绑定眼镜。
提示：请确保手机无线处于开启状态，连接过程中需将眼镜靠近手机。

6.产品参数

产品类型：智能眼镜
无线连接：5.2
续航时间：8小时以上

扬声器：高保真
麦克风：语音降噪

电池容量：300mAh
充电时间：60分钟

7.主要功能

播放音乐

无线通话

语音助手

计步

距离

8.注意事项

1.切勿严重撞击眼镜。
2.切勿接触苯、稀释剂等化学物品。
3.请不要靠近强磁场、电击站。

4.请避开直射光线或发热器具。
5.切勿自行拆卸、修理、改造。
6.废弃包装、电池、旧电子产品，请分类妥善处理。

GS300 User Manual

1. Appearance description

Indicator light

Microphones

Mirror leg touch control area

Description: The touch area, microphone, charging contacts, speaker and indicator light are symmetrically distributed on the left and right temples.

Charging contacts

Speaker

2. Button Location and Function

How to turn on/off?

Open the legs, the glasses are turned on.

Close the legs, the glasses are turned off.

How to enter pairing status?

Turn on the glasses to enter the pairing status.

How to do voice interaction?

Long press the center(left side)

Wake up the voice assistant

Mirror leg touch control area

Description: The left and right side mirror legs are distributed with touch control area.

How to play music?

Click the right side

Play/Pause

Swipe back and forth (left)

Sound increase/decrease

Slide back and forth (right side)

Next/Previous

How does incoming call work?

Swipe back and forth (right)

Answer/Reject

Swipe back (right)

Hang up during a call

How to control the phone shooting?

After entering the cell phone shooting interface, swipe forward (right)
(Only supported by some Android phones)

3.Charging instructions

When the glasses are connected to the charging cable, connect the USB end of the charging cable to a standard charger and it will take only 60 minutes to be fully charged.

4.Wireless Pairing

Open your cell phone to search for the name of glasses "XXX" wirelessly and click pairing on the cell phone.

5.Installation of connection APP

1. Scan the QR code on your cell phone to download and install APP.
Support system:For iPhone 10.0, Android 9.0 and above.
2.Login your account in APP and choose to connect the bound glasses.
Tips: Please make sure the wireless of your cell phone is on, and keep the glasses close to your cell phone during the connection process.

6. Product parameters

Product type: smart glasses
Wireless connection: 5.2
Battery life: more than 8 hours

Speaker: high fidelity
Microphone: voice noise reduction

Battery capacity: 300mAh
Charging time: 60 minutes

7. Main functions

Play music

Wireless call

Voice assistant

Step counting

Distance

8. Precautions

1. Do not severely impact the glasses.
2. Do not contact chemicals such as benzene and thinners.
3. Please do not approach strong magnetic fields or electric shock stations.
4. Please avoid direct light or heating appliances.
5. Do not disassemble, repair or modify by yourself.
6. Please classify and properly dispose of discarded packaging, batteries, and old electronic products.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.