

160 mm

AI Smart Glasses User Manual

Y03 – Y05 Series

ENGLISH



Charging point

Charging terminals

1. Packing List

- AI Smart Glasses × 1
- Charging Cable × 1
- User Manual × 1

2. Product Overview

- 1. Speakers: Audio output.
 - 2. Touch Zone: Located on the right temple.
 - 3. Right Button:
 - Press & hold for 3 seconds: Power On / Off.
 - Video / Photo Control.
 - 4. Left Button:
 - AI Voice Assistant / Recording Switch.
 - Factory Reset: Press and hold for 10 seconds.
 - 5. Camera
 - 6. Fill Light
 - 7.
 - Alternating Red & Blue: Powered on and in Bluetooth pairing mode.
 - Solid Blue: Audio or video recording is active.
 - Solid Red: Charging / System busy.
 - Solid Blue (when charging): Fully charged.
 - 8. Microphone Hole
 - 9. POGO PIN
- Charging Port (POGO PIN)

3. Charging Your Glasses

- 3.1 Ensure the POGO pins on the charging cable align correctly with the charging terminals on the glasses.
- 3.2 Plug the standard USB end of the cable into a certified power source.

4. App Installation & Pairing

- 4.1 Power On: Put on the glasses, then press and hold the right button for 3 seconds. You will hear a prompt tone from both speakers, and the indicator light will flash red and blue.
- 4.2 Download App: Search for "EYEKE" in the Apple App Store or Google Play Store to install, or scan the QR code below using your mobile browser.
- 4.3 Pairing: Open the EYEKE App, go to Settings, select "Add Device", and click on your glasses to connect.
- 4.4 Unbinding: To unbind, remove the device within the App settings. *Note for iOS users: You must also go to your iPhone's Bluetooth settings and select "Forget This Device".*



5. Operating Instructions

5.1 Photography

- Button Control: Short press the right button once.
- Voice Command: Wake up the AI and say "Take a photo".

5.2 Video Recording

- Button Control: Double-click the right button to start; single-click it again to stop and save.
- Voice Command: Wake up the AI and say "Start recording". Click the right button to stop.

5.3 Audio Recording

- Button Control: Double-click the left button to start; single-click it again to stop and save.
- App Control: Open the app, enter the "Transcription" interface, and tap "Start Recording". Tap again to stop.

5.4 Media Import & Management

- Importing Media: After recording, tap the "Import" button on the App homepage to establish a Wi-Fi

connection and sync your photos, audio, and videos to your phone. You can then view them in the App or your local photo album.

- File Operations: The latest files will appear as previews on the homepage. Tap to view directly. Tap "View All" to browse the full library, and tap "Select" for single or batch selection to delete or share files.

5.5 Conversation Translation

- Language Setup: Select the respective languages for both the glasses wearer and the phone user in the App.
- Speaking via Glasses: Talk normally; the glasses will automatically record your voice and display the real-time translation on the phone screen.
- Speaking via Phone: The other party holds down the button on the App to speak. The system will translate their speech into your language, broadcast it through the glasses speakers, and display the text on the App.




5.6 Live Translation

- Best for conferences, presentations, or continuous single-speaker translation.
- How to Use: Wear the glasses, tap "Start" in the App, and select the target language. The glasses will automatically capture the audio, display real-time text translation on the App, and provide voice broadcast via the speakers.



5.7 AI Dialogue & Object Recognition

- AI Dialogue: Say the wake word "小艾, 小艾" (or "Hey, Alice" in English), or short-press the left button to activate the AI assistant. Ask questions like "What's the weather like today?" or "What are some fun places in Hong Kong?". Detailed text responses can be viewed in the App's chat dialog.



- Object Recognition: Activate the AI and ask "What's in front of me?". The glasses will automatically take a snapshot, identify the object or scene, and read out the description through the speakers.



5.8 Hands-Free Voice Calls

- Answer Call: Double-tap the right touch zone when a call comes in.
- Reject / Hang Up: Press and hold the right touch zone.



5.9 Media Control

- Control playback using the right touch zone during music streaming:
- Volume Up: Swipe forward on the touch zone.
 - Volume Down: Swipe backward on the touch zone.
 - Play / Pause: Double-tap the touch zone.
 - Next Track: Triple-tap the touch zone.

5.10 Settings & Reset

- App Settings: In the App Settings, you can configure device connection/unbinding, photo/video aspect ratios, video duration, recording resolution, ambient light, recording length, and prompt sound settings. You can also view device info, perform firmware OTA upgrades, or reset the device.
- Factory Reset: Press and hold the left button for 10 seconds. This will clear all local data, reset the glasses, and put the device back into Bluetooth pairing mode.

50 mm

Federal Communications Commission (FCC) Statement.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.