


ERDRAGE




Mouse for e-Sports

Quick Start Guide


Please read this user manual carefully before using the product.

01 / Product Details

Brand:	CRDRAKO
Model:	KO-1
Colors:	Black/White/Purple
Switch:	Huano Transparent Shell Pink Dot Switch
Encoder:	TTC Gold
Sensor:	PAW3950
Resolution (DPI):	Up to 30,000
Speed (IPS):	750
Acceleration (G):	50
Polling Rate (Hz):	Up to 8,000Hz
Processor:	32-bit ARM
Customization Option:	Customizable Sensor Settings/Keys/Macros
Cable:	USB-C Data Cable
Operating Systems:	WINDOWS, MAC, LINUX (WINDOWS 7 or Higher Version)




02/Key Function Description



- ① Left Button
- ② Right Button
- ③ Middle Button
/Scroll Wheel
- ④ Forward Button
- ⑤ Backward Button
- ⑥ Charging Indicator Light

- A. Low battery status: Mouse indicator light flashes (red light)
- B. Charging status: Mouse indicator light breathes (yellow light)
- C. Fully charged status: Mouse indicator light stays on (green light)




- ⑦ PAW3950 Sensor
- ⑧ Power Indicator Light
- ⑨ Power Switch

A. ON position: Push the switch left to (○) to turn on the power


B. OFF position: Push the switch right to (×) to turn off the power

03/Mouse Size Diagram




2.44in | 62mm

43.9in | 1116mm



(~37g)



1.45in | 37mm

04/Instructions for Pairing the Wireless Receiver

USB Wired Mode:

When the mouse is connected via a TYPE-C cable, it will automatically switch to wired mode and begin charging.

2.4G Wireless Mode:

1、How to use 2.4G mode:

Push the power switch on the bottom of the mouse to ON (this activates 2.4G mode).

Note: The 2.4G receiver is pre-paired at the factory.


2、How to pair the 2.4G receiver:

In 2.4G mode, when the mouse indicator light flashes (purple light), it means the mouse is in the pairing mode.

Please connect in wired mode, open the web-based driver, go to the homepage, then click the "Pairing Tool" button to start pairing.

- ①Unplug the 2.4G receiver from your PC.
- ②Put the mouse in pairing mode: Press and hold the left, middle, and right buttons on the same time for 3 seconds until the pairing indicator light start to flash.
- ③Reconnect the 2.4G receiver to your PC USB , then move the mouse nearby the receiver.

2.4G Receiver Diagram:



① DPI Button ② Polling Rate Button ③ CE Mode Switch

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

ISED Statement

- English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux CNR exempts de licence d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

(1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé.

Cet équipement doit être installé et utilisé avec une distance minimale de 0 cm entre le radiateur et votre corps.