

说明书

29mm

155mm

Beifa AI

PEN

AI 智能 翻译 电容笔

外观示意图

硬件规格说明

规格	参数
型号	AI PEN 02
外观颜色	冰雾白
产品尺寸	Ø9.1×168mm
内置电池	锂电池, 型号60400, 容量=90mah
充电接口	TYPE C
输入电源	5V = 1A
通讯方式	蓝牙
工作时长	6-8h
工作温度	0~40℃

包装清单

AI智能翻译电容笔、充电线、皮套、笔尖替换头、说明书

快速入门

开机：
双击触摸按钮，设备开机，在手机蓝牙清单中出现“Beifa AI-Pen 02”，点击进入蓝牙配对状态，LED灯闪烁，配对成功后，灯灭，代表已成功连接手机。

连接：
1.请扫描二维码下载应用并完成安装

2.初次使用请授予APP运行必要的许可证，以确保设备正常运行
3.APP右上角出现“Beifa AI-Pen 02”，说明连接成功

一键翻译：
打开APP首页，按住触摸按钮，绿灯常亮，开始讲话翻译，松开按钮绿灯熄灭，停止翻译。

跨系统翻译：
打开APP首页，开启“跨系统翻译”，就可以进入第三方社交软件（如微信、WhatsApp、line等），按住触摸按钮，绿灯长亮，开始讲话翻译，松开按钮绿灯熄灭，停止翻译。

注：在苹果手机上，完成翻译后，ios系统会弹出提示框，询问是否允许黏贴。

对话翻译：
打开APP，点击“AI秘书”，点击“对话翻译”，选择翻译语言，按住语音喇叭开始说话翻译，松开停止翻译。

拍照翻译：
打开APP，点击“AI秘书”，点击“拍照翻译”，选择翻译语言，拍照后自动翻译。

AI秘书：
打开APP，点击“AI秘书”，选择翻译语言，开始录音。录音结束后保存。语音可形成文字、总结和思维导图。

同声传译：
打开APP，点击“AI秘书”，点击“同声传译”，选择翻译语言，开始同声翻译。

电容笔功能：
双击触摸按钮，设备处于开机状态，即可使用电容笔功能（注：开机后即使没有连接蓝牙，没有使用翻译功能，电容笔功能也可用）本产品具有智能省电模式，如果只是单独使用电容笔功能，30分钟后会自动关机，如需继续使用，需要重新开机。

其他说明

充电功能：
插上充电器，开始充电，充电状态下，当电量出于0-25%、25%-50%、50%-75%、75%-99%时，对应第一、二、三、四个灯闪烁，电量充满时，所有绿灯常亮。

低电量报警功能：
1.低电量报警：当电池电压低于3.3V时，长按触摸按钮翻译时，红灯常亮，提醒用户电池低电量，需要充电。
2.低电量关机：当电池电压低于3V时，强制关机。

自动回连功能：
设备关机，再重新开机后，设备会自动回连上次成功连接过的手機。

关机机制，以下4个条件，均会关机：

- 1.双击触摸按钮，设备强制关机。
- 2.插入充电器，设备优先进入充电模式，自动关机。
- 3.当电池电压低于3V时，自动关机。
- 4.设备开机后蓝牙未连接或连接后无操作30分钟自动关机。

注意事项

使用本产品之前，请先仔细阅读以下安全提示，以确保正确使用并避免可能的安全隐患。

- 1. 请勿使用损坏或未经品质检测的充电器，以防火灾、爆炸或其他危险。
- 2. 请将设备及所有配件放在儿童无法接触的地方，以免发生误食窒息或其他安全风险。
- 3. 本设备不防水，请避免设备与水接触，以免导致设备损坏。
- 4. 请勿重摔、焚烧、挤压或以其他方式损坏设备，以免影响正常使用或引发危险。
- 5. 请勿将产品暴露在高温处、发热设备周围如烤箱、微波炉等；使用非官方认可的配件造成的品质问题，设备故障及安全事故，由用户自行承担，我司概不负责。

使用方法：见说明书
执行标准：Q/NBF 152
质检证明：合格
品牌商：文蔚库（宁波）品牌管理有限公司
制造商：贝发集团股份有限公司
地址：宁波北仑小港纬六路68号
售后电话：4001152189

产品保固卡

尊敬的用户：
感谢您选购本公司产品。为了方便提供您保固服务，请填写真填此卡以便日后凭此卡维修。本凭证为商品三包的重要依据，请妥善保管。

·姓名：
·电话：
·产品型号：
·购买日期：
·购买通路：
·设备MAC：

保固说明

- 1.请妥善保管此卡，保修时需出示此卡及购买凭证。
- 2.产品自购买之日起，凡按照产品说明书正常使用，一年内出现故障可免费维修。
- 3.下列情况不属于免费服务范围，但可实行收费维修服务：
 - (1)不能出示保修卡及发票。
 - (2)发票涂改。
 - (3)意外因素或使用不当造成损坏。
- 4.未经我司许可，自行修理造成的损坏。
- 5.超过三包有效期，经修复仍可继续使用。对于超过保修期的产品，本公司将继续为您提供有偿服务。

正面

Beifa AI

PEN

AI 智能翻译电容笔

User Manual

I Schematic diagram

① Touch Button

② type-c

③ Indicator Light

④ NIB

II Specifications

Specifications	Parameters
ITEM No.	AI PEN 02
Colour	White
Size	Ø9.1×168mm
Built in battery	Lithium battery, model 60400, Capacity=90mAh
charging port	TYPE C
input power	5V = 1A
contact method	Bluetooth
Working hours	6-8h
working temperature	0-40℃

III Packing list

- 1.AI Pen
- 2.Charging Cable
- 3.Leather Case
- 4.Replacement Core/Refill
- 5.User Manual

IV Get started

Power On:

Double-tap the touch button to power on the device.In your mobile's Bluetooth list, locate "Beifa AI-Pen 02 ".Tap to enter Bluetooth pairing mode.The LED indicator will flash.Upon successful pairing, the light will turn off, indicating a successful connection to your mobile.

Connection:

1.Please scan the QR code to download and install the application.

2.For first-time use, please grant the necessary app permissions to ensure normal device operation.

3.When "Beifa AI-Pen 02" appears in the upper-right corner of the app, it indicates a successful connection.

One-Key Translation:

Open the APP home page, press and hold the touch-sensitive button. When the green light stays on steadily, you can start speaking for translation. Release the button to turn off the green light and stop translation.

Cross-System Translation:

On the APP homepage, enable "Cross-System Translation" to use the feature within third-party social applications (e.g., WeChat, WhatsApp, LINE). Press and hold the touch-sensitive button—a steady green light indicates translation has begun. Release the button to turn off the green light and stop translation.

Note: On iPhone, after completing the translation, the iOS system will display a dialog box asking for permission to paste.

Conversation Translation:

Open the app, tap "AI Translation", tap "Conversation Translation", select the translation languages, press and hold the speaker icon to start speaking for translation, and release to stop translation.

Photo Translation:

Open the APP tap "AI Translation", tap "Photo Translation", select the translation languages, take a photo, and the system will translate it automatically.

AI Secretary:

Open the APP tap "AI Translation", tap "Voice Notes", select the translation languages, and start recording. Save after recording ends. The voice can be converted into text, summarized, and formed into a mind map.

Simultaneous Interpretation:

Open the APP tap "AI Translation", tap "Simultaneous Interpretation", select the translation languages, and begin simultaneous interpretation.

Capacitive stylus functionality:

Double-tap the touch button to activate the device.The capacitive stylus function will then be available. (Note: This function remains operational even when Bluetooth is disconnected or the translation feature is inactive.)This product incorporates an intelligent power-saving mode.When using solely the capacitive stylus function, the device will automatically power down after 30 minutes.To resume operation, restart the device.

V Other instructions

Charging Function:

Plug in the charger to commence charging. During charging, when the battery level is within the ranges of 0-25%, 25%-50%, 50%-75%, and 75%-99%, the first, second, third, and fourth indicator lights will flash respectively. When fully charged, all green lights will remain steadily illuminated.

Low Battery

Alert Function:

- 1.Low Battery Alert: When the battery voltage drops below 3.3V, the red light will stay on continuously during long-press translation using the touch-sensitive button, reminding the user that the battery is low and requires charging.
- 2.Low Battery Shutdown: When the battery voltage drops below 3V, the device will perform a force shutdown.

Automatic Reconnection Function:

When the device is powered off and then turned on again, it will automatically reconnect to the phone that was last successfully paired.

Shutdown Mechanism Under any of the following 3 conditions, the device will shut down:

- 1.Double-click the touch button to force shutdown.

- 2.When the charger is plugged in, the device will prioritize entering charging mode and automatically shut down.
- 3.Automatic shutdown when the battery voltage drops below 3V.
- 4.After powering on, the device will automatically switch off after 30 minutes of inactivity if Bluetooth remains unconnected or no action is taken following connection.

VI Precautions

Before using this product, please carefully read the following safety warnings to ensure proper operation and avoid potential hazards.

1. Do not use damaged or uncertified chargers to prevent fire, explosion, or other dangers.
2. Keep the device and all accessories out of the reach of children to prevent risks such as accidental ingestion, choking, or other safety hazards.
3. This device is not waterproof. Avoid contact with water to prevent device damage.
4. Do not severely drop, burn, crush, or otherwise damage the device, as this may affect normal use or cause hazards.
5. Do not expose the product to high temperatures or near heat-generating appliances such as ovens or microwave ovens. Users shall bear full responsibility for any quality issues, device malfunctions, or safety incidents caused by the use of non-officially certified accessories. Our company assumes no liability.

Usage: See instructions
Execution standards: Q/NBF 152
Quality inspection certificate: qualified

Brand Owner: VANCH(NINGBO) BRAND MANAGEMENT CO.,LTD.
Manufacturer: BEIFA GROUP CO., LTD.

Add: No. 68, Weiliu Road, Beilun District, Ningbo
Tel: 4001152189

Product Warranty Card

Dear Valued Customer:

Thank you for choosing our product. To facilitate warranty services, please fill out this card carefully. This document will serve as an important basis for future repairs under the warranty. It is also a key proof for the "Three Guarantees" policy. Please keep it safe.

·Name: _____

·Phone: _____

·Product Model: _____

·Purchase Date: _____

·Purchase Channel: _____

·Device MAC: _____

反面

100g白纸折页(一面中文一面英文)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.