


HISONG RX Plus User Manual

An Enhanced Wireless Audio Receiver with Multi-Function Interfaces

Powered by HISONG ZeroSync™ wireless technology.

Multi-interface support enables synchronized audio output to cameras or mixers while maintaining precise sync with IEMs (with only 0.9 ms latency deviation).



1. Auto-Connection

- Powers on and automatically pairs with the S1 main unit (ensure the S1 is powered on).

2. Power Button

- Long press (2 seconds): Power on / off.
- Status:

White flashing: Waiting for connection

Green light: Connected & real-time volume metering

3. USB-C Interface(Side)

- Used for charging the RX Plus (standard 5V USB-C power input).

4. 3.5mm Headphone Output

- Designed for low-impedance outputs.
- Usage: Connect to active speakers, mixer line inputs, etc.

5. OUT 3.5mm TRS Audio Output

- Optimized for high-impedance inputs.
- Usage: Connect to camera microphone inputs, etc.


6. USB-C Hot Shoe Connector (Mobile phones recommended; compatible with desktop devices)



- Supports Standard USB Recording.
- Supports Video Recording Audio.
- Supports Live Stream Input.
- Note: Supports USB-C to USB-A / Lightning adapters.

7. Camera Cold Shoe Mount

1.



- Used to secure the RX Plus onto a camera cold or hot shoe mount.

8. Volume + / - Buttons

- Adjusts RX Plus output volume (synchronizes both USB-C and 3.5mm TRS output levels).


9. HISONG RX Plus Pairing Guide

- Before using a newly purchased RX Plus, the RX Plus must be paired with the charging case.
- Please follow the instructions below to complete the pairing process.

Pairing Procedure

1. On your mobile device, open the HISONG Link app.

Go to Settings → Device → Pair RX Plus to enter the pairing page.



2. Press and hold the Volume “+” and Volume “-” buttons on the RX Plus simultaneously.


Keep holding until the indicator light alternates between red and green, indicating that the RX Plus has entered pairing mode.



3. Once the RX Plus is in pairing mode, tap PAIR on the Pair RX Plus page.

1.

When “Pairing Successful!” appears on the screen, the RX Plus has been successfully paired with the charging case.



Notes:

- 1、Pairing is required only for first-time use or after a factory reset.
- 2、During pairing, keep the RX Plus close to the charging case.
- 3、Do not disconnect or power off the RX Plus during the pairing process.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.