



产品使用说明书

产品介绍

纳米级芳香精油雾化器，能够百分百保存芳疗精油功效，通过雾化能在更大空间体验芳香，芳疗，比传统香炉，芳疗扩散载体使用时间长，拥有定时功能适合个人生活习惯，让您的生活空间增添舒适宜人的气味。

产品结构经过精心设计，呈现扇形雾化效果有效提升扩散效果，彻底雾化精油，不堵塞，不积液，颗粒均匀，扩散迅速。

全新设计的PCB控制面板，极简风格，操作快速上手，方便使用。

注意事项

使用设备前请详细阅读本使用说明书，并妥善保管。

- ▲ 请勿使用过期的电源插座，定期检查连接线或适配器，否则可能危及您的安全为避免火灾风险若有发现请及时更换。
- ▲ 如果设备不能技术人员迅速不要试图修改、拆卸、维修设备以免设备损坏。如果设备发生异常，请联系最近的服务工程师或维修中心，故障排除时请进行维修。若不能解决请及时与经销商联系
- ▲ 设备使用时不可倒置、倾斜。若设备需要连接到其他系统，请针对设备进行保养（详见设备维护），方可正常使用。避免精油堵塞其他流量
- ▲ 请定期对设备进行维护和维护，确保设备保持最佳工作状态。

产品特点

雾化孔

雾化头

密封圈

精油瓶

时间设置按钮

电源灯按钮

开关按钮/蓝牙按钮

底座按钮

产品参数

产品名称: 香机	产品型号: M202B	额定输入: DC5V
尺寸: 58x110x340mm	精油容量: 100ml	额定功率: 4W
产品重量: 1.189kg	重量: 1.5kg	材料: 铝合金
覆盖面积: 1000m²	噪音: <38db	
包装尺寸: 398x150x132mm		



控制面板

一、长按按钮打开，进入上次模式，默认模式为睡眠模式，有三个档位

1档：一档白天亮，一档工作灯，一档工作灯，一档工作灯

2档：一档白天亮，一档工作灯，一档工作灯，一档工作灯

3档：一档白天亮，一档工作灯，一档工作灯，一档工作灯

二、有设置，最亮设置，电压个时间段。

需按 8 小时，12 小时，24 小时

需按 8 小时一档白天亮

需按 12 小时一档白天亮

需按 24 小时一档白天亮

需按 8 小时一档白天亮

需按 12 小时一档白天亮

需按 24 小时一档白天亮

三、【蓝牙连接模式】

1. 使用手机扫描二维码或扫描 Scent Diffuser app 下载 app

2. 打开手机蓝牙连接设备

3. 打开手机蓝牙，搜索设备，连接设备，连接设备后 app 即可开始操作

蓝牙连接模式

电量不足或无电时

1. 设备在无电或电量不足时关机，所有灯同时闪烁 3 次

2. 无电时


3. 电量不足 30% 时，三个档位指示灯闪烁提示。

电量为 30% 60% 以下时，第一个档位灯亮，第二个档位灯亮，第三个档位灯亮。

电量为 60% 以上时，第一个档位灯亮，第二个档位灯亮，第三个档位灯亮。

电量为 30% 以下时，三个档位灯同时亮。

遥控器



设置运行时间：

遥控器可以对香味浓度，工作时间及开关机进行设置，方便使用和延长使用寿命。

(ON) 设备开启按键，按下可以开启香机。

(OFF) 设备关闭按键，按下可以关闭香机。

(AROMA) 在工作状态下，按下恢复出厂设置，默认程序为 8H。

雾化量最大。

(Low) 低浓度，(Med) 中等浓度，(High) 高浓度


(8h) (12h) (24h) 在工作状态下，按下按钮设置需要的时间长短

8h=按下设备工作8小时

12h=按下设备工作12小时

24h=按下设备工作24小时

安装指南



1. 旋转取出雾化头。
2. 旋转取出精油瓶，并加入精油。
3. 装上雾化头，并开始设置。

操作提醒

1. 连接电源，成功从电池电源充电。
2. 通电开机默认待机，小时键按8小时/短按右边小时键切换工作小时

故障排除

在开始使用设备之前，请首先按照以下方法尝试解决以下问题

问题故障	解决方案	问题故障	解决方案
设备不工作	请检查电源是否连接正确，请检查设备是否正常工作，请检查设备是否正常工作	雾化量小	请检查设备是否正常工作，请检查设备是否正常工作
雾化量小	请检查设备是否正常工作，请检查设备是否正常工作	雾化量小	请检查设备是否正常工作，请检查设备是否正常工作

故障排除

为了帮助您快速解决故障，请按照以下步骤进行故障排除。

1. 检查设备是否正常工作，请检查设备是否正常工作
2. 检查设备是否正常工作，请检查设备是否正常工作
3. 检查设备是否正常工作，请检查设备是否正常工作
4. 检查设备是否正常工作，请检查设备是否正常工作

APP使用说明书：

1. 扫描封面二维码或机器背面二维码APP下载安装。
2. 打开Scent Diffuser 智能APP界面，点击WiFi (如图1所示)
3. 点击搜索出来设备 (如图2所示)



设备列表

设备名称: Scent080002

模式: 运行 - 工作 0s - 停止 0s

时间: 开始 00:00 - 结束 00:00

电源开关: 100%

模式设置: 图4

点击模式设置添加工作模式 (如图5)

工作设计模式：



选择工作星期

上下滑动调节

上下滑动调节

图5



APP下载

使用前请先根据您购买的版本仔细阅读说明书！



USER MANUAL

Product Introduction

Nano aromatherapy essential oil atomizer, preserve 100% aromatherapy essential oil efficiency, adds a pleasant smell to your living space.

The newly designed PCB control interface features a minimalist style, ensuring quick and easy operation for user convenience.

Attention:

Before using the equipment, please read this user manual carefully and keep it properly.

- ▲ Do not use overloaded power sockets, damaged power cables, or adapters, as it may endanger your power line and safety.
- ▲ If you are not a technical professional, do not attempt to modify, dismantle, or repair the equipment to avoid damage.
- ▲ During use, do not invert or tilt the equipment. Please package the essential oils and the machine separately before transportation.
- ▲ Regularly maintain and clean the equipment to ensure it remains in optimal working condition.

Product Features

Atomizing Hole

Atomizing Head

Sealing Ring

Oil section pipe

Essential oil bottle

Time Button

Analog Light Button

Bluetooth Button

Base Rubber Pad

Product parameter

Product Name : Aroma Diffuser	Product Model: M202B
Product Size : 58x110x340mm	Oil Capacity : 100ml
Rated input: DC5V	N.W : 0.9kg G.W : 1.5kg
Rated Power: 4W	Coverage Area: 1000m²
Noise: <38db	Material: PP +aluminum alloy
Packaging Size : 398x150x132mm	




Control Panel

1. Connect to power, press the power button 3 seconds to turn on; press the power button briefly to adjust the grade.
2. Press the time button 3 seconds to turn the ambient light on or off.
3. Chime-on/light features: White -> Purple -> Blue -> Green cycling breathing light mode. Short press the button to select color for continuous illumination. When a single color is continuously lit, short pressing the button again switches back to the four-color changing mode. Pressing the button twice in quick succession adjusts the light brightness. There are three brightness levels: high, medium, and low. Long press the button to turn off the light.
4. Bluetooth Connection: 1) Scan the QR code with your phone or search "Scent diffuser" on Google to download the app. 2) Open the app and select Bluetooth login without a password. 3) Open the device list, search for the device, connect to it, and enter the app adjustment page to operate.

V. Battery Low and Charging Instructions:

When there is no power or the battery is low, Power-off reminder: All lights flash simultaneously for 3 times. After powering off due to no power, it is impossible to turn on the device again. Pressing the power-on button will only remind you that there is no power. You need to plug in the electricity before you can turn it on again.



Set the operating time period:

The remote control allows for the flexible adjustment of the fragrance concentration, the working duration and the auto-off function. This not only makes the use more convenient but also extends the life of the equipment.

(ON) The device starts working. Pressing it will turn on the device.

(OFF) The device starts working. Pressing it will turn off the device.

(AROMA) When in operation mode, press to restore factory settings. The default program is 8H, with the maximum concentration and concentration of 100%.


1. Low concentration, 100% concentration, 100% concentration.

8h -> Operating the equipment for 8 hours.

12h -> Operating the equipment for 12 hours.

24h -> Operating the equipment for 24 hours.

Installation Guide:



1. Rotate to remove the atomizer head.
2. Twist to take out the bottle, and fill it with oil.
3. Attach the atomizer head and proceed with the setup.

Operation Reminder

1. Please connect the power or ensure the battery is fully charged.
2. When powered on, the digital display (LED) button indicates 8 hours of operation. Pressing it briefly will reset the working hours in Bluetooth mode.

Troubleshooting

When operating, report the equipment status to the following issues using the following methods.

Problem	Solutions	Problem	Solutions
The device is not working	Please check if the power is connected correctly. Check if the power is connected correctly. Check if the power is connected correctly.	Oil leakage	Check if the atomizer head is damaged. Check if the atomizer head is damaged. Check if the atomizer head is damaged.
No oil or weak mist	Check if the oil is added correctly. Check if the oil is added correctly. Check if the oil is added correctly.	Abnormal noise	Check if the atomizer head is damaged. Check if the atomizer head is damaged. Check if the atomizer head is damaged.

Troubleshooting

In order to ensure the best effect, please check and maintain the equipment every six months.

When it is necessary to replace the essential oil, the oil should be replaced in the equipment. The equipment should be replaced in the equipment.

Maintenance steps:

1. Connect the power and ensure the battery is fully charged.
2. When powered on, the digital display (LED) button indicates 8 hours of operation. Pressing it briefly will reset the working hours in Bluetooth mode.
3. After powering on, the digital display (LED) button indicates 8 hours of operation. Pressing it briefly will reset the working hours in Bluetooth mode.
4. After powering on, the digital display (LED) button indicates 8 hours of operation. Pressing it briefly will reset the working hours in Bluetooth mode.

App Download



Google Play

Android

Notice: Please scan the QR code on the left to download the app. If you are unable to download it, please try scanning the QR code on the right.

Google Play Download Application: <https://play.google.com/store/apps/details?id=com.im.scentdiffuser>

Bluetooth Connection

Open the app and press the "Bluetooth login free" button

Login

Sign In

Email/ Tel: 1591476301

Password: Enter Your Password

Forgot Password

Login

Bluetooth login free

Select the device

Device list (Bluetooth)

Search device name (Please)

Scent033224

Enter the machine operation interface

Device name: Scent033224

Spraying Status & Countdown

Run 57% Stop 60s

Time 06:00 - 22:00

DC Pump Line

Daily Start Time Daily End Time

Power switch

Fan switch

Add Spray Mode

Mode set

Tap to Change Spray Mode

Model

Run 60s Stop 60s Time 06:00-22:00

Week

Set Spray Mode

Click to change the working mode

Week: Click to change each week

Time settings

Set daily end time

Set the fragrance spraying time

Set the spray duration

Run settings

Set the pause time after each spray

Cancel Confirm

FCC Radiation Exposure Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.