

M10(QZ)香薰机说明书157g铜板纸 风琴折页
20260613Ver1.0



Product Introduction

This aromatherapy device features an aluminum alloy shell, which is sturdy, durable and premium in texture. With a minimalist and stylish appearance, it perfectly blends with all kinds of scene styles. It supports dual control modes: physical button control and Bluetooth control. Adopting two-fluid aromatherapy atomization technology, it delivers precise, stable and wide-range fragrance diffusion. It creates diverse fragrance atmospheres for daily life, and is widely applicable to homes, offices, villas, KTVs, exhibition halls, shopping malls, 4S stores, hotels, airports, health spas and more.

Precautions

Please read this user manual carefully before using the device and keep it properly for future reference.

1. Do not use overloaded power sockets, damaged power cords or adapters, otherwise it may endanger personal safety and cause fire hazards. Replace them immediately if any damage is found.

2. Non-professional personnel shall not attempt to modify, disassemble or repair the device, so as to avoid damage. If the device malfunctions, please check whether it is operated in accordance with standard instructions or follow the troubleshooting guide. If the problem remains unsolved, contact the seller in a timely manner.

3. Do not invert or tilt the device during operation. If the device needs to be transported to another location, please perform maintenance and cleaning first (see Device Maintenance for details). Essential oil must be completely emptied before packing and transportation to avoid oil leakage and damage to the device.

4. Maintain and clean the device regularly to ensure it stays in optimal working condition.

Special Instructions for Essential Oil Use

1. Before refilling essential oil, stop the device for 2 minutes. Wait for the essential oil to flow back, then unscrew the oil bottle.

2. Do not overfill beyond the maximum capacity of the oil bottle when refilling. Overfilling may cause essential oil splashing or device malfunction.

Precautions for Use

PAGE 002

Parameters

Product Name	Aroma Diffuser	Input Voltage	DC 5V-2A(Type-C)
Product Model	M10	Working Noise	≤38db
Rated Power	1.2W	Battery Capacity	4000mAh
Essential Oil Capacity	100ml	Main Material	Aluminum Alloy
Product Dimensions	Φ105X365(mm)	Package Dimensions	L476xW150xH170(mm)
Net Weight	1203g		

Product Design

Mist Outlet, Atomizing Main Body, Essential Oil Bottle, Working Indicator Light, Type-C Charging Port, Ambient Light, Main Body, Base, Function Button

Accessories

Power Adapter	Power Cord	Product Manual	User manual
---------------	------------	----------------	-------------

PAGE 003

封面

WARNING

Built-in battery inside the product. To avoid hazards, only use an official charger. Do not use the battery if it gets wet. Do not disassemble, impact, squeeze or throw it into fire. Stop using the battery immediately if it bulges or deforms. Do not place the battery in high-temperature areas; do not disassemble, pierce, squeeze, heat or burn it. To prevent damage from long-term idle storage, charge the battery regularly.

Maintenance

To ensure better fragrance diffusion effect, please inspect and maintain the device at least once every six months. Maintenance is also required when replacing with a new fragrance or when the scent diffusion effect weakens.

1. Unscrew the empty essential oil bottle.

2. Pour an appropriate amount of alcohol into the bottle and clean it thoroughly.

3. After cleaning, pour in a small amount of alcohol, install the bottle back to the device, and turn on the device to run for 5 to 8 minutes.

4. Turn off the power after cleaning is completed.

Troubleshooting

Before arranging equipment maintenance, please follow the methods below to troubleshoot and resolve common problems first.

Fault Description	Solution
Device does not work	① Please check if the power adapter is USB DC5V-2A, and ensure the Type-C and USB plugs are inserted correctly. ② Check the device working program to confirm whether it is within the set working time.
Oil leakage	① Check whether the essential oil bottle and atomizer head are tightly screwed. ② Check if the sealing ring of the atomizer head is deformed or damaged. ③ Check whether the atomizer head is damaged.
No atomization Weak atomization	① Check if the air pump works normally and whether there is airflow at the mist outlet. ② Check if the atomizing core and oil suction pipe are loose or blocked. (Remove the atomizing core with a tool, clean it with alcohol or cleaning solution, then reinstall and fix it in place.) ③ Check whether the air nozzle sealing ring is damaged, loose or fallen off.
Abnormal noise	① The air pump is loose, please fix it again. ② The air pump is damaged, replace it with a new one.

PAGE 006

Add Essential Oil

1. Rotate the atomizing main body ① counterclockwise, lift up the atomizing main body together with the essential oil bottle ②, and take them out.

2. Grasp the essential oil bottle, rotate it counterclockwise to separate it from the atomizing main body, then add essential oil (max 100ml) ③.

3. Screw the essential oil bottle filled with essential oil clockwise onto the atomizing main body tightly ④.

4. Install the essential oil bottle and atomizing main body into the device main body, then tighten it clockwise. No alignment required ⑤.

5. Set the working time, then the device is ready for use.

Operating Instructions

1. Power Instruction

① Connect the power cord to the power adapter (DC5V-2A).

② Insert one end of the power cord into the Type-C POWER IN port of the device.

③ Plug the power adapter into the wall socket to power on the device.

2. Mode Function:

Press and hold the power key (powermode) for 1.5 seconds to turn on the device. It will enter the default low mode with the LOW icon white light on (10s spray for 15 seconds, pause for 200 seconds).

Press the mode key (powermode) briefly to switch gears; when switching to HIGH mode, the icon white light turns on (10s spray for 60 seconds, pause for 60 seconds).

Press the mode key (powermode) again to switch to Bluetooth mode. Keep pressing the mode key to cycle through modes in sequence. Press and hold the power key for 1.5 seconds to power off the device.

3. Timing function: The device defaults to auto power-off after 8 hours when powered on (except in Bluetooth mode).

Machine Operation Interface

PAGE 004

Operating Instructions

4. Bluetooth Function: Bluetooth Function: Press the mode (powermode) key after power-on to activate Bluetooth connection, and the Bluetooth icon lights up blue * O BT. Please enable Bluetooth and location on your phone. For first use, download and install the APP to bind and connect the device.

5. Light Function (7-color RGB):

① The default light mode is 7-color breathing gradient after power-on, which auto-off in 8 hours by default (except Bluetooth mode).

② Mode switching: Press the light (Light) key once to lock the current color; press again to restore 7-color gradient mode. Press repeatedly to cycle through light modes in sequence.

③ Brightness adjustment: Double-click the light (Light) key quickly to switch among three brightness levels: 100% full brightness, 50% half brightness, and 15% dim brightness.

④ Press and hold the light (Light) key for 1.5 seconds to turn off the light. The light can be turned on or off independently.

6. Charging Indication: When the battery is low, the red light * O BAT flashes 5 times then the device shuts down. During charging, the battery indicator stays solid red * O BAT; when fully charged, it stays solid white. If the voltage is lower, the red light keeps flashing * O BAT. The device will power off automatically when the battery is exhausted, and the red light will flash 5 times then turn off.

Bluetooth Connection:

Press the mode (powermode) key to activate Bluetooth mode, and the Bluetooth icon lights up blue. Enable Bluetooth and location on your mobile phone, connect to the device, open the APP (scan the QR code to download for first use), then bind and operate the device.

Download APP

① Scan the QR code shown below to download with your browser.

② Apple phone users can go to the app store and search for "Aroma Master" to download.

Bluetooth APP

1. Download App for smart phone: scan the following App QR and choose to download app corresponding to iOS or Android system.

2. Press the mode (powermode) key to switch to Bluetooth mode.

3. Turn on Bluetooth mode on your cell phone.

4. Turn on your APP, click the search button "Q" in the upper right corner to connect to the device, and then you can control the diffuse with your smartphone.

Note: One diffuser can only connect to one mobilephone, if others need to connect, the previous person needs to disconnect Bluetooth.

PAGE 005

底面

英文版

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.