

A MOOD PARTNER WHO UNDERSTANDS YOU BETTER!

PRODUCT INSTRUCTION

DOUMAO DiMi

ProductUserManual

PRODUCT OVERVIEW

DiMi, a versatile desktop robot designed for multiple scenarios, upholds the product vision of "Fun AI Interaction & Emotional Companionship".

With rich functions and high-quality hardware configurations, it delivers diversified human-robot interaction experiences and provides emotional support for users.

NETWORKING TUTORIAL

The device supports both 4G and Wi-Fi modes. Please make sure the Bluetooth mode of the device is turned on. The device uses the 4G mobile network by default. (To switch the network mode later, you may go to "More" on the device and select Network Mode to change it.)

1

Power on for the first time / Power on in unbound status:

1. After power-on, the startup screen will display together with DiMi's sound effects.

2. A QR code will appear on the screen. Scan the code to log in to the Mini Program, enter the v-verification code, and bind the device.

*The above is for illustration only. Please scan the exclusive QR code on the device.

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

切换网络模式

A MOOD PARTNER WHO UNDERSTANDS YOU BETTER!

PRODUCT INSTRUCTION

DOUMAO DiMi

ProductUserManual

INSTRUCTIONS

Device Startup

Press and hold the power button for 3 seconds. The indicator light will turn on, indicating that the device has started successfully.

Device Upgrade

Tap the device screen, select Firmware Upgrade in System Settings, and the upgrade will be completed immediately.

Charging Instructions

Please use a Type-C charger and the original data cable for charging.

Open your phone, search for and access the "DouMao AI" Mini Program/Select "DouMao DiMi" to enter. Tap "Add Device" to enter the device SN and verification code, then tap "Confirm" to complete device binding.

Charging Cable

QR Code

2

After binding, wait for the QR animation to play on the device screen. At the same time, the device will announce: "Network connected. You can wake me up by saying 'DouMao DouMao' to interact with me." The device is now ready for normal use.

3

The device defaults to 4G mobile network. If users need to switch to Wi-Fi, they can select Wi-Fi in the device settings and follow the prompts to complete the switch.

Wi-Fi Mode -> 4G Mode

Enter the device settings interface, find and turn on the "Mobile Network" switch.

The system will pop up a prompt "Switching network mode requires restarting the device". Tap "Confirm".

Wait for the device to reboot. After restarting, the 4G mobile network will take effect.

Method 1:

Open the device page in the corresponding Mini Program, tap Wi-Fi, enter the Wi-Fi account and password to complete the network configuration.

Method 2:

On the device's Wi-Fi page, scan the QR code displayed on the screen. You will be redirected to the Mini Program, then follow the prompts to complete the network configuration.

Notes:

The device defaults to 4G mobile network out of the factory and can be used directly after binding.

To configure a Wi-Fi network, go to More Settings to perform the setup.

Only one of 4G or Wi-Fi can be used at a time. Switching between modes requires a restart before the configuration takes effect.

The verification code can be found on the label on the back of the packaging box.

CUTE EXPRESSIONS

DiMi is equipped with over 100 fun expressions in various styles. It flexibly matches animated expressions according to different conversation scenarios, making AI interaction both warm and full of fun.

Standby

Greetings

Cheers!

Coffee

Listening

Birthday

*More expressions waiting for you to unlock

BUTTON INSTRUCTION

1

2

3

4

5

6

7

8

9

10

11

12

1. Camera

2. Touch Sensing Area (both sides)

3. Touch Screen

4. Dual Microphones (both sides)

5. Light Strip

6. Power Button (at 6 o'clock position directly below the sphere)

7. NFC Area

8. Visual Photo Button

9. Conversation Button

10. Mute Button

11. Speaker

12. Type-C Charging Port

MATTERS NEED ATTENTION

1. The device is not waterproof. Please keep it away from any liquids to prevent damage.

2. Please use a Type-C charger for charging.

3. Operating Environment: Use the device in a cool area and avoid direct sunlight to ensure proper performance.

4. Device Temperature: Do not use or store the device in extreme temperatures, as this may cause overheating or excessive cooling.

5. Battery Usage: Use and charge the battery properly. Avoid overcharging to prevent battery damage or fire hazards.

COMMON PROBLEM

1. Device fails to charge

Solution: Please use a 3C-certified charger. The charging port is a standard Type-C port.

2. Device fails to power on

Solution: Please check whether DouMao DiMi has power or is connected to a power supply, and verify that the power button is not stuck.

3. Device fails to connect to the network

Solution: Check if your home network is working properly. If it is, please reconfigure the network (refer to the network configuration process).

4. Inaccurate content recommendations

Solution: Try switching to a different character — the platform provides a large selection of characters. Please also submit your feedback to us.

SPECIFICATION PARAMETER

Product Name: DouMao DiMi

Screen Size: 2.1 inches

Microphone: MEMS microphone

Product Model: DM 03

Display: TFT-LCD

Networking Mode: 4G + Wi-Fi

Product Material: ABS + PC

Resolution: 540 × 540

Product Dimensions: 10010590mm

Rated Input: 5V + 1A

Camera: 2.0 megapixels

Button Mode: 4 mechanical buttons

Battery Capacity: Main unit 780mAh / 3.7V

Base 240mAh / 3.7V

90mm

100mm

product LIST

1

2

3

4

1 x DouMao DiMi AI Robot Main Unit

1 x Rotating Base

1 x Type-C Charging Cable

1 x Product User Manual

AFTER-SALES SERVICE

Warranty Terms: 15-day free replacement for the whole device, one-year warranty (excluding man-made damage).

Contact Person: _____ Phone Number: _____

Purchase Date: _____ Contact Address: _____

Purchase Address / Platform: _____

Remarks of Repair Items: _____

CONTACT US

微信扫码官方账号

微信扫码小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

官方微信小程序

Join us, DiMi — your emotional companion who understands you better!

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.