

VM5267
VM5267-2
5" Video Monitor
with Night Light



Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	Baby unit: 2405 ~ 2475 MHz Parent unit: 2405 ~ 2475 MHz
Channels	32
LCD	5" Color LCD (WQVGA 480x272 pixels)
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
Power requirements	Parent unit: 3.6V, 2600mAh, 9.36Wh Li-ion battery Baby unit power adapter: Output: 5V DC @ 1A Parent unit power adapter: Output: 5V DC @ 1A




Use the menu

Press **Menu** to enter the menu, choose a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.


While in the menu:

- Press **Left Arrow** or **Right Arrow** to scroll among the menu options.
- Press **Menu** to select an item, or to save a setting.
- Press **Up Arrow** or **Down Arrow** to scroll among the sub-menus, or to adjust a setting.
- Press **Left Arrow** to return to the previous menu options without changing the current setting.
- Press **Back/TALK** to return to live video.




The diagram shows a Vtech parent unit on the left with a color screen displaying a menu. To its right is a circular inset showing a close-up of the unit's control buttons. A line points from the 'Press' label to the central button, which is the same 'Menu' button shown in the previous diagram.

Press and hold TALK and speak to your parent unit. Your voice is transmitted to the baby unit. Release **TALK** when finished talking and hear your baby again.



Press **POWER** to turn off the parent unit screen without powering off the parent unit. You will still hear sounds from the baby unit.



CAUTION: Do not install the baby unit at a height above 6.5 feet (2 meters).

CAUTION: This product is intended as an aid. It is not a substitute for reading and following all warnings and instructions marked on the product. Do not use the product without proper adult supervision and should not be used as such.

CAUTION: This product is not intended for use as a medical monitor.

CAUTION: Do not use this product near water, for example, near a swimming pool.


CAUTION: Use only the battery provided (if applicable). There may be a risk of explosion if a wrong type of battery is used for the parent unit. The battery cannot be subjected to high or low temperature and low air pressure at high altitude during use, storage or transportation. Disposal of battery in fire or hot oven, mechanically crushing or cutting the battery may cause the battery to explode. Exposure of the battery to high temperature surrounding environment can result in an explosion or the leakage of flammable liquid of gas. Battery should be stored in a cool and dry place.

 Power adapter information:
Output: 5V DC 1A
VTech Telecommunications Ltd.
Model: VT05EUS05100
-OR-
Jiangxi Jian Aohai Technology Co.,Ltd
Model: A318-050100W-US2


9. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

- For pluggable equipment, the socket-outlet (power adapter) should be installed near the equipment and should be easily accessible.
11. Use the product from the wall outlet before cleaning.
Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
12. Do not modify the power adapters or replace with other adapters, as this causes a hazardous situation.
13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped.
14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power source available at your home, consult your dealer or electricity supply provider.
15. Do not overload wall outlets or use an extension cord.
16. Do not place this product on an unstable table, shelf, stand or other surface.
17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back and sides of the product are for ventilation. These slots and openings protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a rug or on a table top. The product should never be placed near or over a radiator or heat source.
18. Never push objects of any kind into this product through the openings. If they do, the object may be damaged or cause a short circuit. Never spill liquid of any kind on the product.

Press **VOL - / VOL +** to adjust your parent unit speaker volume.



Press **Arrow keys** **←**, **↑**, **↓** or **→** to pan and tilt the Baby Unit.




The diagram shows the handset from two perspectives. The left view shows the front of the handset with the antenna at the top. The right view shows the back of the handset, highlighting the battery pack and charging port. Numbered callouts identify the following components:

- 1: Antenna
- 2: 3-level sound indicator light
- 3: Battery LED light
- 4: LINK LED light
- 5: Arrow keys <V> <V>
- 6: MENU / SELECT key
- 7: RETURN / TALK key
- 8: LCD off / POWER key
- 9: VOL - / VOL + keys
- 10: Power jack
- 11: RESET button
- 12: Speaker

The parent unit turns on automatically after connecting the power adapter to the power socket and the battery LED light illuminates.

 NOTES

- The rechargeable battery in the parent unit is built-in.
- Use only the power adapters supplied with this product.
- Make sure the parent unit and the baby unit are not connected to an electronically controlled electric power outlet.
- Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets.
- Make sure the parent unit, the baby units and the power adapter cords are out of reach of children.



The diagram illustrates the features of the VTech DECT 6.0 parent unit from three perspectives: front, back, and top. The front view (left) shows the display and controls, with callouts 1 through 6. The back view (middle) shows the speaker, temperature sensor, and power jack, with callouts 7 through 9. The top view (right) shows the mounting slots, with callouts 10 and 11.

1 Night light key • Tap to turn on/off the night light. 2 Light Sensor 3 Camera lens 4 Infrared LEDs 5 Microphone 6 Night light	7 PAIR key • The parent unit and baby unit provided are already paired. 8 Speaker 9 Temperature sensor 10 Power jack 11 Slots for wall mounting
--	--

For operations and guides to help you use your video monitor, and for the latest information and support, check out our online help topics and online FAQs.

Use your smartphone or mobile device to access our online help.

- Go to <https://help.vtechphones.com/vm5267> or <https://help.vtechphones.com/vm5267-2>; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to be redirected to the online help page.
 - If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

You can also call our Customer Support at 1 (800) 595-9511 [in US] or 1 (800) 267-7377 [in Canada] for help.

VM5267

VM5267-2

Charge the parent unit battery

When you have connected and turned the parent unit on, the battery charges automatically.

NOTES

- Before using the baby monitor for the first time, charge the parent unit battery for 12 hours. When the parent unit battery is fully charged, the battery icon segments are solid .
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.
- The standby time varies depending on the sensitivity level you set, your actual use and the age of the battery.

The battery icon indicates the battery status (see the following table).

BATTERY INDICATORS	BATTERY STATUS	ACTION
The screen displays  and  . The  light flashes.	The battery has very little power and can only be used for a short time.	Charge without interruption (about 30 minutes).
The battery icon segments are solid  .	The battery is fully charged.	To keep the battery charged, connect the unit to AC power when in use.

- 1 Connect the baby unit to a power supply to turn it on. Disconnect the baby unit to turn it off.
- 2 Press and hold **POWER** to power on or off your parent unit.

1 CAUTION

- Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or playpen.

2

3

NOTE

- To avoid interference from other electronic devices, place your baby monitor at least 3 feet (1 meter) away from devices such as wireless routers, microwaves, mobile phones and computers.

CAUTION

- The default volume of your parent unit is level 4, and the maximum volume is level 7. If you experience feedback noise from your baby monitor while positioning:
 - Make sure your baby unit and parent unit are more than 3 feet (1 meter) apart, OR
 - Turn down the volume of your parent unit.


Once you power on both your baby unit and parent unit, your parent unit displays image from the baby unit, and the **LINK** LED light turns on.

Use the menu

Press **Menu** to enter the menu, a menu item, or save a setting. You can use the parent unit for advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound sensitivity.


While in the menu:

- Press **Left Arrow** or **Right Arrow** to scroll among the menu options.
- Press **Menu** to select an item, or to save a setting.
- Press **Up Arrow** or **Down Arrow** to scroll among the sub-menus, or to adjust a setting.
- Press **Left Arrow** to return to the previous menu options without changing the current setting.
- Press **Back/TALK** to return to live video.




Talk to your baby unit

Press and hold **TALK** and speak to your parent unit. Your voice is transmitted to the baby unit. Release **TALK** when finished talking and hear your baby again.




Turn off the screen

Press **Screen Off/POWER** to turn off the parent unit screen without powering off the parent unit. You will still hear sounds from the baby unit.



Tip

- Press any key on the parent unit to turn the screen on again.



Adjust parent unit volume

Press **VOL - / VOL +** to adjust your parent unit speaker volume.

Pan and Tilt the Baby Unit

Press **Arrow keys** **◀ ▲ ▼ ▶** to pan and tilt the Baby Unit.

OVERVIEW - PARENT UNIT

- Antenna
- 3-level sound indicator light
- Battery LED light
- LINK LED light
- Arrow keys **◀ ▲ ▼ ▶**
- ≡** MENU / SELECT
- ↶** RETURN / TALK
- ⏻** LCD off / POWER key
- VOL - / VOL +**
- Power jack
- RESET
- Speaker

The diagram illustrates the VM5267 video monitor from three perspectives: front, back, and internal components. The front view shows the lens and display area with callouts 1 through 6. The back view shows the mounting slots and sensors with callouts 7 through 9. The internal view shows the battery and wiring with callouts 10 and 11.

1 Night light key 2 Light Sensor 3 Camera lens 4 Infrared LEDs 5 Microphone 6 Night light	7 PAIR key 8 Speaker 9 Temperature sensor 10 Power jack 11 Slots for wall mounting
---	---

Main menu	Sub-menu	Main menu	Sub-menu	Main menu	Sub-menu
Brightness Adjust the parent unit's LCD brightness.		ON/OFF Turn on/off the adaptive night light feature. When this feature is on, the baby unit detects the ambient light. If the room is bright, the night light adjusts itself to be brighter; if the room is dim, the night light adjusts itself to be dimmer.		Temperature 	ON / OFF - Turn on/off temperature alert tone. - Set the parent unit to beep whenever the room temperature detected by the baby unit falls outside of the set temperature range.
Lullaby 	Play/Stop lullaby ≈ 1 ≈ 2 ≈ 3 ≈ 4 1 2 3 4 5 - Select one of the soothing sounds. - Select one of the five melodies. Play all melodies. 60min 45min 30min 15min OFF - Set timer to stop playing the selected melody or soothing sound.	Screen off Timer OFF 5min 30min 60min Screen off Timer The parent unit screen will turn off after the selected time to save energy. You can still hear your baby while the screen is turned off.		Baby Unit Settings Baby unit speaker volume - Adjust the baby unit's speaker volume. + 2X 1X - Zoom in.	
Night Light 	ON/OFF Turn on/off night light 1 2 3 4 5 6 7 - Select one of the night light colors. - Change to all seven colors in cycle. 60min 30min 15min OFF - Set a timer to turn the night light off. OFF - Set the night light to be always on. AUTO - Set to turn on the night light automatically when baby unit detects sounds exceed a set level. It will turn off after 15 minutes if the sound detected is lower than the set level. You can set Sound sensitivity level to detect sounds that exceed set levels. See Sound sensitivity and sound activation section.	Alert Tone Settings - Set the parent unit to beep when the battery is low. - Set the parent unit to beep when the link between the parent unit and the baby unit is lost. - Set the confirmation tone on or off when selecting an option in the menus. - Set the parent unit to beep when the baby unit detects sounds while in Split mode (For pairing with VM5267-2 only).		Monitoring Mode (For pairing with VM5267-2 only) 1 2 Single CAM mode The screen displays images only from the selected baby unit in full screen. Split mode The screen displays images from all the paired baby units at the same time in split view. Patrol mode The screen displays a single cam view that transitions to a different baby unit every 10 seconds.	

PARENT UNIT ICONS (CONT'D)

Status icons



Connection status

- Strong signal strength.
- Moderate signal strength.
- Low signal strength.
- Weak signal strength.



Split mode

(*For pairing with **VM5267-2** only)



Patrol mode

(*For pairing with **VM5267-2** only)



Current view status

- The baby unit number that is being viewed when in:

- Single CAM** mode.
- Patrol** mode (For pairing with **VM5267-2** only)
- Split** mode (For pairing with **VM5267-2** only)



Night vision - On



Zoom - On



Lullaby - On



Night light - On

Alert icons



- Displays when parent unit's battery is low and needs charging.



- Displays when connection between parent unit and baby unit is lost.



- Displays when sound is detected at a baby unit when in **Split** view. (For **VM5267-2** only)



- Baby unit detects temperature reaches or exceeds the set maximum.



- Baby unit detects temperature is at or is lower than the set minimum.

Status icons



Night light - Auto-on

- Color icon indicates the night light is set to auto-on, and is currently turned on by sound activation.
- White icon indicates the night light is currently off but is set to auto-on. Night light will turn on when sound is detected by the baby unit.

°F or °C

Real-time temperature

- Real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. **57°F** or **14°C**).



Temperature alert tone - On



Talkback - On



Mute alert

- Displays when the parent unit speaker volume is set to off.
- Displays when the parent unit is talking to the baby unit.



Battery status

- animates when the battery is charging.
- battery is fully charged.
- battery is low and needs charging.

SOUND SENSITIVITY AND SOUND ACTIVATION

Adjust the sound sensitivity of the baby unit


The parent unit screen will turn on only when the detected sounds exceed a set level.

Use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds that transmit to the parent unit. The sound sensitivity level is preset to the highest level.

SOUND SENSITIVITY LEVEL	Level 5 (Highest)	Level 4 (High)	Level 3 (Medium)	Level 2 (Low)	Level 1 (Lowest)
DESCRIPTION	The parent unit screen turns on for quiet sounds, (including background noises) from your baby's room.	The parent unit screen turns on for soft babbling and louder sounds from your baby. It remains off when your baby sleeps soundly.	The parent unit screen turns on for loud babbling and louder sounds from your baby. It remains off when your baby makes soft sounds.	The parent unit screen turns on for crying and louder sounds from your baby. It remains off when your baby makes soft sounds.	The parent unit screen turns on for loud crying or screeching sounds from your baby. It remains off when your baby makes soft sounds.


When **AUTO** is selected, the parent unit screen stays off to save power when the baby unit detects sounds that are lower than the set sensitivity level.

Once the baby unit detects sounds that are louder than the set sensitivity level, the parent unit screen turns on automatically. It will then turn off again after 50 seconds if the sounds detected are lower than the set sensitivity level.




DIM MODE

Dim mode helps you save parent unit power. Your parent unit display will automatically dim after 10 minutes of inactivity, when no keys are pressed or alerts are received from the baby unit.



NIGHT VISION



The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and appears on the screen.

NOTES

- It is normal to see a short white glare on your parent unit screen when the baby unit adapts to the dark environment.
- When the infrared LEDs are on, it is normal for the images to be in black and white.

TIP

- Depending on the surroundings and other interfering factors, for example, lighting, objects, colors and backgrounds, the image quality may vary. Adjust the baby unit angle or place the baby unit at a higher location to prevent glare and a blurred display.


FOR VM5267-2 ONLY



Change different views - Single CAM

To switch between the image of baby units 1 and 2:


- Press .
- Enter **Monitoring mode** menu.
- Select the baby unit you would like to view 1 or 2.



Change different views - Patrol



Select **Patrol** as your monitoring mode to alternately view the image from baby units 1 and 2 every 10 seconds.



Change different views - Split



Select **Split** as your monitoring mode to view the images from both baby units at once.



FREQUENTLY ASKED QUESTIONS

Below are the questions most frequently asked about the baby monitor.

Why does the baby monitor not respond normally?	Try the following (in the order listed) for common cure: 1. Disconnect the power to the baby units and the parent unit. 2. Wait a few seconds before connecting power back to the baby units and the parent unit. 3. Turn on the baby units and the parent unit. 4. Wait for the parent unit to synchronize with the baby units. Allow up to one minute for this to take place.
Why doesn't the baby unit and parent unit power-on/light illuminate when the units are switched on?	Perhaps the parent unit is not connected to the power. Insert the adapter plug into the parent unit and put the adapter in a wall socket. Then, press and hold POWER to switch on the parent unit and to establish connection with the baby unit. Perhaps the baby unit is not connected to the power. Insert the adapter plug into the baby unit and put the adapter in a wall socket to establish connection with the parent unit.
Why doesn't my parent unit charge while connected to AC power?	Make sure the power is not controlled by an electronically controlled electric power outlet. The battery may be degraded through extended use or defective. See Warranty for repair/replacement.
Why is my screen in black and white?	The screen is in black and white during night-time or in a dark room when the night vision feature is activated. This is normal.
Why do I get glare or blurry display on my screen when viewing my baby at night?	During night-time or in a dark room, the surroundings and other interfering factors, like lightings, objects, colors and backgrounds may affect the image quality on your parent unit screen. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.
Why does the baby monitor produce a feedback noise?	The parent unit and baby units may be too close to each other. • Move the parent unit away from the baby units until the noise stops; OR • Turn down the volume of your parent unit.
Why does the parent unit beep?	The baby units may be out of range. Move the parent unit closer to the baby units (but not less than 3 feet). The parent unit may not have enough charge for the parent unit to perform normally. Charge the battery in the parent unit until the battery icon segments are solid The temperature of your baby's room may be too high or too low.
Why does the parent unit react too quickly to other sounds?	The baby unit also picks up other sounds than those of your baby. Adjust the sound sensitivity level to a lower level or lower the parent unit speaker volume.
Why don't I hear a sound/Why can't I hear my baby cry?	The parent unit speaker volume may be too low, press VOL + to increase the volume. You may have set a low sound sensitivity level. See Adjust the sound sensitivity of the baby unit to set to a higher level.
Why can't I establish a connection? Why is the connection lost every now and then? Why are there sound interruptions?	The baby units may be out of range. Move the parent unit closer to the baby units (but not less than 3 feet). Other electronic products and wireless products may cause interference with your baby monitor. Try installing your baby monitor as far away from these devices as possible. If you power on only one baby unit, your parent unit may display , and the LINK LED light will flash.

MOUNT THE BABY UNIT (OPTIONAL)





Not Included

You will need to purchase the following items separately to mount your baby unit:

- 2 screws
- 2 anchors

NOTE

- The types of screws and anchors you need depend on the composition of the wall.



THE RBRC SEAL

The RBRC seal on the Li-ion battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada.

The program provides a convenient alternative to placing used Li-ion batteries into the trash or municipal waste, which may be illegal in your area. VTech's participation makes it easy for you to drop off the spent battery at local retailers participating in the program or at authorized VTech product service centers. Please call **1 (800) 8 BATTERY** for information on Li-ion battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

The **RBRC Seal** and **1 (800) 8 BATTERY®** are registered trademarks of Call2recycle, Inc.

FCC and IC REGULATIONS

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The baby unit shall be installed and used such that parts of all persons' body are maintained at a distance of approximately 8 in (20 cm) or more. The transmitter and antenna of the parent unit shall be held at least 1 in (2.5 cm) from your face.

This Class B digital apparatus complies with Canadian requirement:

Industry Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

RF radiation exposure statement

The product complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The baby unit should be installed and operated with a minimum distance of 8 in (20 cm) between the baby unit and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of Humans to RF Fields.

CALIFORNIA ENERGY COMMISSION BATTERY CHARGING TESTING MODE

This baby monitor meets the California Energy Commission (CEC) regulations for energy consumption. Your baby monitor is set up to comply with the energy-conserving standards right out of the box. Follow the instructions to install and charge the battery. The CEC battery charging testing mode is activated while charging. Even if the parent unit is paired to baby units, the CEC battery charging testing mode is activated while it is powered off and charging.

DISCLAIMER AND LIMITATION OF LIABILITY

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.
Company: VTech Communications, Inc.
Address: 9020 SW Washington Square Road • Ste 555 Tigard, OR 97223, United States
Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

FOR CETL COMPLIANCE ONLY

Mesures de sécurité importantes

La plaque signalétique appliquée est située au bas du socle de l'unité du bébé. De même, ne le positionnez pas à proximité ni au-dessus d'une source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit avant de vous assurer qu'il y ait une bonne circulation d'air.

- N'enfoncez jamais d'objets à travers les ouvertures de cet appareil, car ils pourraient entrer en contact avec des points de tension dangereux ou causer des courts-circuits qui peuvent déclencher des incendies ou en risquer d'électrocution. Ne renversez jamais de liquide dans ce produit.
- Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, mais apportez-le dans un centre de service autorisé. L'ouverture du boîtier ou le retrait de toutes pièces que contient cet appareil, à l'exception de l'accès autorisé à certaines portes ou ouvertures, risque de vous exposer à des points de tension dangereux ou d'autres dangers. Un remontage incorrect peut par la suite présenter des risques d'électrocution.
- Vous devriez tester la réception chaque fois que vous mettez l'appareil en fonction.
- Examinez les composantes afin de vérifier si celles-ci ne sont pas endommagées.
- Il existe un très faible risque de perte de confidentialité avec certains appareils électroniques (autres écoute-bébés, téléphones sans fils etc.). Pour l'éviter, s'assurer que le produit n'a jamais été utilisé avant l'achat, réinitialiser l'unité de façon périodique, éteindre l'écoute-bébé quand il n'est pas en cours d'utilisation.
- Les enfants devraient être supervisés afin de vous assurer qu'ils ne jouent pas avec l'appareil.
- Le produit n'est pas conçu pour être utilisé par des personnes (incluant des enfants) aux capacités physiques, sensorielles ou mentales réduites ou qui manquent d'expérience et de connaissances, à moins qu'on leur ait donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.

CONSERVEZ CES INSTRUCTIONS
This limited warranty does not cover:
1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or
4. Product to the extent that the problem is caused by use with non-VTech accessories; or
5. Product whose warranty/quality stickers, product serial number or plates or electronic numbers have been removed, altered or rendered illegible; or
6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
7. Product returned without a valid proof of purchase (see item 2 below); or
8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside of the unit.

Mises en garde
1. Utilisez et entreposez le produit à une température entre 0° C (32° F) et 40° C (104° F).
2. N'exposez pas cet appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de chaleur.
3. Le bloc-piles ne doit pas être exposé à la chaleur excessive telle que la lumière du soleil ou au feu.

⚠ Avertissement - Risque de strangulation
Les enfants se sont ÉTRANGLES dans des cordons. Gardez ce cordon hors de portée des enfants (à plus de 0,9 m). N'enlevez pas cette étiquette.
Ne jamais placer le moniteur à l'intérieur du berceau ou du parc de bébé. Ne jamais couvrir le moniteur ou l'unité(s) portative avec un article tel une serviette ou une couverture.

⚠ D'autres équipements électroniques peuvent produire des interférences sur votre moniteur vidéo et audio. Testez d'installer votre moniteur vidéo ou audio à l'écart des appareils électroniques tels que des routeurs sans fil, radios, téléphones cellulaires, interphones pour support de bloc d'alimentation et le maintenir en place si celui-ci est branché dans une prise au plafond, sous une table ou dans un tiroir. Débranchez ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettoyants en aérosols. Utilisez un chiffon humide pour le nettoyer.

⚠ Ne coupez pas les cordons d'alimentation pour remplacer les fiches. Car ceci peut présenter un danger potentiel.
Ne laissez aucun objet reposer ni appuyer sur le cordon d'alimentation. N'installez pas cet appareil dans un endroit où l'on risque d'écraser le cordon d'alimentation ou de le piétiner.
Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur l'étiquette. Si vous ne connaissez pas le type d'alimentation que vous possédez à votre domicile, consultez votre marchand ou votre compagnie locale d'électricité.

⚠ Ne surchargez pas les prises de courant murales ni les rallonges électriques.
Ne placez pas cet appareil sur un chariot, meuble, trépied, support de montage ni table chancelants.
Les trous et ouvertures du boîtier, situés à l'arrière de l'appareil ou sous celui-ci, servent à aérer l'appareil. Pour l'empêcher de surchauffer, ne bloquez sous aucun prétexte ces ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le

CABLE MANAGEMENT

