




# UVS10W

## OWNER'S MANUAL

In-Car Phone Sanitizer  
with Wired and Wireless Phone Charging

Powerful Sanitizing  
in just 5 Minutes



### Using the Sanitizer



Place your phone in the sanitizer, centered on the four plastic legs and close the lid. Press the button on the top of the lid to sanitize and the light will turn Red. Light will turn off when complete after 5 minutes.

*Magnetic switch in lid prevents unit from turning on when open.*



Your phone will be bathed by 8 UV-C LED's to completely clean all the surfaces.

### One-Year Limited Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Dual Electronics Corp. warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase. Dual Electronics Corp. agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period. Who is covered? This warranty is extended to the original retail purchaser for products purchased from an authorized Dual dealer and used in the U.S.A. What is covered? This warranty covers all defects in material and workmanship in this product. The following are not covered: software, installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific license conditions and copyright notices for the software can be found via [www.dualav.com](http://www.dualav.com).

#### What to do?

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.
2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service center.
3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.
4. For more information and for the location of the nearest authorized service center please contact us by one of the following methods:
  - Call us toll-free at 1-866-382-5476 (Monday-Friday, 9:00 am, to 5:00 pm, EST) or
  - E-mail us at [cs@dualav.com](mailto:cs@dualav.com)

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental or consequential damages.

### FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### Powering Up the Sanitizer

#### Product Information

1. Power Button
  - Light will turn Blue while charging
  - Light will turn Red when sanitizing
2. Wireless Charging Area
3. USB-C Power Cable Input (cable included)



Use the supplied USB-C cable and 12V adapter for in-car use.

Use your USB power adapter to power the sanitizer for in home use.

### Wired and Wireless Charging



Wireless Charging (with compatible phones)  
Place your mobile phone in the center of the charging area.  
Blue light = charging.  
Blue light off = fully charged.  
Blue Blinking = Remove non-chargeable object from top of wireless charger.  
(Phone cases thicker than 3mm may need to be removed for wireless charging.)



Wired Charging  
Plug your phone charging cable into the 12V adapter and place your phone inside the sanitizer. To also sanitize while charging, close the lid and press the button on top.

### Specifications and Features

**General**  
Dimensions : 9.3" (W) x 5.7" (D) x 2.3" (H)  
Weight: 1.6 lbs.  
Color: Gray  
Materials: ABS+PC (plastics) and Silicon Pad  
12V Power Adapter : 5V/2A  
USB-C Charging Cable Length : 4.9 ft.  
Certificates: FCC, RoHS  
Operating temperature from -4° F to 158° F

**Wireless Charger Specifications**  
Wireless Charger Output:

- Apple devices up to 7.5W
- Android devices up to 10W

The charging current will automatically adjust the power according to the requirements of the mobile phone. Once the phone is fully charged the wireless charger will automatically switch off.

**Specifications**  
Input Voltage: 5V, 9V, 12V Wireless  
Charging output: 5W、 7.5W、 10W、 15W

**UV Sanitizer**  
UV-C LED (8 TOTAL): Broad Beam Sterilizing with 160° Dispersion per LED at 230nm-280nm wavelength.

Sanitizing Time : Push sanitizer button once - 5 minutes.

#### Warning:


Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Contact us for help

Dual Electronics Corp.  
Toll Free: 1-866-382-5476  
Monday-Friday, 9AM-5PM EST  
[www.dualav.com](http://www.dualav.com)

©2020 Dual Electronics Corp.  
All rights reserved.

NSA0720  
Printed in China



Ultraviolet (UV) light may cause eye damage.  
Do not look directly at the light. If you experience any discomfort or pain, stop using the UV Sanitizer and contact your physician.

SAVE THESE INSTRUCTIONS