

Instruction for Model: BE-059

Getting Started

FM MIC

1. Open Battery Compartment by Screwdriver.
2. Insert two "AA" batteries, checking the + and - ends of the batteries. We recommend do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
3. Screw backs the battery door.

We recommend

- Do not mix old and new batteries.
- Removing batteries if unit is not used for more than 30 days.

Radio

1. This FM MIC needs a radio for receiver. We recommend you to use a high sensitivity analog turning radio at the receiver.
2. Turn on your radio and set it to FM band and the BE-059 FM MIC. The Power ON LED on the MIC will turn on.
3. Talking to the FM MIC and then turn your radio station turner until you can listen your voice.
4. You may necessary to fine turn your radio station after when you are walk away to the radio.

Maintenace

Cleaning the Cabinet

Take cares to keep the unit clean and dry. You may clean the cabinet with mild soap and water.

Trouble Shooting

Problem	Probable Cause	Remedy
Distorted of fuzzy sound	Weak Batteries	Replace with new Alkaline or rechargeable Batteries

If problems persist, please do not attempt to repair unit; see warranty for factory service.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiator radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off an on, the user is encouraged to try to correct the interference by one or more of the following measure:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.

Questions or Comments

- ☎ For questions or comments regarding this or other products, please call our toll free number:
1-800-777-5206