

Attachment 1

➤ Test Setup Photograph

<Conducted Emission>

Test Mode : Mode 1: Transmit_Adapter 1

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Transmit_Adapter 1

Description : Back View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit_Adapter 2

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit_Adapter 2

Description : Back View of Conducted Emission Test Setup



<Radiated Emission>


Test Mode : Mode 1: Transmit_Adapter 1

Description : Front View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 1: Transmit_Adapter 1

Description : Back View of Radiated Emission Test Setup (Bilog)




Test Mode : Mode 2: Transmit_Adapter 2

Description : Front View of Radiated Emission Test Setup (Bilog)




Test Mode : Mode 2: Transmit_Adapter 2

Description : Back View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 1: Transmit_Adapter 1

Description : Front View of Radiated Emission Test Setup (Horn)



Test Mode : Mode 1: Transmit_Adapter 1

Description : Back View of Radiated Emission Test Setup (Horn)

