

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions contained in this manual, may cause harmful interference to radio and television communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- RE-ORIENT OR RELOCATE THE RECEIVING ANTENNA
- INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND THE RECEIVER
- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT OF THE RECEIVER
- CONSULT THE DEALER OR AN EXPERIENCED AUDIO/TELEVISION TECHNICIAN

NOTE: Connecting this device to peripheral devices that do not comply with Class B requirements for radio or television reception, could also result in harmful interference to radio or television reception.

The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. To ensure that use of this product does not contribute to interference, it is necessary to use shielded I/O cables.

Canadian Department Of Communication Notice

Canadian Department Of Communications (DOC) label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protection, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Copyright

This manual is copyrighted with all rights reserved. No portion of this manual may be copied or reproduced by any means. While every precaution has been taken in the preparation of this manual, no responsibility for errors or omissions is assumed. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Installation

Mouse model : SZU800A, SZU800A, AZU800A and AZU800A

A) System Requirement

IBM PC or compatible computer with a RS-232 (or PS2), USB port and a 3 1/4" floppy driver.

All brand names and registered trademarks mentioned are property of their respective owners.

B) Hardware Install

1. Turn off the power of your computer. Disconnect another mouse installed and locate an empty 9-pin D-sub connector from AQM/mouse (serial mouse) to the RS-232 port, or connect the USB port connector from AQM/mouse USB mouse to the USB mouse port.
2. Tighten the screws and secure the connection.
3. Turn the power on to start your computer.
4. Driver Install (After finish the "Hardware Install" as showed above)
 - It's recommended that you remove other mouse control program and reboot your computer before following installation steps.

Windows 3.1

1. Start Windows (C:\>WIN).
2. Open the "Program Manager" window (Alt + TAB).
3. Pull down the "File" menu (Alt + F), and type R to open RUN dialog box.
4. Insert the AQM/mouse Driver disk to you driver A (or B).
5. Type A:\WINDOWSETUP in the command line and press ENTER(↵).
6. Follow the directions / steps on the screen and use default settings by just pressing ENTER. Change the settings if necessary.
7. Be sure to remove the disk from the driver as the install program indicates.
8. The install program will restart your computer and then the AQM/mouse works.

Windows 95

1. Start Windows 95.
2. Pull-up "Start" menu (Ctrl + ESC).
3. Select "RUN" by arrow keys (↑) or type R.
4. Insert the AQM/mouse Driver disk to you driver A (or B).
5. Type A:\WINDOWSETUP in the command line and press ENTER(↵).
6. Follow the directions / steps on the screen and use default settings by just pressing ENTER. Change the settings if necessary.
7. Be sure to remove the disk from the driver as the install program indicates.
8. The install program will restart your computer and then the AQM/mouse works.