


V5 Speedracer Touchscreen QSG
Folded size: 5.6875” W x 5.125” H
TRI-FOLD, 4-5C glossy finish



Outside View		
Inside info-graphic key pg (pg 2)	Back Page	Cover
Operating specifications: Temperature: 32° to 122°F (0° to 50°C) Indoor use only Power source AC power plug AC power input: 100-120V, 60Hz, 0.8A DC power output 12V, 2.0A Backup battery: rechargeable lithium-ion Open-source software notice For information about the open-source code under GPL, LGPL, MPL and other open-source licenses that are contained in this product, please visit help.adt.com/s/article/adt-open-source. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download. Warranty For warranty details, visit: help.adt.com/s/article/warranty Company address ADT LLC 1501 Yamato Road Boca Raton, FL 33431 Questions? Give us a call at (888) 392-2039 or visit us at i.adt.com/touchscreen where you can also find the complete owner’s manual.	 ©2023 ADT LLC. All rights reserved. ADT, the ADT logo, 800.ADT.ASAP and the product/service names listed in this document are marks and/or registered marks. Unauthorized use is strictly prohibited. Third-party marks are the property of their respective owners. License information available at www.ADT.com/legal or by calling 800.ADT.ASAP. CA ACO7155, 974443, PPO120288; MA 7164C; NC Licensed by the Alarm Systems Licensing Board of the State of North Carolina; 2736-CSA, 2381-CSA; NY 12000305615, 12000261120; PA 090797; MS 15019511. 23.13.11 04042023	 Touchscreen Quick Start Guide

Inside View			
Pg 1 - welcome & set up	Pg 3 & 4 (hidden until graphic page opened)		
Welcome to ADT We're honored to know you trust ADT to help protect the people and things you value most in life. The ADT 8" LCD touchscreen is a wall-mounted, easy-to-use device for convenient control of your ADT security system. You can arm, disarm, access alerts, see system status, view your system history, and a handy panic button provides quick action for police, fire, or medical emergencies. Setting up your ADT Touchscreen 1. Press the power button to turn on the touchscreen. 2. Connect to a Wi-Fi network. 3. Log into an existing ADT+ account. 4. If prompted, select the location of the touchscreen. Note: ADT system must be installed and connected before touchscreen setup. Do not attempt to remove the touchscreen from the wall. For more detailed setup and troubleshooting information, see the complete owner's manual at i.adt.com/touchscreen or scan the QR code below. 	Important safety information 1. Read and keep these instructions. 2. Clean only with a dry cloth. 3. Set up in accordance with the manufacturer's instructions. 4. Do not set up near any heat sources such as radiators, heat registers, stoves or other devices (including amplifiers) that produce heat. 5. Only use attachments/accessories specified by the manufacturer. 6. The device should not be exposed to dripping or splashing water. Items filled with liquids, such as vases or hoses, should not be placed on or near the device. 7. Disposing of your device and old battery: ADT is committed to environmental protection and sustainability. We strongly encourage you to recycle your device and old battery in accordance with local waste and recycling laws. The device and battery cannot be disposed of with regular household waste. Please visit call2recycle.org and, in the "Find a recycling location" field, enter your ZIP Code to find your nearest battery recycling facility. 8. Do not drop the device or subject it to physical shock. 9. Do not use high-voltage products around this device (e.g., electrical swatter) as this product may malfunction due to electrical shock. 10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where it exits from the device. 11. Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply may cause damage to the device and void your warranty. 12. Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades, with one wider than the other. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. 13. WARNING: This product contains chemicals known to the State of California to cause cancer and congenital disabilities or other reproductive harm. Wash hands after handling.		Regulatory approvals FCC statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation. FCC radiation exposure statement • This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. • This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 7.87 in. (20 cm) between the radiator and your body. Note: FCC information can be found on the back of the device.