



**MANUAL FOR INSTALLATION
AND OPERATING INSTRUCTION**

SAMJUNG PORTABLE ILLUMINATION	INSTRUCTIONS FOR USE	MODEL : SS-430
PRODUCT FEATURES ■ Energysaving lamp This table stand use an energysaving FPL 27W Lamp The lamp has the same light as a 100W ordinary lamp bulb, but uses only 20% of the energy and lasts 8 times longer. The FPL 27W lamp gives off cool and pleasant task lighting. Comfortable for your eyes. ■ The SAMJUNG IC inverter luminaire is equipped with an electronic one-touch switch which turn the lamp on/off with the lightest pressure. It also ignites the lamp immediately without flickering and gives off a pleasant electronic beep when touched. ■ Electronic ballast The electronic ballast makes the lamp operate more efficiently and is less tiring for the eyes than a conventional ballast. ■ Adjustable range : Light distribution is easily regulated by moving the arm up/down. The shade can also be tuned up/down and from side to side.		
		
 1. Shade 2. Arm 3. Body 4. Power plug 5. Lamp 6. Operating point 7. ON/OFF switch 8. Base		
120V 50/60Hz FPL27W EX-N		

INSTALLATION INSTRUCTIONS

1. Assembling the SS-430



Remove the large screw under the luminaire body




Attach the base to the body




Use a screw driver(coin) to tighten the screw)

2. Insertion of the lamp




Hold the lamp in one hand and support the shade with the other
Push the lamp into the lampsocket until your hear a click



Push the lamp into the shade

3. For replacement of lamp



Pull the end of the lamp gently downwards.
Pull it out of the socket

4. Movement of the arm

Of SS-430 can be tightened or loosened by using hand to adjust the screw the base.

5. Insert the plug

6. Switch on the luminaire

7. To maximise lighting benefits

PRECAUTION/IMPORTANT NOTICE

- Use the luminaire in a dry place :do not cover
The electronic switch is very sensitive and can activate spontaneously in extreme heat or humidity. Therefore avoid contact with wet towels and/or paper and do not use thermal blankets or heaters close to the luminaire.
- Disconnecting the plug
When disconnecting the plug from the power supply socket, pull the plug gently out . Do not pull the cord.
- Radio interference
Like other electronic equipment, the luminaire may react and cause disturbance to radio reception. Avoid using the luminaire close to the radio.
- Do not use for ambience temperature over 35 °C
This luminaire has a safety fuse which prevents overheating. Operating temperature is from 5-35 °C. If the room temperature exceeds 35 °C, the luminaire will automatically switch off.
- Keep the lamp shade in horizontal position
Avoid staring directly on the lamp when in use as it can cause discomfort to your eyes.
- Do not use strong chemical detergent
sprays to clean the luminaire as they may cause discolouration.

