




Installation Instructions



- 1) Turn all power off to the lamp or fixture
- 2) Remove shade, bulb and harp.



- 3) Remove bulb and adapter from package
- 4) Screw fluorescent bulb and adapter into lamp socket. **DO NOT OVER TIGHTEN.** Gently adjust (loosen) adapter if harp interference is encountered.



- 5) Replace harp and shade.

Replacement for fluorescent bulb only

- 1) Turn all power off to the lamp or fixture.
- 2) Remove shade and harp
- 3) Unscrew and remove fluorescent bulb and adapter from lamp or fixture
- 4) Replace with new **LightWave** fluorescent bulb and adapter.
- 5) Screw fluorescent bulb and adapter into lamp socket
- 6) Replace harp and shade.

Can be used with open or enclosed ceiling fixtures, long chain (swag) lamps and portable table lamps. Minimum starting temperature 0°F. Best performance if operated at 77°F ambient temperature.

CAUTION: Use indoors and do not use in wet location or room (bathroom, shower room, etc.). This device not intended for use with emergency exit fixtures or emergency exit lights. To prevent risk of fire or product damage, do not use this adapter on dimming circuits, electronic timers or photo cells. Added weight of fitting may cause instability of free standing portable lamps. Use only in portable lamps in which the distance from the bottom of the base to the top off the lamp holder does not exceed three (3) times the base width. Use only with portable lamps which are provided with lamp shades.

NOTE: This equipment has been tested and found to comply with the limits for a RF lighting device pursuant to part 18 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular instantiation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- 1) reorient or relocate the receiving antenna
- 2) increase the separation between the equipment and the receiver
- 3) connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4) Consult the dealer or an experienced radio / TV technician for help.