

LB55963T/R

LB**tech**


INSTRUCTION MANUAL

1


Setup and use your digital video baby monitor

Installing Baby Unit

A. Place Baby Unit on a flat surface, such as a desk or shelf or mount the camera on a wall.




B. Connect the small plug of the power adapter to the Baby Unit and the other end to a suitable electrical outlet. Only use the enclosed adapter (5V DC 1000mA). Press and hold “” button till green power LED is turned on to turn on baby unit.



C. Connecting the power supply for the Parent Unit.

Connect the small plug of the power adapter to the parent unit and the other end to a electrical outlet. Only use the enclosed adapter (5V DC/1000mA). Recommend charging time of at least 3 hours before first use.




2

Precaution: use of battery for Parent Unit

Only charge the battery when the battery life indicator is low. Constant recharging of your battery before the low battery indicator light comes on will decrease the life of your batteries.

When battery is low, the power on off LED (icon) will flash red and on screen display battery icon will flash red indicating that the battery needs to be charged.

Video Baby Monitor-Monitor LB55963R



Notice:

If you use the parent unit for the first time, when you turn on the parent unit, some boot menus will pop-up on the screen, we try to explation status and function on these menus, please according to the tips to switch to the monitor system interface. When you are fimaliar with this monitor, you could switch off these on screen tips in menu.

⚠

WARNING

THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION

- When an AC Adapter is plugged into an electrical outlet, do not the exposed end.
- Test baby monitor before first use, periodically, and when changing location of the baby unit(Camera).
- Do not use monitor near water (Such as bathtub, Sink, etc)
- Keep parent unit away from heat sources (Such as stoves, radiators, etc)
- Make sure there is proper ventilation around baby unit and parent unit.
- This product is not a toy. Do not allow children to play with it.
- The mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- The baby monitor should not be considered as a medical device. While using the baby monitor, it is strongly recommended to have an adult directly checking on your baby. Premature babies or children considered at risk must be supervised by your pediatrician or other medical staff.

⚠

Battery Warning

- Use only the original rechargeable battery provided.
- Do not short-circuit supply terminals.
- Remove battery when product is stored for long periods of time or when batt ery is exhausted.
- Dispose of exhausted battery properly.
- Keep all batteries away from children.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.



⚠

WARNING


STRANGULATION HAZARD Children have STRANGLED in cords. Keep this cord out of reach of children (more than 3 feet/1 meter away from the crib). Never use extension cords with AC adapters. Only use the AC Adapters provided.

3

Function of keys and LED indicators



	VOL-	Volume down/up	Press to decrease and increase volume.
	TALK	Talk	Press and hold to talk to baby unit.
	VOX	Power Saving-on/off	Press to switch on/off Power Saving (voice activation mode).
	OK CAM	Select	Menu mode (Press to select menu option)
	▲ ▼	Up/Down	Menu mode (Press to adjust menu settings)
	◀ ▶	Left/Right	Menu mode (Press to adjust menu settings)



Video Baby Monitor-Camera LB55963T

	Power	Press and hold till power LED is turned on to turn on baby unit. Short press to turn off baby unit.
	Pairing button	When camera is powered on, press and hold till power LED starting to blink.

Precautions

- Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- The baby monitor works better in temperature ranging between 0°C and 40°C (32°F and 104°F)
- Do not dismantle the appliance. It does not contain any parts that may be used independently.
- Never Expose the baby monitor for long period to sun's direct rays and never place it next to a source of heat, in a damp or very dusty room.
- Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- The product should be mounted to a wall or ceiling inly as recommended by the manufacturer.

Industry Canada Statement

This device complies with Industry Canada licence-exempt RSS standard. Operation is subject to the following two conditions: (1) this device must not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux condiions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limit set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet équipement est conforme aux CNR-102 d'Industrie Canada. Cet équipement doit êtreinstallé et utilisé avec une distance minimale de 20 centimètres entre le radiateur et votre corps. Cet émetteur ne doit pas être co-localisées ou opérant en conjoncti on avec autreantenne ou émetteur. Les antennes utilisées pour cet émetteur doivent être installées etfourrir une distance de séparation d'au moins 20 centimètre de toute personne et doit pas être co-située ni fonctionner en onjonction avec une autre antenne ou émetteur.

⚠

WARNING

Adult assembly required. Keep small parts away from children when assembling.


⚠

Warning Information

* Keep this instruction manual for future reference.
* For adult use only.

4

Start to use monitor



ADD: Add additional camera.

Step 1: Move the parent unit to the same area as the camera. Both parent and baby unit are switched on.

Step 2: Select ADD in Menu. The next available camera will automatically be highlighted. Press “Select” to begin pairing.

Step 3: Within 10 seconds, press “Pairing button” of camera.

Step 4: Once successfully paired, the camera light will stop flashing and video will appear on the monitor screen within 20 seconds.

Delete: Delete paired camera from the list.

SCAN: Display paired camera one by one.

View: Select and display the camera.

Zoom

Out In

HIGH **High:** Beep Alarm is issued when room temperature is higher than this setting.

LOW **Low:** Beep Alarm is issued when room temperature is lower than this setting.

°C **C:** Display temperature in Celsius scale.

°F **F:** Display temperature in Fahrenheit scale.

Temperature calibration: calibrate room temperature display to your standardized one.

ON **ON:** Activate room temperature alarm function.

OFF **OFF:** Deactivate room temperature alarm function.

Baby's crying sound level

To activate Parent unit from Power saving mode

Activation sound level selection in power saving mode.

AUTO **Auto:** Learning environment sound and activation. Recommend for users having white noise machine, fans and lullabies near by.

Quiet **Quiet:** Baby cry a little bit to activate the Parent Unit.

Medium **Medium:** Baby cry moderate to activate the Parent Unit.

Loud **Loud:** Baby cry louder to activate the Parent Unit.

Audio on or off option in power saving mode: Keep audio continuously on or OFF when screen is off in power saving mode.

Sound Bar: This sound bar is designed for deaf parents to reflect sound level picked up from camera. You can turn visual sound level indication on or off.

Explanation On/Off: We try to explation status and function on the boot menu. You can turn the explanation on or off based on your usage.