


Type No. C19F16110



NEXT

 **ImageQuest**

ImageQuest Q910
Flat & Compact Monitor

User's Guide

V Check
YUNDAl
www.imageQuest.co.kr

U.S.A.

U.S. FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT INFORMATION TO THE USER

NOTE: This equipment has been tested and found to comply with the limits for a

Class B digital device pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet of a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Connecting of peripherals requires the use of grounded shielded signal cables.

DECLARATION OF CONFORMITY

WE

ImageQuest CO., LTD.
Am-ri Bubal-Fub Ichon-Si Kyungki-Do
467-860 KOREA

declare under our sole responsibility that the product:

Kind of equipment : COLOR MONITOR

Type-Designation : C19F16110

to which this declaration relates is, in conformity with the following standard(s) or other normative document(s)

Safety : EN 60950 : 1992 + A1, A2, A3, A4, A11
EMC : EN 55022 : 1998, EN 55024 : 1998
EN 61000-3-2 : 1995 + A1 : 1998 + A2 : 1998
EN 61000-3-3 : 1995

following the provisions of the Low Voltage Directive 73/23/EEC,
93/68/EEC and the EMC Directive 89/336/EEC.

Accredited test laboratory:

TÜV Rheinland
Am Grauen Stein
51105 Köln

KOREA / FEB. 1, 2002

(Place and date of issue)

HONG, KI KIM

(Name and signature of
authorized person)

Hong Ki Kim


Contents



1. Introduction	1/19
2. Safety Information	1/19
3. Installing the monitor	3/19
3-1. Packing List	3/19
3-2. Fastening the swivel and tilt base ..	4/19
3-3. Selecting a suitable location	4/19
3-4. Connecting the monitor	5/19
3-5. Setting the refresh rate	7/19
Preset Timing Table	7/19



4. Adjusting the picture	8/19
4-1. Using the On-Screen-Display	9/19
4-2. Direct access buttons	9/19
4-3. OSD Adjustments	10/19
5. Display power management	15/19
Reducing power consumption	15/19
6. Troubleshooting	16/19
7. Specifications	19/19



1. Introduction

This manual contains instructions for installing and operating ImageQuest Q910.

ImageQuest Q910 is a highly ergonomic color display unit;

- 19" diagonal Flat(18" viewable) 0.25mm dot pitch CDT
- Supporting high screen refresh rates and full scan flicker-free picture quality
- With On Screen Display menus for user control
- 100-240V AC Input voltage
- VESA DPMS (Display Power Management Signaling)
- VESA DDC1/2B compatibility

2. Safety Information

When you set up and use your display unit, follow the safety instructions below.


- Do not use the display unit in humid environments like bathrooms, damp cellars, swimming pools, etc.
- This equipment must be connected to an earthed outlet which is close to the display unit and accessible in case you need to disconnect the display.
- Do not connect an extension cord.
- Never insert objects into the openings on the outside of the device as you can come into contact with live electrical components. This can cause fire or give strong electrical shocks.
- Slots in the cabinet are provided for ventilation. Do not block the ventilation slots in the display unit cabinet.
- Do not under any circumstances open the display unit cabinet.

Cleaning and Maintenance

- To avoid risk of electric shock, do not disassemble the display unit cabinet. The unit is not user-serviceable. Remember to unplug the display unit from the power outlet before cleaning.
- Do not use alcohol (methyl, ethyl or isopropyl) or any strong solvent. Do not use thinner or benzene, abrasive cleaners or compressed air.
- Do not wipe the screen with a cloth or sponge that could scratch the surface.
- To clean your antistatic screen, use water and a special microfiber screen cleaning tissue used in optical lens cleaning, or lightly dampen a soft, clean cloth with water or a mild detergent.
- To clean display unit cabinet, use a cloth lightly dampened with a mild detergent.
- During the transportation of the monitor, the swivel base has to be removed in every case.



3. Installing the
monitor
3-1. Packing List

The following items should be found in the packaging.



i Above power cord can be changed upon different voltage areas. Please contact your dealer if anything is missing or damaged.

3-2. Fastening the swivel and tilt base




- Place the base against the bottom of the monitor so that the base fasteners are aligned with appropriate slots.
- Push the base towards the front of the monitor until the latch locks into position.

3-3. Selecting a suitable location

- Place the monitor at least 30cm from other electrical or heat-emitting equipment and allow at least 10cm on each side for ventilation.
- Place the monitor in a position where no light shines directly onto or is reflected on the screen.
- To reduce eye strain, avoid installing the display unit against a bright background such as a window.
- Position the monitor so that the top of the screen is no higher than eye level.
- Position the monitor directly in front of you at a comfortable reading distance (around 45 to 90cm)

**3-4. Connecting the
monitor**

1 Before you start cabling your monitor, check that the power is off on all units. To avoid any possibility of electric shock, always connect your equipment to properly earthed outlets.




Q910 Flat & Compact Monitor

BACK

NEXT

1. Insert the 15-pin signal cable connector to the VGA connection on your computer and screw it down.
2. Plug the display unit's power cable first to the back of the display unit.
3. Then plug the power cable to a 100V - 240V earthed electrical outlet or to the system unit, if it has an outlet for the display power cable.
4. Turn on the display unit using the Soft power switch and check that the power LED is on. If not, repeat steps 2, 3 and 4 or refer to the *Troubleshooting* section of this guide.



5. Turn on the power to the computer. The picture will appear within about 15 seconds. Adjust the picture to obtain optimum picture quality. See the section *Adjusting the picture* in this guide for more information.

3-5. Setting the refresh rate

- Follow the instructions below to set your refresh rate in Windows 98.
1. Go to the configuration window (Start-Settings-Configuration window).
 2. Double click on the 'Display' icon.
 3. Click on the 'Settings' tab.
 4. Click on the 'Advanced' button.
 5. Click on 'Adapter' and select 85Hz from the list.
 6. Click on 'Apply' to accept the selected value.

The recommended setting is a resolution of 1280x1024(1600x1200) and a refresh rate of 85Hz.

Preset Timing Table

No.	Resolution	Horizontal Frequency	Refresh rate
1	720 x 400	31.5 KHz	70 Hz
2	640 x 480	37.5 KHz	75 Hz
3	640 x 480	63.7 KHz	120 Hz
4	800 x 600	53.7 KHz	85 Hz
5	1152 x 864	67.5 KHz	75 Hz
6	1024 x 768	68.7 KHz	85 Hz
7	1024 x 768	81.8 KHz	100 Hz
8	1280 x 1024	79.9 KHz	75 Hz
9	1280 x 1024	91.1 KHz	85 Hz
10	1600 x 1200	93.8 KHz	75 Hz
11	1600 x 1200	106.3 KHz	85 Hz

4. Adjusting the picture

You can adjust the screen display by using the buttons located below the screen.

