

ry


o PCS new AAA alkaline batteries
he mouse upper cover and pull the
d (Please see the reference picture)
atteries correctly according to the
battery grooves.

rs forward, when you hear "crack"
s the battery cover is locked

hector, please use the USB to PS/2
t with the connector before your

connect the receiver directly with the

ere is a little far between the case and
s suggest you use an extended USB
case and the receiver, so you can place
orking surface conveniently.



Then press the button of the



Attention Please

1. Please don't make the mouse move too fast in order to work more smoothly.
2. You'd better use the mouse for a long time, the batteries can be used longer. If the mouse will not be used for a long time, the mouse will not be used for a long time.
3. This mouse with save power. If you press any key or scroll the wheel, the mouse will be sleeping.
4. The optical mouse will not work on any reflecting surface, 3D mouse will not work.
5. No need to check the digital transmission when change the batteries, it will be automatically the above way to re-operate.

Caution

Any changes or modifications to the original design are the responsibility of the user. The manufacturer is not responsible for compliance with the regulations to operate the equipment.

ID Setup

1. Please move the mouse near to the receiver
2. Press the ID button of the receiver by your hand, the receiver light begin to flash
3. Press the ID button of the mouse bottom with some hard and acuate object within 10 seconds, the receiver light will flash very fast, a few seconds later it will be on which shows it is successfully to finish the digital transmission between the mouse and the receiver. You may start to use it.
4. Working distance: within 1-2 meters.