

**FOR / POUR / PARA
NINTENDO SWITCH™**

**WIRED
CONTROLLER**



Product name: Switch Wireless Controller

Model: SL-4106/SA5449

Manufacture: Dongguan Kingsheng Electronics & Technology Co., Ltd



1. Before using

Thank you for purchasing the controller for Nintendo Switch.

Before using it, please read this instruction manual carefully and keep it for future reference.



Before the first use, go to www.proSController.com to update the controller driver.

Register on the website in order to get all the latest updates.

2. Installing the controller on Nintendo Switch

1 - Before plugging the controller, turn on the console and go to *System Settings / Controllers and Sensors / Pro Controller Wired Communication*. Check that *On* is selected.

2 - Then, go to the menu *System Settings / Controllers and Sensors*, then to *Change Controller Grip/Order*.

3 - Plug the controller in one of the USB ports located on the left side of the Nintendo Switch dock, then follow the on-screen instructions:

- Press *L+R* on the controller, the controller will appear in one of the available slots.
- Press *A* when you're ready, the controller is now ready to use.

For further information regarding the use of the controller, please refer to the instruction manual of your Nintendo Switch.

3. Problem solving

If the controller encounters operational problems, that means that the driver is not up to date. From a PC, go to www.proSController.com to upgrade your controller with the last driver version.

4. Warning

- To avoid electrical incidents, make sure to keep the product in a dry place, protected from the rain or humidity.
- Do not dismantle.
- Do not insert any objects in the product as this could cause electrical incidents.
- Immediately put down the product if you feel tired or feel pain in your hands or arms while using the product. If the symptoms persist, consult your doctor.
- Take breaks during the game on a regular basis.

5. Contact and customer support

Please feel free to contact your Subsonic team for more information about the controller or other products in our range.

contact@subsonic.com

6. Respect the environment



In order to protect the environment, please do not discard electric/electronic devices and appliances with household garbage. Please take them to a recycling collection centre.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.