

Atencion



APAGAR EN HOSPITALES

Por favor respetar las disposiciones o reglamentos pertinentes.
Por favor apague su teléfono móvil cerca de equipos médicos.



APAGUE CUANDO PONGA COMBUSTIBLE

No utilice el teléfono en un punto de repostaje. No lo utilice cerca de combustibles o productos químicos.



TARJETAS SIM SON PORTATILES

Mantenga el teléfono y los accesorios fuera del alcance de los niños.



BATERIA

Por favor, no destruya ni dañe la batería, puede ser peligroso y provocar incendio.

Por favor no tire la batería al fuego para evitar riesgos.

Si no se puede usar la batería, deséchela en un lugar seguro.

Si la batería o el cargador está roto o viejo, por favor deje de usarlos, y reemplácelo con una batería genuina certificada.



USE EQUIPO DE CALIDAD

Usar equipo autorizado para evitar peligro.



LA SEGURIDAD VIAL VIENE PRIMERO

Preste toda la atención mientras conduce. Estacione antes de usar el teléfono. Por favor, siga las normas de tráfico de la ciudad local.



INTERFERENCIA

Todos los dispositivos inalámbricos pueden ser susceptibles a causar interferencia, lo que podría afectar el rendimiento.



DESACTIVAR EN AERONAVE

Los dispositivos inalámbricos pueden causar interferencias en aviones. No sólo es peligroso, sino también ilegal utilizar el teléfono móvil en un avión.

Comenzar

Llegar a tener en cuenta los conceptos básicos y tener su teléfono en marcha en poco tiempo.

Resumen de Telefono



Definición de teclas:

Teclas	Definicion
Tecla de encendido (Tecla final)	❖ Presione para finalizar una llamada que está siendo marcada o para finalizar una llamada en curso. ❖ Pulse para salir del menú y volver al estado de espera. ❖ Usted puede sostenerlo por dos o tres segundos puede encender / apagar el teléfono móvil.
Tecla de marcar	❖ Oprima para originar una llamada ingresando el número llamado o seleccionando un contacto de la agenda. ❖ Oprima para recibir una llamada entrante. ❖ Púselo en estado de espera para mostrar los registros de llamadas más recientes si desea marcar una llamada.
Tecla de direccion	❖ Púselos para desplazarse por las opciones cuando explore una lista de funciones. ❖ En el estado de edición, pulse las teclas de dirección para navegar.
Tecla de función izquierda y derecha	La línea inferior de la pantalla muestra las funciones de la tecla suave izquierda y derecha.
Tecla OK	Pulse para confirmar una selección.


Tecla de Número, Tecla de * y Tecla de #	✧ Pulse las teclas numéricas 0 a 9 para introducir o números y caracteres; ✧ En la pantalla de espera, puede presionar la tecla suave izquierda y luego presionar * para bloquear / desbloquear el teclado. ✧ Pulse dos veces la tecla * para introducir "+" en la interface de espera. Cuando aparezca el símbolo "+". ✧ Presione la tecla * rápidamente para ingresar "P" o "W", "P" y "W" se utilizan para llamar a la extensión; "+" se utilizan para marcar una llamada internacional.
--	--

Insertar tarjeta SIM


1.Retire la tapa de la batería.



2.Coloque la tarjeta SIM en la ranura.




3. Coloque la tarjeta SIM en la ranura para tarjetas.



Tip: La tarjeta SIM / SD son piezas pequeñas. Por favor mantenga alejado de los niños para evitar tragar la tarjeta por accidente. No toque la superficie metálica de la tarjeta SIM y manténgala alejada del campo electromagnético para evitar daños.

Cargar la batería

Cargue la batería antes de usarla. Conecte el cable USB al adaptador de alimentación USB y, a continuación, conecte el extremo del cable USB al puerto USB.



Configuracion

Perfiles

El teléfono móvil proporciona múltiples perfiles de usuario, de modo que puede personalizar algunas configuraciones para adaptarse a los eventos y entornos específicos.

Configuración de telefono

En este menú, puede establecer de acuerdo con sus preferencias y en diferentes situaciones (Pantalla, Hora y fecha, Encendido / apagado automático, Configuración de acceso directo, Bloqueo automático del teclado, Configuración de idioma).

Configuración de llamada

En este menú, puede establecer de acuerdo con diferentes situaciones (Voltear para responder, Desvío de llamadas, Llamada en espera, Restricción de llamadas, Ocultar ID, Otros).

Configuración de la red

En este menú, puede configurar el modelo de red (Automático, Manual.).

Conexiones

En este menú, puede establecer según diferentes situaciones (cuenta de red, servicio GPRS, itinerancia de datos, configuración de conexión de datos).

Seguridad

Esta función le proporciona ajustes relacionados con el uso de seguridad (PIN, Modificar PIN2, Bloqueo del teléfono, Modificar contraseña de privacidad, Privacidad, Marcación fija, Lista negra) urity.

Restaurar configuracion

Puede cancelar la configuración que haya establecido. El código original es 0000.

Acerca del telefono

En este menú, puede obtener la información de la versión del software.

Advertencias y notas

INFORMACIÓN IMPORTANTE SOBRE UNA OPERACIÓN SEGURA Y EFICAZ. Lea esta información antes de usar su teléfono. Para una operación segura y eficiente de su teléfono, siga estas pautas:

Potencialmente explosivo en las atmósferas: Apague el teléfono cuando se encuentre en áreas con un ambiente potencialmente explosivo, como zonas de abastecimiento de combustible (gas o gasolina, debajo de la cubierta de embarcaciones), instalaciones de almacenamiento de combustible o productos químicos. Y las áreas donde hay sustancias químicas o partículas (como polvos metálicos, granos y polvo) en el aire.

Interferencia con dispositivos electrónicos médicos y personales: La mayoría pero no todos los equipos electrónicos están protegidos contra las señales de RF y ciertos equipos electrónicos no pueden protegerse contra las señales de RF de su teléfono.

Seguridad de audio: Este teléfono es capaz de producir ruidos fuertes que pueden dañar su audición. Cuando utilice la función de teléfono con altavoz, se recomienda que coloque el teléfono a una distancia segura de su oído.

Otros dispositivos de medios, hospitales: Si utiliza cualquier otro dispositivo médico, consulte con la fabricación de su dispositivo para determinar si está adecuadamente protegido de la energía de RF externa. Su médico puede ayudarle a obtener esta información. Apague el teléfono en las instalaciones de atención médica cuando cualquier normativa publicada en estas áreas le indique que lo haga. Los hospitales o centros de atención médica pueden estar utilizando equipos que podrían ser sensibles a la energía de RF.

Declaración del producto sobre manejo y uso: Usted es el único responsable de cómo usa su teléfono y las consecuencias de su uso.

Debe apagar su teléfono siempre que se prohíba el uso de un teléfono. El uso de su teléfono está sujeto a medidas de seguridad diseñadas para proteger a los usuarios y su entorno. Siempre trate su teléfono y sus accesorios con cuidado y manténgalo en un lugar limpio y sin polvo.

Batería: Tenga en cuenta que el uso de determinadas aplicaciones de datos puede resultar en un uso pesado de la batería y puede requerir una carga frecuente de la batería. Cualquier desecho del teléfono o de la batería debe cumplir con las leyes y regulaciones relativas a las baterías de iones de litio o de iones de litio.

Productos defectuosos y dañados: No intente desarmar el teléfono ni sus accesorios. Sólo el personal calificado debe reparar el teléfono o su accesorio. Si su teléfono o su accesorio se ha sumergido en agua, perforado o sometido a una caída grave, no lo use hasta que lo haya revisado en un centro de servicio autorizado.

Información de certificación de la Tasa específica de absorción (SAR)

El dispositivo cumple con las normas de la Comisión Federal de Comunicaciones de Estados Unidos (FCC) que limitan la exposición de las personas a la energía de radiofrecuencia (RF) que emiten los equipos de radio y telecomunicaciones. Estas normas evitan la venta de dispositivos móviles que excedan el nivel de exposición máximo (conocido como Tasa específica de absorción o SAR) de 1,6 watts por kilogramo. Para ver información de SAR sobre este y otros modelos de dispositivos móviles, visite transition.fcc.gov/oet/rfsafety/sar.html.

En el uso normal, es probable que el índice de SAR real sea mucho menor, puesto que el dispositivo fue diseñado para emitir sólo la energía de RF necesaria para transmitir una señal a la estación base más cercana. Al emitir automáticamente niveles más bajos cada vez que es posible, el dispositivo reduce su exposición general a la energía de RF.

La FCC ha otorgado una Autorización de equipo para este modelo de dispositivo basado en el cumplimiento para todos los niveles SAR informados con las directrices de exposición a RF de la FCC. Este dispositivo tiene un número de identificación de la FCC : RQHLT-FS18203 [Número de modelo : D275D] y los niveles de SAR específicos para este dispositivo se puede encontrar en el siguiente sitio web de la FCC :

www.fcc.gov/oet/ea/

Attentions



SWITCH OFF IN HOSPITALS

Please abide by relevant provisions or regulations. Please turn off your mobile phone near medical equipment.



SWITCH OFF WHEN REFUELING

Don't use the phone at a refueling point. Don't use near fuel or chemicals.



SIM CARDS ARE PORTABLE

Keep your phone, phone parts and accessories out of children's reach.



BATTERY

Please do not destroy or damage the battery, it can be dangerous and cause fire.

Please do not throw battery in fire to avoid hazard.

When battery cannot be used, please dispose in safe environment.

If the battery or the charger is broken or old, please stop using them, and replace with certified genuine battery



USE QUALITY EQUIPMENT

Use authorized equipment to avoid danger



ROAD SAFETY COMES FIRST

Give full attention while driving. Park before using your phone.

Please follow traffic rules of local citytown.



INTERFERENCE

All wireless devices may be susceptible to cause interference, which could affect performance.



SWITCH OFF IN AIRCRAFT

Wireless devices can cause interference in aircraft. It's not only dangerous but also illegal to use mobile phone in an aircraft.

Get Started

Get to grip with the basics and have your phone up and running in no time.

Over view




Keys definition:


Keys	Definition
Power key(End key)	✧ Press it to end a call being dialed or end an ongoing call ✧ Press it to exit the menu and return to the standby state. ✧ You can hold it for two or three seconds can power on/off the mobile phone
Dial key	✧ Press it to originate a call by entering the called number or selecting a contact from the phonebook ✧ Press it to receive an incoming call ✧ Press it in standby state to show the latest call records .if you want to dial a call.
Direction key	✧ Press them to scroll the options when browsing a function list. ✧ In edit state, press direction keys to navigate.
Left and right soft key	The bottom line on the screen displays the functions of the Left and Right soft key.
OK key	Press it to confirm a selection.
Number keys, * key and # key	✧ Press number keys 0 through 9 to input or edit state to input numbers and characters; ✧ In idle screen, you can press left soft key then press * to lock/unlock keypad. ✧ Press two times the key * to input "+" in standby interface. When the symbol "+" appears, ✧ Press the * key quickly to input "P" or "W";"P" and "W" are used for calling the extension; "+" are used for dialing an international call.

Insert SIM card


1.Remove the battery cover



2.Put the SIM card into the slot




3.Put the SD card into card slot.



Tip: The SIM/SD card are small parts. Please keep away from Children to avoid swallowing the card by accident.
Please do not touch the metal surface of SIM card and away from electromagnetic field to avoid damage data.

Charge the Battery

Charge the battery before using it. Connect the USB cable to the USB power adaptor, and then plug the end of the USB cable into the USB Port.

**Settings****Profiles**

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Phone settings

In this menu, you can set according to your preferences and in different situations (Display, Time & date, Auto power on/off , Shortcut settings, Auto keypad lock , Language settings)

Call Settings

In this menu, you can set according to different situations (Flip to answer, Call divert, Call waiting, Call barring, Hide ID, Others.)

Network selection

In this menu, you can set according to different situations (Auto select, Manual select.)

Connections

In this menu, you can set according to different situations (Network account, GPRS Service, Data roaming, Data connection settings.)

Security

This function provides you with related settings about safety use (PIN, Modify PIN2, Phone lock, Modify privacy password, Privacy, Fixed dialing, Blacklist.)

Restore factory settings

You can cancel the setting you set. The original code is 0000.

About phone

In this menu, you can get the software version information.

Warnings and notes

IMPORTANT INFORMATION ON SAFE AND EFFICIENT

OPERATION. Read this information before using your phone.

For the safe and efficient operation of your phone, observe these guidelines:

Potentially explosive at atmospheres: Turn off your phone when you are in any areas with a potentially explosive atmosphere, such as fueling areas (gas or petrol stations, below deck on boats), storage facilities for fuel or chemicals, blasting areas and areas near electrical blasting caps, and areas where there are chemicals or particles (Such as metal powders, grains, and dust) in the air.

Interference to medical and personal Electronic Devices:

Most but not all electronic equipment is shielded from RF signals and certain electronic equipment may not be shielded against the RF signals from your phone.

Audio Safety: This phone is capable of producing loud noises which may damage your hearing. When using the speaker phone feature, it is recommended that you place your phone at a safe distance from your ear.

Other Media Devices, hospitals: If you use any other personal medical device, consult the manufacture of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Product statement on handling and use: You alone are responsible for how you use your phone and any consequences

of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment. Always treat your phone and its accessories with care and keep it in a clean and dust-free place.

Battery: Please note that use of certain data applications can result in heavy battery use and may require frequent battery charging. Any disposal of the phone or battery must comply with laws and regulations pertaining to lithium-ion or lithium-ion polymer batteries.

Faulty and damaged products: Do not attempt to disassemble the phone or its accessory. Only qualified personnel must service or repair the phone or its accessory. If your phone or its accessory has been submerged in water, Punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Specific Absorption Rate (SAR) certification information

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: Mobile Phone (FCC ID: RQQLT-FS18203) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on - line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested simulation typical 10mm to body. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly; the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation

is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.