


INFINITER®



Wireless
Laser Presenter
Model No: LR4

User Manual

Statement:

This device complies with Part 15 of the FCC Rules. Operations is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Copyright Information

Copyright © QUARTON, 2006. All rights reserved.

Disclaimer: QUARTON shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

QUARTON reserves the right to change product specifications without notice. Information in this document may change without notice.

No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from QUARTON.

Preface

Congratulations on your purchase of LR4. It is a versatile presentation laser pointer, wireless USB controller, and combined flash drive.

About This User's Guide

This manual is designed to guide you through setup and operation of LR4. The introduction details quick setup and operation. The OSD chapter details how to use LR4 menu, and the final chapter explains additional functions available.

Quick Start Guide

The Quick Start Guide is designed to help you set up and operate LR4 as quickly as possible. It contains basic information to get started.

Syntax Convention

- Buttons with captions, and menu options begin with capital letters
- Buttons without captions are referenced by their graphical representation

Table of Contents

Introducing LR4	1	Additional Information.....	13
Features	1	Operating the Laser	13
Package Contents	3	Timer Quick Settings	13
LR4 Components	4	OSD Backlight	13
Specifications	5	Vibrate Alert	14
Laser Pointer Icons	5	Frequency Search	14
Preparing for Use	6		
Installing the Battery	6		
Removing the Wireless USB Receiver	7		
Installing the Wireless USB Receiver	7		
LR4 Menu Display.....	8		
Introducing the Display	8		
On-Screen (OSD) Modes	9		
Keyboard (K/B)	9		
MOUSE	10		
MEDIA Player	10		
TIMER	11		

CHAPTER 1 Introducing LR4

This chapter details the uses, features, and installation of LR4

1.1 Features

Wireless USB Transceiver

LR4 is an all-in-one transmitter and receiver. The wireless USB receiver separates from the main controller unit and plugs directly into any USB port. The controller can transmit up to 10 meters.

Remote Keyboard and Mouse

Control the mouse or keyboard during presentations over the wireless connection.

Remote Multimedia

Use LR4 as a remote control for playing multimedia content.

Laser Pointer Icons

Project five different pointer images and enhance the appeal of your presentations.

1GB USB Flash Drive (optional)

LR4 wireless USB receiver is also a USB flash drive that can store up to 1GB of your data. Now you can carry all your multimedia and presentations in one convenient drive.

Backlit LCD Menu

Always know the current status of your LR4 with an easily viewable display.

Navigation Pad

The ergonomic LR4 provides simple thumb control for easy navigation of the LCD Menu and replacing the mouse during presentations.

Countdown Timer

Set the timer to countdown from up to 24 hours to remind you of important events, or how much time is left for your presentation.

Vibrate Alarm

The vibrate lets you discretely acknowledge timed alerts without creating a distraction.

Power-saving Mode


The LR4 will automatically turn off after 30-minutes standby.

System Restore


LR4 remembers and restore the previous state of operation after switching off or even changing the batteries.

1.2 Package Contents

Please check the package contains the following items.



1.3 LR4 Components



4

LR4 User Manual Chapter 1 Introducing LR4

1.4 Specifications

Dimensions	13(L) x 3.5 (W) x 2.2 (T) cm
Weight	78g (including battery)
Transmission Distance	33 feet (10 meters)
RF Frequency	2.4G
Interface	USB 2.0
OS Supported	Windows 2000/Me/XP/Mac OS 9.0 & higher
Laser Wavelength	630~680nm
Output Power	CL IIIa, <5mW CL II, <1mW
Power	1x AAA 1.5V battery
Battery Burn Time	6 hours

1.4.1 Laser Pointer Icons



Warning : Laser radiation is harmful to the eyes. Do not stare directly into the beam.

Caution : Use of controls, adjustments or procedures other than those specified in this manual could result in hazardous exposure to laser radiation.

LR4 User Manual Chapter 1 Introducing LR4


5

1.5 Preparing for Use

1.5.1 Installing the Battery

For first use, or should the battery indicator on the LCD show empty. Please use the following guidelines to install a new battery.

- 1 Push the battery cover down and away from the controller.
- 2 Align the AAA battery according to the (+) and (-) markings on the battery compartment.
- 3 Replace the battery cover sliding back until it clicks into place.



Caution:

- Only use the specified AAA battery.
- Insert battery according to (+) and (-) markings. Inserting the battery incorrectly may result in cracking or leakage, which may pose a risk of fire or lead to personal injury.
- Dispose of the battery in accordance with local laws and regulations. Please turn in your batteries at the responsible collecting point, or place of purchase.
- When the controller is not used for extended periods, please remove the battery.


Warning: Never dispose of batteries in fire, as they could explode.

1.5.1.1 Powering LR4

To switch LR4 on or off, press and hold the **Power/Mode** button for two seconds, at the same time, the LCD illuminates for 3 seconds. The LR4 will automatically turn off after 30-minutes standby.

1.5.2 Removing the Wireless USB Receiver


Locate the raised edge at the rear-end of the controller module.
Push and slide out the wireless USB receiver.



1.5.3 Installing the Wireless USB Receiver

The wireless USB receiver is used like a regular USB flash drive. Plug the receiver directly into an available USB port of your notebook or computer. Windows 2000/XP/Mac OS 9.0 operating systems and later, the drive is automatically recognized and installed.


Note: If after installation, the USB receiver does not respond to the controller, please **See "Frequency Search" on page 14** for how to match the frequency between controller and receiver.



CHAPTER 2 LR4 Menu Display

This chapter explains how to use the OSD menus

2.1 Introducing the Display




8

LR4 User Manual Chapter 2 LR4 Menu Display

2.2 On-Screen (OSD) Modes


LR4 has four modes of operation. Press the **Power/Mode** button to cycle through the different methods of using the controller.



2.2.1 Keyboard (K/B)

Press the **Power/Mode** button until **K/B** is highlighted on the OSD.

Enter **K/B** mode to replace the computer keys.



ALT + TAB

ALT
TAB
PgUp
PgDn
ESC
F5

Press **ALT** and then press **TAB** to scroll through open windows and programs.

ALT, **TAB**, **PgUp**, **PgDn**, **ESC/F5** also replace their keyboard equivalents.

The right-hand multifunction navigation pad button turns the screen blank.

LR4 User Manual Chapter 2 LR4 Menu Display

9

2.2.2 MOUSE

Press the **Power/Mode** button until **MOUSE** is highlighted on the OSD.

Enter **MOUSE** mode to replace the computer's mouse.



ALT **ALT** replaces the right mouse button.


TAB **TAB** replaces the left mouse button.

▲ The multifunction navigation pad moves the mouse pointer.



2.2.3 MEDIA Player

Press the **Power/Mode** button until **MEDIA** is highlighted on the OSD.



▶/||



Enter **MEDIA** mode to play your media with the controller.

▶| Remotely play, pause, stop, skip tracks or adjust the volume.

Vol +

Vol -

2.2.4 TIMER


Press the **Power/Mode** button until **TIMER** is highlighted on the OSD.

Enter **TIMER** to set and start a countdown from a maximum of 24 hours using HH:MM:SS.

Press **SET** to start the timer and edit that value or press **START** to exit timer if countdown function is not needed.

▲ Press the plus(+)/minus(-) sign to increase/decrease the highlighted number.


◀ Press the left/right arrow to highlight the desired number to change.



Press **SET** to stop the timer and edit that value.

Press **START** to begin the countdown.

The following example details how to edit the timer settings.



Quick Timer Setup: When starting the timer setting, press **SET** to setup the timer quickly. Press once to add 5 minutes, and so on.

CHAPTER 3 Additional Information

This chapter details additional functions of LR4

3.1 Operating the Laser

While pressing the **Laser Pointer** button, rotate the jog-wheel and cycle through the various pointers to the desired icon.



3.2 Timer Quick Settings

To quickly set the timer, press the **Mode/Power** button until **TIMER** is highlighted. Now press **SET**, the countdown setting increases by 5 minutes with each subsequent press (i.e. 5,10,15,20), until the maximum of 24-hours is reached.

3.3 OSD Backlight

The controller's OSD is backlit for viewing under virtually any lighting conditions, and turns on for three seconds after the following events.

- Pressing the **Power/Mode** button
- Pressing the **PgDn** (down arrow) on the multifunction navigation pad during **K/B** (keyboard) mode

Note: During **Timer** mode, the backlight remains illuminated.

3.4 Vibrate Alert

LR4 has a vibrate alert to discretely inform:

- The final three minutes of the timer; three short vibrations
- The final minute of the timer; short vibration
- When the timer reaches zero; long vibration

3.5 Frequency Search

Should the receiver not respond to the controller after installing the driver **See “Installing the Wireless USB Receiver” on page 7**, reset the transmission and reception frequency between controller and wireless USB receiver using the following procedure.

- 1 Plug the wireless USB receiver into an available USB port.
- 2 Press the **Connect Key** on the wireless USB receiver.
The **Status LED** starts flashing.
- 3 Remove the battery on the LR4.
- 4 Press the **Power button** while re-install the battery.
- 5 Wait till the boot-up completes and then release the **Power button**.
The **Status LED** on the wireless USB receiver stops flashing.
- 6 When the **Status LED** stops flashing, the wireless transmission is reset.
Now the LR4 is ready to use.

Note: For additional information, please visit www.infiniterlaser.com