

Yealink

Certified for
Microsoft Teams

BHD742 Bluetooth Headset



Quick Start Guide V1.1



Please update the headset to the latest version via Yealink USB Connect (PC) or Yealink Connect (APP) before using.

Notes

1. The signal range of Bluetooth headset typically spans around 10-30 meters. Please ensure the distance between your device and the headset is close to prevent signal interruption or degradation.
2. It is advised to minimize proximity to other Bluetooth devices or wireless signal sources, such as Wi-Fi routers, to reduce the likelihood of interference.

Safety Guide


1. Do not disassemble the product by yourself or bring it near fire and water to avoid short circuit leakage or damage to the product.
2. Do not use the product in high temperature, humidity, and corrosive environment to avoid damaging the circuit and causing failure to charge or other failures.
3. Do not expose the product to corrosive liquids. Otherwise, it will cause severe damage.
4. Do not disassemble or re-equip the product for any reason to avoid secondary failure and burnout.
5. Do not place the product below -10°C or above 60°C.
6. Do not knock, throw or shake the product because rough methods will damage the internal circuit board structure.

1 Package List

• Standard




BH74 Headset




Quick Start Guide




Carrying Case



BT51-C Dongle




USB C/A Adapter




USB Charging Cable

• Optional



BHC74 Charging Stand



Replacement Ear Cushions

Note: We recommend that you use the included accessories, and other accessories may have compatibility issues that prevent them from working properly.

2 Overview

-  Teams button
-  Voice Assistant button


 Power on/off

 Bluetooth

 Call control

 Busylight

 Charging port



Microphone 

Volume + 

Next track 

Mute 

Play/pause 

Volume - 

Previous track 

ANC 



3 Charging

USB Charging




Charging stand (optional)



Note: We recommend to fully charge the headset when using it for the first time.


LED Indicator Status

Charging



Breathing green LED indicator


Fully Charged



Green LED indicator

Note: It takes 1.5 hours to fully charge the headset.

4 Power on/off




Power Button	LED Indicator	Prompt Sound
 Power on	Green	 "Power on, battery low/medium/high"
 Power off	Red	 "Power off"

Note:


When the headset is powered on but not connected for a long time, it will enter deep sleep mode. To wake up the headset, briefly push the **Power** button down or tap the **Call Control** button.

5 Pairing and Connecting Device

• Enter Pairing Mode



• Pair with PC




• Pair with Desk Phone




Note:

- If your desk phone does not have built-in Bluetooth, you need to use the BT51 dongle to pair the headset.
- The BT51 and headset are already pre-paired when leaving the factory. They can automatically connect after powering on.

• Pair with Mobile Device



6 Call & Music Control



Press once


- Answer call
- End call
- Accept the incoming call and end the active call

Double-press

- Redial
- Reject the incoming call and continue the active call


Hold for 2 sec

- Hold call
- Put the current call on hold and answer an incoming call
- Switch between held call and active call



Press once

- Mute/unmute the microphone
- Alternatively, move up/down the microphone boom-arm




Press once

- Volume up (+)/volume down (-)

Hold for 1.5 sec

- Next track (volume +)
Previous track (volume -)



Press once/Put on

- Play music




Press once/Take off

- Pause music



7 Customers Button




Teams Edition

Press once

- Open Teams Notification

Note:

You can switch to Teams or UC platform through Yealink USB Connect.



Teams/UC Edition

Hold for 2 sec


- Activate Voice Assistant
- Dismiss/invoke raise hand during the meeting (Supported only in Teams edition)



Siri, Google assistant..., depending on mobile phone.

8 Busylight Control

- Via Yealink USB Connect (PC)/Yealink Connect APP (Mobile)
- Via headset buttons



Simultaneously press and hold the Volume +/- buttons




Busylight LED solid red



"Busylight on"


9 Sound Control



Note:


- You can set the level of noise cancellation on Yealink USB Connect (desktop client) or Yealink Connect (mobile app).
- If you are in Noise Canceling Mode, you might not hear the ambient sound. It depends on ambient conditions and the type or volume of audio playback.
- Do not use the headset in places where the inability to hear ambient sounds would be dangerous.

10 Replace Ear Cushions



11 Software Management


• Yealink USB Connect (PC)



Download it from the Yealink website <https://www.yealink.com/product/yuc>.

Note: It needs to be used with Yealink USB Connect of version 4.38.x.x or later.

• Yealink Connect App (Mobile)



Apple and the Apple logo are trademarks of Apple Inc.

Download the Yealink Connect App from IOS App Store or Android App Store.

Label Information

Remove the earcup to find the label information, such FCC ID.



Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +14 to 113°F (-10 to 45°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +160°F (-30 to +70°C)

Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

Explanation of the symbols

- DC symbol
- is the DC voltage symbol.
- WEEE Warning symbol

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

Safety Instructions

Read these instructions. Read these safety instructions before use!

General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

Environmental Requirements

- Do not cover ventilation openings, this equipment is not intended to be used on soft support.
- The marking information is located at the exterior of the bottom
- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- Keep the device dry and free of dusts.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.

Battery Requirements

- Do not immerse the battery into water, which could short-circuit and damage the battery.
- Do not expose the battery to an open flame or leave the battery where it could be subjected to extremely high temperatures, which could cause the battery to explode.
- Do power the handset off before removing the battery.
- Do not try to use the battery for the power supply of any device other than this handset.
- Do not open or mutilate the battery, released electrolyte is corrosive and may cause damage to your eyes or skin.
- Use only the rechargeable battery pack delivered with the handset or those rechargeable battery packs expressly recommended by Yealink.
- Defective or exhausted battery should never be disposed of as municipal waste. Return old battery to the battery supplier, a licensed battery dealer or a designated collection facility.



Cleaning Requirements

- Use a piece of soft, dry and anti-static cloth to clean the device.

Troubleshooting

The usage environment is out of operating temperature range.

1. Use in the operating temperature range.

The cable between the unit and the Yealink device is connected incorrectly.

1. Connect the cable correctly.
You cannot connect the cable properly.
1. You may have connected a wrong Yealink device.

2. Use the correct power supply.
Some dust, etc., may be in the port.

1. Clean the port.

Contact your dealer or authorized service facility for any further questions.

FCC CAUTION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED WARNING:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'encombrer le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Les communications effectuées au moyen de cet appareil ne sont pas nécessairement protégées des interférences.

This equipment complies with ICSED radiation exposure limits set forth for an uncontrolled environment.

L'appareil est conforme aux limites d'exposition aux rayonnements spécifiées par la ICSED pour les environnements non contrôlés.

EU Regulatory Information

Support Frequency Bands and Power:
Bluetooth 2.4GHz: <20 dBm

Contact Information

YEALINK NETWORK TECHNOLOGY CO., LTD.
No.666 Hu'an Rd, Huli District Xiamen City, Fujian, P.R.C
YEALINK (EUROPE) NETWORK TECHNOLOGY B.V.
Keizersgracht 62, 1015CS Amsterdam
YEALINK (USA) NETWORK TECHNOLOGY CO., LTD.
999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA
Made in China