

LX2 Smart Watch

User Manual

Before using please check instruction

V0.1

1.Considerations for use Notice

1.1 Company reserves the right to modify the contents of this manual without any notice. It is normal for some functions to differ in a particular software version.

1.2 Please charge the product for more than 2 hours before using

1.3 Do not press the button or slide the screen in the water.

1.4 This product supports IP68 waterproof, which is not suitable for diving, soaking hot water, brewing tea and other corrosive liquids. Diving more than 3 meters or pressing the button underwater may cause water entering into the product, which is a destructive use and will not enjoy the product warranty and free maintenance.

1.5 Mobile Device Requirements

Android: Support original Android 5.0 and above Android mobiles

IOS: Support IOS 9.0 and above

2. Product Introduction

Basic operation

2.1 First use, system need to set features, please be patient

2.1.1 Setting Language: set the language you need.

2.1.2 Setting body features, weight, height, Daily exercise goals, etc

2.1.3 Select the your mobiles

2.1.4 Scan the QR code, download and install the sync app according to the tips on your watch. Synchronization software can synchronize the relevant information on the phone to the watch shortcut interface, convenient for you to read, see the "synchronization software instructions" in detail.

2.2 Press and hold the **Power** button until the device turns on.

2.2.1 To turn the device off: Press and hold the **Power** button, tap **Power off**.

2.2.2 Restart: restart the device;

2.2.3 Super power saving: when this option is selected, the super power saving button changes from gray to green, indicating that the system will enter the super power saving mode. The super power saving mode only displays time and power, while other functions are in a deep sleep. The screen cannot slide into function selection. Click the "X" button in the power-saving mode interface to resume normal use.

2.2.4 Recent task: which is the most recent use of the application shortcut, swipe left or right to close the background application, free memory; Swipe up or down to quickly open used apps.

2.3 Basic Operation

The dial area is small, during operation, the sliding distance is required to be more than half of the screen diameter, only sliding the middle distance may be invalid.

2.3.1 Dial interface from right to left, enter the main menu, you can choose functions;

2.3.2 Main menu interface, from left to right swipe, are exit functions.

Dial effect drawing and setting method :(see the product for more dial)

3. Notice

3.1 Please charge it fully before use, it will take 1-2 hours to charge

3.2 Charging cable can use the charging head of android smartphone, and use the special magnetic absorption charging cable configured; During charging, keep magnetic absorption normal;

3.3 BT disconnects over the distance during use. After two-way anti-loss is enabled, it cannot use the search function before reconnection.

3.4 When the watch and the mobile phone synchronization software are connected successfully and some functions cannot be used normally, please delete the paired BT information and reconnect. If the connection steps are not as described in the manual, the result will lead to abnormal connection and some functions cannot be used normally.

4. Trouble Sheet

Please refer to the following terms to solve the problems arising from the use of mobile phones. If the problem still exists, please contact the dealer or appoint a repairman.

4.1 Can not switch on

Press and hold the **Power** button more than 3 seconds
charge the smart watch

4.2 Automatically switch off.

Low power, please charge

4.3、 Watch lasts only a short time

The battery is not fully charged, please make sure that
there is sufficient charging time (the minimum charge
time is 2 hours).

The function of raising the hand and brightening the
screen is on, which consumes more power

4.4 Watch can' t charge

Check the charger, or change another charger.,

Please ensure the PIN on both Smart watch and charger are
connected, try one more time.

FCC/ISED Compliance Notice

This device complies with Part 15 of the FCC Rules and ISED Licence-exempt RSS standard.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

Cet appareil est conforme à la partie 15 des règles de la FCC et à la norme RSS exonérée de licence ISED.

L'opération est soumise aux deux conditions suivantes:

- (1) cet appareil ne peut pas causer d'interférences nuisibles, et
- (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent causer un fonctionnement indésirable.

Toute modification ou modification non expressément approuvée par la partie responsable de la conformité pourrait annuler l'autorisation de l'utilisateur d'utiliser l'équipement.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information

SAR tests are conducted using standard operating positions accepted by the FCC/ISED with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new model is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure limit established by the FCC/ISED. Tests for each product are performed in positions and locations as required by the FCC/ISED. For Handheld operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

For limb worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

Informations sur l'exposition RF

Les tests SAR sont effectués à l'aide de positions de fonctionnement standard acceptées par la FCC/ISED, l'appareil transmettant à son niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de puissance certifié le plus élevé, le niveau de fonctionnement peut être bien inférieur à la valeur maximale. Avant qu'un nouveau modèle ne soit disponible à la vente au public, il doit être testé et certifié conforme par la FCC/ISED qu'il n'excède pas la limite d'exposition établie par la FCC/ISED. Les tests de chaque produit sont effectués à requis par la FCC/ISED. En mode portatif, cet appareil a été testé et respecte les directives d'exposition RF de la FCC/ISED lorsqu'il est utilisé avec un accessoire conçu pour ce produit ou avec un accessoire ne contenant pas de métal.

Pour le fonctionnement des membres usés, cet appareil a été testé et respecte les directives d'exposition RF de la FCC/ISED lorsqu'il est utilisé avec un accessoire conçu pour ce produit ou lorsqu'il est utilisé avec un accessoire ne contenant pas de métal.