

iBaby Care

Monitor M8

Quick Start Guide
Schnellstartanleitung
Guide de démarrage rapide
Guía de inicio rápido

iOS
Android

Includes

- 1 MB Baby Monitor
- 1 Power Adapter (5V/1.5A)
- 1 Quick Start Guide
- 1 Screw Assembly

Getting Started

What you'll need:

Modern Router (not included) Your Smart Device (not included) Monitor Power Adapter

How to Install Your Monitor

- Verify that your smart device is connected to a Wi-Fi network. Your router must provide Wi-Fi connection for Internet access during installation.
- From App Store or Google Play Store, download the **iBaby Care®** app and create an account.
- Follow the in-app steps to set up the monitor.

LED Light Indicator

The LED light indicator behind your iBaby Monitor M8 indicates your monitor's status. You can determine the status by matching the color pattern below:

Installed successfully	Solid Blue
Waiting for installation	Flashing Red
No Network Connection	Solid Red

EN

How to Mount Your Monitor

- Choose a place to position your wall mount kit.
- Drill two holes and insert (2) screws.
- Make sure that the wall mount kit is sturdy.
- Mount your baby monitor on the wall.

Changing your router or installation failed?

Reset your monitor by holding the **BOTTOM** reset button for 5 seconds. Then reinstall your device when you hear "Reset Successful".

How to Install Your Monitor

- Verify that your smart device is connected to a Wi-Fi network. Your router must provide Wi-Fi connection for Internet access during installation.
- From App Store or Google Play Store, download the **iBaby Care®** app and create an account.
- Follow the in-app steps to set up the monitor.

LED Light Indicator

The LED light indicator behind your iBaby Monitor M8 indicates your monitor's status. You can determine the status by matching the color pattern below:

Installed successfully	Solid Blue
Waiting for installation	Flashing Red
No Network Connection	Solid Red

DE

Lieferumfang

- 1 MB Baby Monitor
- 1 Netzteil (5 V/1,5 A)
- 1 Schnellstartanleitung
- 1 Schraubenmontage

Erste Schritte

Was Sie benötigen:

Modern/Router (nicht incl.) Smart-Gerät (nicht incl.) Monitor Netzteil

So installieren Sie Ihren Monitor

- Stellen Sie sicher, dass Ihr Smart-Gerät mit einem WLAN-Netzwerk verbunden ist. Während der Montage muss Ihr Router für Internetzugang über WLAN sorgen.
- Laden Sie aus dem App Store oder Google Play Store die App **iBaby Care®** herunter und erstellen Sie ein Konto.
- Befolgen Sie zum Einrichten des Monitors die in der App genannten Schritte.

LED-Lichtanzeigen

Die LED-Lichtanzeige hinter Ihrem iBaby Monitor M8 zeigt den Status Ihres Monitors an. Sie können den Status durch Zuerst den durch die Farben festlegen bestimmen.

Installation erfolgreich	Ununterbrochenes Blau
Auf Installation wartend	Rot blinkend
Keine Netzwerkverbindung	Ununterbrochenes Rot

FR

Contenu

- 1 moniteur pour bébé MB
- 1 adaptateur d'alimentation (5V/1,5 A)
- 1 guide de démarrage rapide
- 1 jeu de vis

Pour commencer

Ce dont vous avez besoin :

Modern (non inclus) Votre smartphone (non inclus) Adaptateur d'alimentation

Comment installer votre moniteur

- Vérifiez que votre smartphone est connecté à un réseau Wi-Fi. Votre routeur doit disposer d'une connexion Wi-Fi pour permettre un accès à Internet pendant l'installation.
- Téléchargez l'application **iBaby Care®** à partir de l'App Store ou du Google Play Store et créez un compte.
- Suivez les étapes contenues dans l'application pour configurer le moniteur.

Voyant lumineux LED

Le voyant lumineux LED situé derrière votre moniteur iBaby MB indique son état. Vous pouvez déterminer l'état dans l'application en regardant les couleurs ci-dessous :

Installation réussie	Blue continu
En attente d'installation	Rouge clignotant
Aucune connexion réseau	Rouge continu

ES

Contenido

- 1 monitor de vigilancia para bebés MB
- 1 adaptador de corriente (5V/1,5A)
- 1 Guía de inicio rápido
- 1 tornillo de montaje

Primeros pasos

Qué necesita:

Modem/routeur (no incluido) Su dispositivo inteligente (no incluido) Adaptador de corriente

Cómo instalar su monitor

- Verifique que su dispositivo inteligente esté conectado a una red Wi-Fi. Su router debe proporcionar una conexión Wi-Fi para el acceso a Internet durante la instalación.
- Descargue la aplicación **iBaby Care®** desde App Store o Google Play Store y cree una cuenta.
- Siga los pasos de la aplicación para configurar el monitor.

Indicador LED

El indicador de luz LED detrás de su iBaby Monitor M8 indica el estado de su monitor. Puede determinar el estado haciendo coincidir los patrones de color siguientes:

Instalado correctamente	Azul fijo
Esperando instalación	Rojío intermitente
No hay conexión de red	Rojío fijo

EN

Comment installer votre moniteur

- Choisissez un emplacement pour positionner votre kit de montage mural.
- Percez deux trous et insérez les 2 vis.
- Assurez-vous que le kit de montage mural est bien mis.
- Fixez votre moniteur pour bébé sur le mur.

Changement de routeur ou échec de l'installation ?

Réinitialisez votre moniteur en maintenant le bouton de réinitialisation enfoncé pendant 5 secondes. Puis, réinstallez votre appareil lorsque vous entendrez « Reset Successfully ».

FR

Comment installer votre moniteur

- Choisissez un emplacement pour positionner votre kit de montage mural.
- Percez deux trous et insérez les 2 vis.
- Assurez-vous que le kit de montage mural est bien mis.
- Fixez votre moniteur pour bébé sur le mur.

Changement de routeur ou échec de l'installation ?

Réinitialisez votre moniteur en maintenant le bouton de réinitialisation enfoncé pendant 5 secondes. Puis, réinstallez votre appareil lorsque vous entendrez « Reset Successfully ».

ES

Cómo montar el monitor

- Seleccione un lugar para colocar su kit de montaje en pared.
- Marque dos orificios e inserte (2) tornillos.
- Asegúrese de que el kit de montaje en pared sea resistente.
- Monte su vigilabebé en la pared.

¿Ha cambiado el router o la instalación no se ha realizado correctamente?

Reinicie su monitor manteniendo pulsación el botón de reinicio (RESET) durante 5 segundos. Después de 5 segundos, reinstale su dispositivo cuando escuche «Reset Successfully».

ES

Cómo montar el monitor

- Seleccione un lugar para colocar su kit de montaje en pared.
- Marque dos orificios e inserte (2) tornillos.
- Asegúrese de que el kit de montaje en pared sea resistente.
- Monte su vigilabebé en la pared.

¿Ha cambiado el router o la instalación no se ha realizado correctamente?

Reinicie su monitor manteniendo pulsación el botón de reinicio (RESET) durante 5 segundos. Después de 5 segundos, reinstale su dispositivo cuando escuche «Reset Successfully».

Manufacturer's Name: iRady Labs, Inc
Sample Description: iRady Monitor M8
Trade Name: iRady
Model number: M8
Operating Temperature: -10° C to 40° C
This device is designed to be used in compliance with RF exposure requirements, a minimum separation distance of 20cm must be maintained between the user's body and the device, including the antenna. Use only the supplied or an approved antenna.
This device is compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All radio frequency emissions have been carried out.
1. CAUTION : RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
2. The device complies with RF specifications when the

POC WARNING

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, even if such interference causes undesired operation.

2. This device has been tested and found to comply with the following requirements: It is authorized for use in the U.S. and is limited to the following conditions:

• This device is a Class B digital device, pursuant to Part 15 of the FCC Rules, and its operation may cause radio interference in a residential installation. This equipment must accept any interference received, even if such interference causes undesired operation.

• It must not be used in accordance with the instructions, may not cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

• If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC RF Exposure guidelines, the following precautions should be followed:

• This equipment should be installed and operated with minimum distance 20cm to the radiator power cord: use only the supplied