

System Requirements

Hardware

- PC with an Intel® Pentium® processor or equivalent
- USB 1.1 interface

Operating System

- Windows® 98SE/Me/2000/XP




NOTE: THE THIRD BUTTON AND THE SCROLLING WHEEL OF THE MOUSE ONLY WORK WITH THE OPERATING SYSTEMS LISTED ABOVE. IF YOU USE THE MOUSE WITH A DIFFERENT OPERATING SYSTEM, IT WILL LOSE ITS ENHANCED FEATURES AND FUNCTION AS A STANDARD, TWO-BUTTON MOUSE.

Installing the Batteries

Optical Mouse

- 1 Remove the battery cover from the top of the mouse by pressing the top center (over the Targus logo) and sliding it back.



Removing the battery cover

- 2 Insert the supplied batteries, making sure that the positive (+) and negative (-) ends of each battery match the polarity indicators inside the battery housing.




WARNINGS: WHEN REPLACING THE BATTERIES, YOU MAY USE ALKALINE OR OTHER HEAVY-DUTY NIMH BATTERIES. NEVER COMBINE AN ALKALINE WITH A NIMH BATTERY IN A DEVICE.

AVOID MIXING NEW AND USED BATTERIES IN A DEVICE.

- 3 Slide the battery cover back into position until it “clicks” firmly into place.
- 4 Turn on the mouse by sliding the on/off switch on the bottom of the mouse to the “on” position. The optical sensor, located on the bottom of the mouse, glows red.

Wireless Keypad

- 1 Remove the battery cover located on the bottom of the keypad.
- 2 Insert the supplied batteries, making sure that the positive (+) and negative (-) ends of each battery match the polarity indicators inside the battery housing.




- 3 Turn on the keypad by sliding the Power switch on the right side of the keypad to the “on” position.

Connecting the Receiver

To connect the receiver:

- 1 Plug the USB receiver into an available USB port on your computer.
- 2 Follow any on-screen instructions to complete the default driver installation.



The “Lock LED” light turns on.

You are now ready to set the identification code to establish a communication link with the receiver.

Setting the Identification Code


After your computer detects the USB receiver and the driver software is installed, you must set the ID code between the receiver and the mouse as well as between the receiver and the keypad **BEFORE** you can use them. To do this, do the following:



NOTE: MAKE SURE THAT YOUR COMPUTER IS TURNED ON AND HAS DETECTED THE USB RECEIVER BEFORE YOU SET THE ID CODE.

Optical Mouse

- 1 Press and release the setup key on the receiver. The Lock LED light turns off.
- 2 Press the setup key on the bottom of the mouse.



When the LED on the receiver is lit, the mouse is set up with an ID and the receiver is locked.

You are now ready to use the mouse.

Wireless Keypad

- 1 Press and release the setup key on the receiver again.
- 2 Press the setup key on the keypad.

When the light emitter diode (LED) on the receiver is lit, the keypad is set up with an ID and the receiver is locked.

You are now ready to use the keypad.

Using the Keypad

Activate Num Lock (LED illuminated)

Definition of the keys:

Num Lock	/	*	BS
7	8	9	-
4	5	6	+
1	2	3	Enter
0	00	.	

Deactivate Num Lock

Definition of the keys:

Num Lock	/	*	BS
Home	↑	PgUp	-
←		→	+
End	↓	PgDn	Enter
Ins		Del	

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.