



Model name: SCON

Rear Seat Remote

Introduction

Applies to: vehicles with Rear Seat Remote

With the Rear Seat Remote you can control convenience features and infotainment functions (e.g. adjust the seats or play media) in the rear cabin.

WARNING

- Do not allow the Rear Seat Remote features to distract you from watching the traffic – risk of accident! Do not reach into the rear to operate the Rear Seat Remote while you are driving.
- The Rear Seat Remote can only be operated safely when the vehicle is stationary or when the remote is secured in its holder in the corresponding vehicle. Like all loose objects, it could otherwise be catapulted through the vehicle in an accident and cause serious injuries. If the Rear Seat Remote is not in the holder provided, it must be stowed safely while the vehicle is being driven.
- No Wi-Fi devices may be used from the front seats in the areas around the airbags while the vehicle is being driven. Please also observe the safety warnings in the chapter on .
- The surface of the Rear Seat Remote can become hot when used for an extended period or while it is being charged. In this case, avoid prolonged contact with the surface of the Rear Seat Remote - risk of injury!

CAUTION

Prevent the Rear Seat Remote from coming into contact with liquids.

Note

- Please note that the Rear Seat Remote requires your vehicle's Wi-Fi hotspot for operation and can only be used when the ignition is on.
- When playing content from online media services, video playback may be restricted and it may take longer to load the content, depending on the Internet connection and

Wi-Fi availability (e.g. in cases where several devices are using the hotspot intensively).

- The Rear Seat Remote can only be connected to the MMI of its corresponding vehicle. This protects it against theft. In addition, the Rear Seat Remote locks itself if it has not been connected to the MMI in more than 30 days. To unlock the Rear Seat Remote again, connect it to the MMI by securing it in its holder .
- Signals from Wi-Fi hotspots within range of the vehicle can interfere with the in car Wi-Fi services.

Wi-Fi hotspots are within range of the vehicle, the data transmission rates may be reduced, the connection may be lost and there may be restrictions to video broadcasts on the Rear Seat Remote.

Setting up

Device layout

Applies to: vehicles with Rear Seat Remote




Fig. 1 Rear Seat Remote: Overview

- ① Microphone
- ② Volume button (quieter/mute)
- ③ Volume button (louder)
- ④ Loudspeakers
- ⑤ Display



Using the Rear Seat Remote holder

Applies to: vehicles with Rear Seat Remote



Fig. 2 Centre armrest (rear): Rear Seat Remote holder

Taking out the Rear Seat Remote

- ▶ To release the Rear Seat Remote, press the button ①
- ▶ Take the Rear Seat Remote out of the holder with both hands.

Securing the Rear Seat Remote

- ▶ Hold the Rear Seat Remote in both hands so that the volume buttons ② and ③ are facing upwards.
- ▶ Carefully push the Rear Seat Remote into the holder until you feel it engage.

WARNING

Always secure the Rear Seat Remote firmly to the holder after use so that it is not catapulted through the vehicle in the event of a braking manoeuvre or accident - risk of injury!

Connecting with the MMI system

Applies to: vehicles with Rear Seat Remote

To use the Rear Seat Remote you first have to connect it to the MMI.

Important: The ignition must be switched on.

- ▶ Secure the Rear Seat Remote in the holder provided ⇒ *page 2*. The Rear Seat Remote will be connected automatically to the MMI.

You can establish a connection manually.

Important: The ignition must be switched on. The Rear Seat Remote must be switched on. The Rear Seat Remote must be within range of the ve-

hicle's Wi-Fi hotspot. The requirements for the Wi-Fi hotspot must have been met and the Wi-Fi function must be switched on. The Discoverability function must be switched on.

- Select: Ω button > Settings > Wi-Fi.
- Tap on the name of the Wi-Fi network (SSID) for your vehicle. Refer to .
- If necessary, enter the password for the Wi-Fi hotspot in your vehicle. Refer to .

The ∞ symbol is displayed in the status line while there is an active connection with the MMI.

Note


The connection with the MMI will remain active if you take the Rear Seat Remote out of the holder.

Charging the battery

Applies to: vehicles with Rear Seat Remote

The battery for the Rear Seat Remote is charged in the vehicle.

Important: The ignition must be switched on.

- ▶ To charge the battery, secure the Rear Seat Remote in its holder ⇒ *page 2*. The battery will be charged automatically .
- ▶ To display the charge level select: Ω button > Settings > Battery.

CAUTION

The battery is permanently installed in the Rear Seat Remote and may only be changed by an Audi dealer. Improper modifications to the battery can cause malfunctions and damage the Rear Seat Remote.

Note

- Batteries have a limited service life. If the operating time of the battery drops off considerably, it is time to have the battery replaced. Please visit your Audi dealer or specialist dealer should you require a new battery.
- The Rear Seat Remote is equipped with an intelligent battery management system to ensure a long battery service life. In certain ≤

circumstances, particularly in case of high or low temperatures, the battery may not be charged to its full capacity.

How to use it

Tapping

The Rear Seat Remote is controlled via a touch-sensitive display in much the same way as a smartphone.



Fig. 3 Display: Selecting a function or button

Selecting a function or button

- ▶ Tap on the desired function or button (e.g. Audi radio app or **Playback** button).

Tapping and holding



Fig. 4 Display: Tapping and holding

Tapping and holding

- ▶ Tap on an element until an option or action assigned to the element is displayed or started.

Example: Calling up the options menu

- ▶ Tap on an element until the options menu appears.
- ▶ Tap on an option.

Closing the options menu

- ▶ Tap anywhere on the screen of the Rear Seat Remote.

Note

The options menus remain open until an option is selected.

Scrolling and dragging




Fig. 5 Display: Selecting a function

Scrolling through menus/lists

- ▶ Swipe your finger up/down ⇒ Fig. 5.

In the selection menus **1/3** (for instance, you can swipe your finger upwards to see more media sources/categories.

Scrolling

- ▶ Swipe your finger to the right/left ⇒ Fig. 5.

Dragging to close

- ▶ Drag an object upwards with your finger to close it ⇒ Fig. 5.

Finding entries


Applies to: vehicles with Rear Seat Remote

You can search for e.g. tracks and video files in the Rear Seat Remote source.*

Important: The X symbol must be displayed.

- ▶ Tap on X.
- ▶ Enter the search term in the entry field.
- ▶ Scroll through the list of results if necessary.
Tap on an entry in the list of results.

Rear Seat Remote

To display the list of results in full screen mode:
Tap on the  button on the virtual keypad.

To clear the entry field: Tap on .

Entries containing the search terms entered will be displayed in the list of results.

If the desired term is not yet displayed, continue entering letters until it appears.

Note

The system will only search for files on the active source.

Controls at a glance

Menus and symbols

Applies to: vehicles with Rear Seat Remote














Fig. 6 Display: Layout of home screen (left) and submenu (right)

Symbol / marking	Description
	To select and call up Audi apps ⇒ <i>page 5</i>
	To adjust the volume of the MMI or Rear Seat Entertainment system*. To call up telephone functions during a phone call –
	To switch the seat heating/conditioning for the right seat on/off
	To adjust and control the air conditioner for the rear cabin ⇒ <i>page 5</i>
	To switch the seat heating/conditioning for the left seat on/off
	To call up the home screen
	To go back one step (context-sensitive function)
	To open the options menu (context-sensitive function)
	To switch the screen mode from landscape to portrait format (context-sensitive function)
	Various media sources can be selected, depending on the equipment in your vehicle.

	Symbol / marking	Description
	Adjusting the volume	To adjust the volume of the MMI or Rear Seat Entertainment system*
	Connection manager	To connect the Rear Seat Remote to a telephone
	Signal strength bars for telephone	Reception strength for the telephone

Overview of Audi apps

You can control the following Audi apps with the Rear Seat Remote, depending on the equipment in your vehicle:

- Seats
- Lights
- Sun blinds
- Media
- Radio
- TV
- Telephone
- Connections
- Sound
- Setup ⇒ *page 6*

Air conditioner

Applies to: vehicles with Rear Seat Remote

- ▶ Press the quick access button for the air conditioner . Or:
- ▶ Swipe your finger upwards from the bottom edge of the screen.

Rear seats: You can switch the air conditioner on/off, adjust the temperature, activate automatic mode or adjust the blower speed/air distribution.

Applies to vehicles with reclining rear seat: You can adjust the leg support heating for the **front seat**.

Seats

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Seats** app.

Adjustment

Rear seats: You can adjust the head restraint, lumbar support, top section of the backrest or seat angle.

Applies to vehicles with reclining rear seat: You can adjust the Rear Seat Entertainment system*, backrest, leg support or seat position for the **front seat**.

Applies to vehicles with reclining rear seat: You can set the reclining position or normal position.

Massage

Rear seats: You can start/stop the massage function or adjust the intensity and type of massage (wave, circles, stretch, rest, shoulder, back, activation, revitalisation).

Applies to vehicles with reclining rear seat: You can start/stop the foot massage function or adjust the intensity, foot area and type of massage (wave, stroke) for the **front seat**.

Balance

Rear seats: You can adjust the zone affected by the seat heating/conditioning.

Lights

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Lights** app.

Matrix

Rear seats: You can switch the matrix lights on/off or adjust the size, brightness and position of the matrix lights.

Background

You can adjust the colour and brightness of the background lighting.

Sun blinds

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Sun blinds** app.

≤

Rear Seat Remote

You can open/close all the sun roofs and sun blinds simultaneously.

You can open/close the sun blinds for the sun roof, rear window and rear side windows individually or tilt/open/close the sun roof.

Media

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Media** app.

Radio

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Radio** app.

TV

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **TV** app.

Telephone

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Telephone** app.

Connections

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Connections** app.

Sound

Applies to: vehicles with Rear Seat Remote

- ▶ Select the **Sound** app.

Settings

Applies to: Rear Seat Remote

- ▶ Select the **Setup** app.

Technical data and troubleshooting

Technical data

Applies to: vehicles with Rear Seat Remote

Rear Seat Remote	
Display	OLED, 5.7 inch screen diagonal, 1920 x 1680 pixels
Graphics processor	NVIDIA Tegra 4
Wireless communication (Wi-Fi)	Wi-Fi 802.11 a/b/g/n/ac
Battery	Lithium polymer
Sensors	Gyro sensor, acceleration sensor, ambient light sensor, magnetic field sensor
Dimensions	??? x ??? x ?? mm (H x W x D)
Weight	??? g

Troubleshooting

Applies to: vehicles with Rear Seat Remote

Subject	Advice
The Rear Seat Remote cannot be switched on.	The battery is insufficiently charged. Attach the Rear Seat Remote to the holder in your vehicle ⇒ <i>page 2</i> and switch on the ignition. The battery will be charged. It may be necessary to wait until a suitable operating temperature has been reached before the Rear Seat Remote can be switched on again.
No touch control possible on Rear Seat Remote.	Make sure that the Rear Seat Remote function – is deactivated.

Rear Seat Remote

Subject	Advice
No connection to Wi-Fi hotspot.	Make sure that the ignition and the Rear Seat Remote are switched on. Check the Wi-Fi settings for the Rear Seat Remote. The Wi-Fi hotspot data for the vehicle must be stored on the Rear Seat Remote –.
The function of the Rear Seat Remote is impaired.	Perform a device test – on the Rear Seat Remote. Follow the directions given in the display.



Industry Canada statement:

This device complies with ISSED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d' ISSED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Caution :

- (i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- (ii) the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits specified for point-to-point and non-point-to-point operation as appropriate; and
- (iii) the worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in Section 6.2.2(3) shall be clearly indicated.
- (iv) Users should also be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Avertissement:

Le guide d'utilisation des dispositifs pour réseaux locaux doit inclure des instructions précises sur les restrictions susmentionnées, notamment :

- (i) les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;
- (ii) le gain maximal d'antenne permis (pour les dispositifs utilisant la bande de 5 725 à 5 850 MHz) doit être conforme à la limite de la p.i.r.e. spécifiée pour l'exploitation point à point et l'exploitation non point à point, selon le cas;
- (iv) les pires angles d'inclinaison nécessaires pour rester conforme à l'exigence de la p.i.r.e. applicable au masque d'élévation, et énoncée à la section 6.2.2 3), doivent être clairement indiqués.
- (iv) De plus, les utilisateurs devraient aussi être avisés que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5250-5350 MHz et 5650-5850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.





Radiation Exposure Statement:

The product comply with the Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les Etats-Unis et le Canada établies pour un environnement non contrôlé.

Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

NCC Statement:

Article 12 Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article 14 The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists.

1. 使用過度恐傷害視力

2. 注意事項

a. 使用30分鐘請休息10分鐘。

b. 2歲以下幼兒不看螢幕，2歲以上每天看螢幕不要超過1小時。

低功率警語：

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。





Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

E-label information:

User can access the E-label screen on rear seat remote by the following instruction:

Main menu->Settings->Legal Notes->png-file is visible

Security:

The regulatory information is programmed in a secured manner. End-Users or third Parties cannot modify the regulatory information page on the device.

